

MEES Air Pro 6 User Manual

Functional	Action	Role position
Power ON	Remove earbuds from case	Charging case
Power off	Placed into Charging Case	Charging case
Pause/Play	Double Tap	Left earbud
Previous Song	Press and Hold for 2s	Left earbud
Next Song	Press and Hold for 2s	Right earbud
Answer/End call	Double Tap	Right/Left earbud
SIRI	Thrice Tap	Left earbud
Space effect	Thrice Tap	Right earbud
Power on(Without charging case)	Press and Hold for 2s	Right/Left earbud
Power off (Disconnected with any device)	Press and Hold for 5s	Right/Left earbud
Reset (Disconnected with any device)	Five times tap	Right/Left earbud

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CMIIT ID: XXXXXXXX

FCC ID:2AR23-MEESAIRPRO

制造商：深圳市迈斯高科技有限公司

**Manufacturer:Shenzhen Mees Hi-Tech Co.,
Ltd**