


SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Front	
2	Back	
3	Side 1	
4	Side 2	
5	Side 3	
6	Side 4	
		


Phantom Position : Head	EUT side : Right Cheek
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Right Tilted
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Left Cheek
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Head	EUT side : Left Tilted
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Front
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat	EUT side : Front
Spacing to phantom : 0 mm	Accessory : N/A




Phantom Position : Flat	EUT side : Back
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Back
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 1
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 1
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 2
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 2
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 3
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 3
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 4
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 4
Spacing to phantom : 0 mm	Accessory : N/A

