
08C 手柄使用说明/ 08C Gamepad User Manual

Switch Mode 模式

1. 轻按[Home]键开启手柄，然后按下【Home】5 秒进入配对状态，指示灯呈滚动闪烁。

press the [home] key to open the controller gently, and then press the [home] for 5 seconds to enter the pairing state, and the indicator light flashes in a rolling manner.

- 2.打开 Switch 主机手柄设置，进入"更改握法/顺序"界面，等待手柄连接，连接成功后指示灯呈常亮显示，同时手柄震动一下。

Open the switch host controller setting, enter the "change grip / order" interface, waiting for the controller to connect, and the indicator light will be on after the connection is successful

and shake the controller at the same time.

- 3.成功配对后，下次使用按 Home 键可自动连接。

After successful pairing, press the home key next time to connect automatically

★Home 键功能为界面键。The function of home key is interface key.

接收器模式：Receiver mode

关机状态下长按 **HOME** 键 **3S**，进入接收器配对状态，蓝灯闪烁，连接上后自动识别安卓，**switch pro,PC IPTV**，连接成功后，蓝灯常亮，同时手柄震动一下；

接收器 **LED** 灯连接时闪烁，连接上手柄后常亮。

进入接收器 **Xinput** 模式，白灯闪烁，连接成功后，白灯常亮，同时手柄震动一下。

Press and hold the home key for 3S in the shutdown state to enter the receiver pairing state. The blue light flashes. After connecting, it automatically identifies Android, switch pro, PC, IPTV. After connecting successfully, the blue light is always on and the

controller vibrates at the same time;

The receiver LED flashes when connected, and is always on after connecting the controller.

After entering the receiver XInput mode, the white light flashes.

After successful connection, the white light is always on and the controller vibrates.

Android (D - input):

1. 同时按住[A+Home] 5 秒进入蓝牙配对状态，指示灯（蓝灯）闪烁状态，连接成功后灯常亮。

At the same time, press and hold [a + home] for 5 seconds to enter the Bluetooth pairing state. The indicator light (Blue light) flashes. After the connection is successful, the light is always on.

2. 打开 Android 设备蓝牙，手机蓝牙页面出现手柄图案 Gamepad,点击连接，连接成功后指示灯常亮。

Open the Bluetooth of Android device, the handle pattern gamepad appears on the Bluetooth page of mobile phone, click Connect, and the indicator light is always on after the connection is successful.

3. 成功配对后，下次使用按 Home 键可自动连接。

After successful pairing, press the home key next time to connect automatically.

IOS 模式:

1. 同时按[Y+HOM],进入蓝牙配对模式，黄灯闪烁，连接成功后,灯常亮。（XBOX 协议）

Press [y + Hom] at the same time to enter the Bluetooth pairing mode. The light flashes. After the connection is successful, the light is always on. (Xbox agreement)

2. 成功配对后，下次使用按 Home 键可自动连接。开 IOS 设备蓝牙，手机蓝牙页面出现手柄图案 Gamepad, 点击连接，连接成功后黄灯常亮。

After successful pairing, press the home key next time to connect automatically. Turn on the Bluetooth of the IOS device, the handle pattern gamepad appears on the Bluetooth page of the mobile phone, click Connect, and the yellow light is always on after the connection is successful.

Windows (x - input)

1. 同时按住[Home+A]5 秒进入配对状态，指示灯呈现闪烁状态。

Press and hold [Home + a] for 5 seconds to enter the pairing state, and the indicator flashes.

2. 打开 Windows 设备蓝牙，搜索设备手柄，出现手柄图案 Gamepad，点击连接，连接成功后指示灯常亮。

Open the Bluetooth of windows device, search the device handle, the handle pattern gamepad appears, click Connect, and the indicator is always on after the connection is successful.

- 3.成功配对后，下次使用按[Home]键可自动连接。

After successful pairing, press the [home] key next time to connect automatically.

USB 有线模式 USB wired connection

自动识别 Switch 平台，PC 平台，安卓平台。Automatic identification switch platform, PC platform, Android platform

PC 平台下默认自动识别为 X-input 模式，可以同时长按“+”键和“-”键 5 秒切换 X-input 和 D-input，白灯亮，手柄震动一下；

The X-input mode is automatically recognized by default on the PC platform. You can press the "+" and "-" keys for 5 seconds to switch between X-input and D-input. The white light is on and the handle vibrates;

连发功能设置：turbo function

1. 同时按下 Turbo+ A/B/X/Y/L1/L2/L3/R1/R2/R3 任一键开启/关闭连发功能

Press turbo + A / B / X / Y / L1 / L2 / L3 / R1 / r2 / R3 at the same time to turn on / off the turbo function

2. Turbo 连发速度为 12 次/s; 按住 turbo 键，右摇杆上下控制调节，三档分别为 20 次/秒，12 次/秒，5 次/秒，默认 12 次/秒记录用户最后一次设置。

Turbo continuous firing speed is 12 times / S; Press and hold the turbo key to control the adjustment of the right rocker up and down. The three gears are 20 times / s, 12 times / s and 5 times / s respectively. The default is 12 times / s, and the last setting of the user is recorded.

- 3.在各种模式下：

按下（第一次）A/B/X/Y/L1/L2/L3/R1/R2/R3 键与 Turbo 键可设置连发功能，手柄震动一下！

再次（第二次）按下 A/B/X/Y/L1/L2/L3/R1/R2/R3 键与 Turbo 键即实现自动连发功能，手柄震动一下；

再次（第三次）按下 A/B/X/Y/L1/L2/L3/R1/R2/R3 键与 Turbo 键可清除任一按键的连发功能，

震动调节：

先按住 Turbo 键，再按“+”或“-”键调节大小。”【+ “为加大震动；” - “为减小震动】

四档震动可调（0，40%，70%，100%）出厂默认 70%，记录用户最后一次调节。

Under various modes:

Press (for the first time) A / B / X / Y / L1 / L2 / L3 / R1 / r2 / R3 and turbo keys to set the turbo function. At the same time the handle vibrates!

Press the A / B / X / Y / L1 / L2 / L3 / R1 / r2 / R3 and turbo keys again (the second time) to realize the automatic turbo function. At the same time, the handle vibrates;

Press the A / B / X / Y / L1 / L2 / L3 / R1 / r2 / R3 and turbo keys again (the third time) to clear the turbo function of any key,

Vibration adjustment:

Press and hold the turbo key first, and then press the "+" or "-" keys to adjust the vibration . "[+" to increase vibration; - "to reduce vibration]

The fourth gear vibration is adjustable (0, 40%, 70%, 100%) and the factory default is 70%. Record the last adjustment by the user.

充电指示：

手柄关机状态：充电时对应电量灯闪烁，充满 LED 灭；

手柄开机状态：充电时当前通道指示灯闪烁，充满电当前指示灯常亮；

Charging indication:

Handle off state: the Blue light flashes slowly when charging, and the full led goes out;

Handle startup status: when charging, the current channel indicator flashes, and when fully charged, the current indicator is always on;

自动休眠 autosleep

1. 主机屏幕关闭手柄自动休眠

The Switch screen shuts down and the controller automatically sleeps

2. 5 分钟内没有任何按键操作则自动休眠

2. If there are no button operations within 5 minutes, it will automatically sleep

3. 长按 HOME 键 5 秒关机，断开与主机连接，手柄休眠。

4. Press and hold the HOME key for 5 seconds to shut down, disconnect from the host, and the controller will sleep

USB 有线模式 USB WIRED CONNECTION MODE

可以同时长按' +' 键' -' 键 3 秒切换 X-INPUT 亮 1 号灯/D-INPUT 亮 2 号灯/SWITCH PRO 亮 3 号,,
切换成功后手柄震动一下;

You can simultaneously press and hold the '+' and '-' keys for 3 seconds to switch between X-Input light 1/D-INPUT light 2/SWITCH PRO light 3. After successful switching, the controller will vibrate once;

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.