## **User Information**

## Tune-Up Procedure

Aside from the 3<sup>rd</sup> party cavity combiners, there is no field tune-up procedure. All adjustments are software controlled and are pre-set at the factory. Certain station operating parameters can be changed via man-machine interface (MMI) commands, within predetermined limits. Examples include transmit / receive operating frequencies and transmitter power level.

For information on tuning the cavity combiners, which is required only if replaced in the field, please refer to the User / Operational Manual.