


**CUSTOMER SUPPORT** 




EN

EN

**EN** 

**PACKING LIST** 



the computer to format it into FAT32.


or higher speed memory card must be used.


continue.

Step ②: Tap ﴿ to enter Settings, then tap Format and Confirm to

Due to the data rate of the video being recorded, a reputable Class 10

 ${\it 3. Professional installation of this product is generally recommended.}\\$ 







EN

**PRODUCT OVERVIEW** 


Touchscreen Display


Mirror Dash Camera







Step 5:






WIFI CONNECTION OF MOBILE PHONE







of "OFF" and "ON" in the submenu. Select "ON" and the rear image will be


 ${\bf 0}$  Note: No matter the original image or reversed image is displayed on the screen, the video file is original .

reversed on the screen. Select "OFF" and the rear image will be original on

Tap 🕲 to enter the picture playback interface, click picture to zoom in

and view, or press and hold the picture file to download.

Timestamp



EN

Only available when the GPS Receiver is installed into the GPS port of the

Tap to manually adjust the speed of your vehicle displayed on the screen.

Set the USB mode when connecting with PC. Select STORAGE to transfer

the photo/video between the camera and your PC; while select CHARGE

