




300 3330A
Ricochet Toy



Please read this entire guide before beginning



Product Manual

Homecare Radio Systems Corporation, Radio Systems PetCare Corp. Ltd., Radio Systems Australia Pty Ltd. and any other division or brand of Radio Systems Corporation may be referred to collectively as "Radio" or "Us".

IMPORTANT SAFETY INFORMATION

Explanation of Attention Words and Symbols used in this guide



CAUTION

CAUTION

NOTICE

CAUTION

Keep away from children.

- Not intended as a Toy for children.
- Do not allow small children to use this product in play with your pet without adult supervision.
- Do not use this product if you have read the entire Product Manual.
- Do not use this product as intended if there is any visible damage to it or the case. Use on the Ricochet only.
- This product should only be used in accordance with the instructions in the user guide.

CAUTION

NOTICE

- Adult supervision is required around pets.
- Inspect the product periodically for damage and discard product immediately if appears worn or broken.
- Do not use old batteries.
- Do not use standard, alkaline or rechargeable batteries.
- Do not use rechargeable batteries.
- Recharged batteries should be disposed immediately. Do not dispose of batteries with household waste.

These instructions must be retained and passed on with ownership.

Toy Assembly

No assembly is required. To use, simply insert batteries and follow the Operating Instructions. Do not place the toy on any surface other than a flat, level floor.

Battery Installation

1. Unscrew the two slotted cylindrical holes of Toy A by hand and gently pull towards the battery and sound cylinder [A].
2. Using a Phillips head screwdriver, unscrew the retaining cap at the end of the battery and sound cylinder [B].
3. Once the retaining cap is removed, remove three AAA batteries from the slots on the side of the cylinder [C].
4. Replace the retaining cap and attach with the Phillips head screw.
5. Slide the battery and sound cylinder back into the slotted end of the toy. Align each slot for the sound and the cylinder with the slotted holes of the housing. There is a slot along the side of the battery and sound cylinder that fits onto a groove made for the sound end of the toy to help with correct insertion.

6. Screw the housing back together by hand firmly until you have pushed the top slot on the side of the toy.
7. Repeat steps 1-6 for Toy B.

Operating Instructions

The Ricochet Interactive Dog Toy is a set of two interactive dog toys that stick together via Bluetooth. Once both toys are turned on, they pair together automatically to create a digital tunnel round that "jumps" between toy to the other, simulating one dog's home run. Adults and pets can trigger Toy A to begin its round. When your pet goes to play with Toy B, Toy A will receive a signal. This game continues as long as your pet plays with the toys. The paired toys automatically turn off after 60 minutes of non-activity.

1. Insert the colored end with speaker holes into each toy. Press and hold down on the cut portion of the speaker covering to turn on each toy [D]. Toy A should have a short beeping tone, followed by a continuous beep that the toy has paired. Then, Toy A will begin to speak.
2. Place Toy A in one location, and Toy B is another location either inside the house or in an adjacent room, maximum range of 10 feet (3 meters).

To Ensure Proper Function

- Do not use old and non-rechargeable batteries.
- Do not use standard, alkaline or rechargeable batteries.
- Do not use rechargeable batteries.
- Recharged batteries should be removed immediately. Do not dispose of batteries with household waste.

Advice for use

Apart from playing with the product, it is recommended that pet owners interact with their pets and provide a variety of play activities, supervised by observation and appropriate amount of daily exercise as determined by their veterinarian.



Important Recycling Advice

Please inspect the Waste Electrical and Electronic Equipment regulations in your country. This equipment must be recycled. If you no longer require this equipment, do not place it in the normal municipal waste system. Please contact the place where it was purchased to make sure that it can be placed in the recycling system. If this is not possible, please contact the Customer Care Center for further information. For a listing of Customer Care Center telephone numbers, visit our website at [pet-safe.com](http://www.pet-safe.com).

Compliance

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] This device may not cause harmful interference, and [2] This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Modification or changes to this equipment not expressly approved by Radio Systems® Corporation may void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If unfairference does occur to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Report or estimate the recurring defects.
- Increase the separation between the equipment and the receiver.
- Contact the supplier or an outlet in a place different from that in which the receiver is connected.
- Consult customer care, the dealer, or an experienced radio-TV technician for help.

ACMA

This device complies with the applicable EMC requirements specified by the ACMA (Australian Communications and Media Authority).

Terms of Use and Limitation of Liability

1. Terms of Use

Use of this Product is subject to your acceptance without modification of the terms, conditions and notice contained herein. Use of this Product implies acceptance of all such terms, conditions and notices. If you do not wish to accept these terms, conditions, and notices, please return the Product, unopened, in its original packaging and/or your own box and talk to the relevant Customer Care Center together with proof of purchase for full refund.

2. Proper Use

If you are unsure whether the Product is appropriate for your jet, please consult your veterinarian or certified trainer prior to use. Proper use includes, without limitation, reviewing the entire Product Manual and any specific Content statements.

3. No Unlawful or Prohibited Use

The Product is designed for use with pets only. Using the Product in a way that is not intended could result in violation of Federal, State or Local laws.

4. Limitation of Liability

In no event shall Radio Systems Corporation or any of its associated companies be liable for (i) any indirect, punitive, incidental, special or consequential damage and/or (ii) any loss or damages whatsoever arising out of or connected with the use of this Product. The Purchaser assumes all risks and liability from the use of this Product to the fullest extent permissible by law.

5. Modification of Terms and Conditions

Radio Systems Corporation reserves the right to change the terms, conditions and/or terms governing the Product from time to time. If such changes have been notified to you prior to your use of the Product, they shall be binding on you as so designated herein.

Warranty

One Year Non-Transferable Limited Warranty

This product has the benefit of a limited manufacturer's warranty. Complete details of the warranty applicable to the Product and its terms can be found at [petpulse.com](#) and/or are available by contacting your local Customer Care Center.

Radio Systems Corporation, 10427 PetSafe Way, Knoxville, TN 37912 USA.

Australia/New Zealand - In compliance with the Australian Consumer Law, Warrantee Against Defects, effective January 1, 2012, warranty details of the Product are as follows: Radio Systems Australia Pty Ltd. (hereinafter referred to as "Radio Systems") warrants to the original retail purchaser, and not any other purchaser or subsequent owner, that the Product, when used in accordance with its intended use, will be free from substantial material or workmanship faults for a period of two (2) years from the purchase date. An "original retail consumer purchaser" is a person who originally purchases the Product, or gets it shipped to a new. The Product must be unopened and in its original packaging. When serviced by Radio Systems Customer Service, Radio Systems covers labour and parts for the first two years of ownership; after the first two years, a service or upgrade charge will apply relative to replacement of the Product with new or refurbished items at Radio Systems' sole discretion.

The limited warranty is non-transferrable and off automatically terminates if the original retail consumer purchaser resells the Radio Systems Product or transfers the property on which the Radio Systems Product is installed. The Limited Warranty excludes accidental damage due to dog abuse, lightning damage, negligence, alteration, and misuse. Consumers who purchase products outside of Australia, New Zealand, or from an unauthorized dealer will need to return the Product to the original place of purchase for any warranty issues.

Please note that Radio Systems does not provide refunds, replacements, or upgrades for damage of any kind, unless any otherwise stated in these Warranty Terms.

Claims for credit. Any claim made under this Warranty should be made directly to Radio Systems Australia Pty Ltd. Customer Care Centre at:

Radio Systems Australia Pty Ltd.
PO Box 7250, Gold Coast Mail Centre QLD 42170, Australia
Australia Telephone: 1800 796 006
New Zealand Telephone: 0800 543 154
Email: auinfo@radio.com.au

To file a claim, a proof of purchase must be provided. Without a proof of purchase, Radio Systems will not repair or replace faulty components. Radio Systems requests the Consumer to contact the Radio Systems Customer Care Centre to obtain a Warranty Return number prior to sending the Product. Failure to do so may delay in the repair or replacement of the Product.

If the Product is deemed to be faulty within 30 days from date of origin of purchase, Radio Systems will organise for a replacement to be sent in addition to returning the faulty Product. A Post Bag will be included with the replacement Product for the return of the faulty Product. The Product must be returned within 7 days of receiving the replacement. If the Product is deemed to be faulty after 30 days from the date of original purchase, the consumer will be required to return the Product to Radio Systems at the consumer's own expense. Radio Systems will not replace the faulty unit or its components and return to the consumer free of charge, provided the Product is within its said warranty period. This warranty is in addition to other rights and remedies available to you under the law. Radio Systems goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Should you have any questions or require any further information, please contact our Customer Care Centre on 1800 796 006 (Australia) or 0800 543 154 (New Zealand).

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Ce dispositif ne peut causer d'interférences ; et
- (2) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

Le dispositif a été conçu pour répondre à la demande générale de radioexposition.

Declaration of Conformity

Radio Systems Corporation hereby declares that this Ricochet Toy is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. Frequency band(s): 2.405GHz Maximum radio-frequency power: -3dbm

Radio Systems Corporation

10427 PetSafe Way
Knoxville, TN 37912
+1 (865) 777-5404

[petpulse.com](#)

AW400-AUSA

©2016 Radio Systems Corporation