BYTECH®
THE ART OF TECHNOLOGY

BY-KB-WS-108-AC

2.4 WIRELESS TECHNOLOGY

Windows™ | Mac™ — Windows® and Mac® Compatible

wireless
CAT KEYBOARD

INCLUDES:
1 (One) Wireless Keyboard 14.9in. x 6.7in. x 2.2in. (37.8cm x 17cm x 5.5cm)
1 (One) Removable Cat Toy 4in. x 2.4in. x 1.8in. (10cm x 6cm x 4.7cm)
1 (One) USB Receiver .75in. x .625in. x .25in. (1.9cm x 1.6cm x .6cm)
1 (One) User Manual

FEATURES
• Wireless connection: automatic linking, plug & play via USB receiver.
• Responsive buttons for ultimate productivity and efficiency.
• Ergonomic design for maximum performance and comfort.
• Customize your working angle with the flip-out stand.

USB RECEIVER
• The USB receiver can be found (and stored) in a slot on the bottom of the keyboard, on the opposite side of the battery bay door.
• Flip the keyboard over. You will see a small rectangular object embedded in a slot in the bottom of the keyboard, imprinted with the FCC ID number, this is the USB receiver unit, and it can be stored in this slot when not in use so that it doesn't get lost or damaged. The keypad will not work without the USB Receiver.
• Remove it carefully by hooking a fingernail into the groove along the side surface, and lift it up slowly to free it, being very careful not to damage or lose it.

HOW TO USE
• Insert the USB receiver into one of your computer's USB ports.
• Place 1 (One) AA 1.5V Alkaline Battery battery (not included) into the battery compartment on the back of the keyboard.
• Locate the power switch on the top/back of the keyboard and switch it ON. To preserve battery life and keyboard functionality, turn it OFF when not in use.
• Your computer should recognize the keyboard instantly. Be sure to check your computer's settings if it is not detected.
• If the keyboard is unused for 2 seconds, it will enter sleep mode, press any key to resume.
• Remove the USB receiver from your computer's USB port when the unit is not in use.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Keyboard: FCC ID: 2AHN6-KBWS108
Dongle: FCC ID: 2AHN6-DE4

TROUBLESHOOTING
If device won't connect, try the following:
• Be sure the USB receiver is connected to your computer.
• Be sure the USB receiver is not damaged.
• Check your computer's input settings.
• Try new battery in the keyboard.
• Restart your computer.

SPECIFICATIONS:
• 2.4GHz wireless keyboard
• 69 keys
• ON/OFF button
• Working range: up to 33 feet
• Battery: 1 (One) X AA 1.5V Alkaline Battery (Not Included)

UNIVERSAL COMPATIBILITY
Windows® 7/8/10/11/2000/XP/ME/VISTA & Mac OS®.

WARRANTY- 12 MONTH
Please visit our website Bytechintl.com/warranty

BYTECH
Contact Info:
2585 West 13th Street,
Brooklyn, NY 11223
BYTECHintl.com
© 2024 BYTECH NY INC.

CE FC

⚠ **WARNING: TO AVOID BATTERY LEAKAGE**
1) Be sure to insert the battery correctly, and always follow the toy/game and battery manufacturers' instructions.
2) Always remove a weak or dead battery from the product.
3) Remove the battery if the product is left unused for a long period of time.