



Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-2


2422 MHz



2437 MHz




2452 MHz




Mode 3: IEEE 802.11g Continuous TX mode_ANT-3


2412 MHz



2437 MHz




2462 MHz




Mode 8: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode_ANT-3


2412 MHz



2437 MHz




2462 MHz




Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-3


2422 MHz



2437 MHz




2452 MHz




Out of Band Conducted Emissions

Mode 2: IEEE 802.11b Continuous TX mode_ANT-0


2412 MHz



2437 MHz




2462 MHz




Mode 3: IEEE 802.11g Continuous TX mode_ANT-0


2412 MHz



2437 MHz




2462 MHz




Mode 8: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode_ANT-0


2412 MHz



2437 MHz




2462 MHz




Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-0


2422 MHz



2437 MHz




2452 MHz




Mode 3: IEEE 802.11g Continuous TX mode_ANT-1


2412 MHz



2437 MHz




2462 MHz




Mode 8: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode_ANT-1


2412 MHz



2437 MHz




2462 MHz




Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-1


2422 MHz



2437 MHz




2452 MHz




Mode 3: IEEE 802.11g Continuous TX mode_ANT-2


2412 MHz



2437 MHz




2462 MHz




Mode 8: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode_ANT-2


2412 MHz



2437 MHz




2462 MHz




Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-2


2422 MHz



2437 MHz




2452 MHz




Mode 3: IEEE 802.11g Continuous TX mode_ANT-3


2412 MHz



2437 MHz




2462 MHz




Mode 8: IEEE 802.11ax 2.4 GHz 20 MHz Continuous TX mode_ANT-3


2412 MHz



2437 MHz




2462 MHz




Mode 9: IEEE 802.11ax 2.4 GHz 40 MHz Continuous TX mode_ANT-3


2422 MHz



2437 MHz




2452 MHz



Conducted Band Edge

Mode 2: IEEE 802.11b Continuous TX mode_ANT-0

2412 MHz



2462 MHz

