

按键	功能说明	操作	安全事项
-\\\-\-	开机	长按,开机后直接进入蓝牙搜索状态	为确保安全,请先详细阅读及遵守以下安全提示: 1.此产品不能服用,请放置于儿童不能拿取的地方以防意外; 2.请勿将机器放置在高温环境,包括太阳直射; 3.请勿将机器放置在靠近火源或其他过热环境; 4.请勿将机器放置于潮湿或湿度太大的地方; 5.除了所提供的充电线以外,请勿试图用其他的方法为机器充电。1.请勿将机器拆开,禁止企图修理,改造机器的任何行为; 7.请注意跌落、撞击、擦伤或其他影响机器功能的行为,如果4任何损坏,如发烫、高温变形或腐蚀等,请立即停止使用该品设备; 8.如果机器产生异常气味,高于正常温度,颜色或形状出现异
	关机	长按,关闭蓝牙音箱	
	TWS组队	双击开机键进入TWS组队模式,连接成功后,主机左声道,副机右声道	
	灯光模式更换	短按, 改变灯光模式	
	复位	开机键和暂停键同时按,可以强制关机	
	来电接听	来电时,短按接听电话	变化,请立即停止该机器的使用; 9.如果电池更换不当会有燃烧危险,只能用同类型或等效类;
	来电拒接	来电时, 长按 2S拒接来电	的电池来更换; 10.长时间高音量使用机器,可能会对您的听力造成损伤。
	结束通话	通话时短按,挂断通话	
	播放/暂停 音乐播放	短按,播放/暂停音乐	温馨提示
	功能切换	长按2秒,切换BT/TF/AUX模式	1.当机器超过3个月未使用时,需要给机器充电后再使用; 2.长期不使用时,建议每3个月为机器充一次电,能更有效的份护电池的使用; 3.建议收到机器充满电后使用。
	断开蓝牙连接	蓝牙连接成功后,长按5秒,断开蓝 牙连接	
_	上一首	长按按键"一",切换上一曲歌曲	电源说明
	音量减	短按按键"一",音量减少	a.请使用支持5V/2A的充电头及原装Type-C线充电; b.充电状态红灯常亮, 电量充满后红灯熄灭;
	下一首	长按按键"+",切换至下一曲歌曲	D. 允电状态红灯吊壳,电量充满加红灯熄火; c.当电压过低时,会有"嘟嘟"提示音。
\top	音量加	短按按键"+",音量增加	

安全事项 请在使用产品之前阅读手册 🛕 🛕 🗵 **电池使用警告!** 电池如果更换不当,则可能存在泄漏或爆炸及造成人身伤害的危险。 如果替换为错误的电池类型,可能有引起火灾或爆炸的风险。请参照所附说明,确保 为确保安全,请先详细阅读及遵守以下安全提示

某替致力错误的电池卖型,可能有引起X买或爆炸的风险。请参照所附说明,确保 他的正确安装。可充电电池如果处置不当,则可能存在火灾或化学烧伤的危险。切 拆卸或将电池与导电材料、液体接触、或暴露于温度超过54°C(130°F)的环境中。 于极低气压下的电池可能会导致爆炸或者易燃液体或气体泄漏。切勿在电池出现泄 变色、变彩或出现任何其足异常的情况下使用或充电、不要让电池,此电池不可更换 或不使用的状态。切勿短路,您的设备可能包含内置可充电电池,此电池不可更换 b寿命随使用情况而异。已报废电池应当依据当地法律进行弃置。如果没有相关法 就法规,请将您的设备丢弃在用于电子设备的垃圾桶中。应将电池放置于远离儿童

举激光产品: 本产品符合国际标准IFC/FN60825-1: 2014、1举激光产品规定。同时 CFR1040.10规定,IEC 60825-1 Ed.3.除外,如2019年5月8日发布的第56号 otice(激光公告)中所述。最大功率716微瓦CW,发射波长832-865纳米;

警告! 如果不按照此处插定的程序进行控制、调整或操作、则可能导致辐射伪善。 警告! 请避免长时间直接以眼睫和小或皮肤接触激光光圈。可能导致烧伤。 本产品包含1类LED。操作温度在0°C至40°C之间 110类激光产品: 本设备符合国际标准LEC/EN60825-1: 2014, 11M类激光产品的相关 要求,同时符合21CFR 1040.10的要求,LEC 60825-1Ed.3.除外,如2019年5月8日发 布的第56号Laser Notice(激光公告)中所述,不可见红外光放射至少+-2°的调散光 束;最大功率为1.4微瓦的连续波,放射的波长范围832-865纳米;操作温度0°C至40°C 警告! 激光辐射。使用光学放大仪器在100毫米距离内查看激光输出可能造成眼睛伤害

使用指南-安全正确地使用产品:

余电池移除和更换外,请勿自行拆削或改装产品。 请勿拆卸或尝试维修本产品,因为这样做可能会导致辐射伤害。 请勿将红外/激光光束指向任何人的跟睛或反射物体。 请勿将产品及人任何液体中,或暴露在炎热或潮湿的环境中。 如果将产品暴露于超出既定温度范围的环境中,则切断电源设备,直至温度在指定 知候作温度范围内达到稳定。 於品仅可使用臃树的电源。不得改装电源。不得在雷雨天气时为产品充电。 使用此产品请搭配所列出八认证的ITE电脑和附件。 设用此户品请将起所约由7人证的旧记电照相附针。 此产品不适合儿童使用,14岁以下儿童为非预期用户。 如果使用产品长时间重复单一动作,则可能导致手部、手腕、胳膊、肩部、颈部或背部的神经、肌腱或肌肉损伤。如果存在疼痛、麻木、酸软无力、肿胀、灼痛、抽筋或 個硬等症状,请向合格的专业保健人士咨询。 在正常和合理可预见的操作条件下,本产品不存在安全隐患。如果产品运行不正常, 请致电支持人员。如需任何服务或维修,请务必将产品送回相关部门。 未经明确批准而对本产品进行的任何改装或改造都将导致用户丧失操作本设备的权 31807年8月86年

电池、电子设备和电气设备不应与生活垃圾一同处理。只要情况允许,应将其隔离并带到适当的收集点,以便回收利用,并避免对环境和人类健康的潜在影响。
 欲了解更多信息,请联系当地主管部门或购买地点。

产品中有害物质的名称及含量 根据中国《电子电气产品有害物质限制使用标识要求》

有害物质 玻璃部件 Glass parts X O O O

表示该有毒有害物质至小在该部件的某一均质的含量超出GB/T26572标准规定的限量要求 表中标有 "X" 的所有部件都符合欧盟RoHS Recast法规-2011/65/EU指令。

注:环保使田相限的参考标准取决于产品正常工作的温度和湿度等条件

10)

产品质保卡

请填写下列信息,并加盖销售单位公章

用户档案 ____年___月 ___日 用户名称 通讯地址 联系电话 邮编 购买地址 购买价格 销售单号 经销商签名 用户签名

如需下载驱动,请联系经销商索取

并请保存产品包装盒,以维护您的合法权益。




产地:中国.深圳

FMQUSE虎猫 **Echo Valley S100** Portable Bluetooth speaker

感谢您选择虎猫S100便携蓝牙音箱

在使用本产品前请仔细阅读好使用手册!


Instruction Manua



Thank you for choosing FMOUSE S100 portable Bluetooth speaker Please read the manual carefully before using this product!

FMOUSE service@fmouse.com

Specification parameter Charging mode :Type-C DC 5V 2A Bluetooth name: FMOUSE S100 Charging time: About 3 hours Bluetooth version: V5.2 Playing time: About 4 hours Bluetooth range: ≤15M Playing time: About 10 hours Waterproof class :IPX6 Product weight: 676g ±1% Product size :W220mm*H79mm*D82mm Key function ON/OFF; Switching lights; TWS; resetti Reduced volume: Previous song



Type-C line *1 Link play Bluetooth connected playback a. Long press the "-ʊ̞k-" key to power on after the blue light flashes, the speaker enters the Bluetooth to be matched state; Speaker enters the bluetooth to be matched state; Turn on the Bluetooth of the mobile phone, search for the Bluetooth name "FMOUSE S100" and click Connect; When the blue light is steady on with a prompt tone, the Bluetooth Two TWS are connected to play a. Start two "FMOUSE S100" speakers at the same time, select one the host, and the other as the secondary; b. Double-click the "--½-" key on the host to enter TWS pairing mode. Automatically connect the secondary machine, and accompanied by a prompt tone; Wait for Bluetooth device to connect; Open the phone, search for Bluetooth name "FMOUSE S100" and clic Connect; After successful connection, prompt tone, play music can eniov wireless stereo sound: Main left track, secondary right track d. After pairing, double-click the "---—," button of any speaker to

Complimentary accessories

AUX cable playback

Sound card function

• TF card playback (up to 32G)

Connect the AUX cable to the device and the speaker to play.

After the TF card is inserted into the speaker, the speaker will

a. USB data cable can be used to connect to the computer, and

computer sound can be transmitted through the data cable.

. The type-c data cable can be used to connect with the mobile pho

nd the mobile phone sound can be transmitted through the data c

automatically read the card and play with a prompt tone The blue light is on. (Support MP3, WAV, FLAC, APE, WMA format)

key	Function description	Controls
	Power on	Press and hold to enter the Bluetooth search state
	Power Off	Press and hold to turn off the Bluetooth speaker
- <u>`</u> \-	TWS team up	Double-click the Power button to enter TWS team mode, to connect After work, main engine left track, auxiliary right track
	Light mode change	Tap to change the light mode
	resetting	Press the Power button and the Pause button at the same time to force shutdown
	Incoming call answering	When an incoming call comes in, short press to answer the call
	Call rejection	When an incoming call comes in, hold down 2S to reject the call
	End the call	Press during a call to end the call
	Play/pause Music playback	Tap to play/pause music
	Function switching	Hold down for 2 seconds to switch to BT/TF/AUX mode
	Disconnect Bluetooth connection	After the Bluetooth connection is successful, press and hold for 5 seconds to disconnect the Bluetooth connection
	Previous song	Long press the button "—" to switch to the previous song
_	Volume down	Short press the key "—" volume reduction
	Nextsong	Long press the button "+" to switch to the next song
\neg	Volume plus	Short press the key "+" volume increase

Safety matters

To ensure safety, please read and follow the following safety tips . This product can not be taken, please place in the children

- can not reach the place to prevent accidents; 2. Do not place the machine in a high temperature en
- including direct sunlight; 3. Do not place the machine near the fire source or other
- overheating environment; 4. Do not place the machine in a humid or humid place; 5. Do not attempt to charge the machine by any means other
- To not attempt to charge the machine by any means other than the charging cable provided;
 Do not disassemble the machine, and any attempt to repair or transform the machine is prohibited;
 Please pay attention to falls, bumps, bruises or other behaviors that affect the function of the machine, if any For any damage, such as burning, deformation or corro lease stop using the product immediately Product
- equipment;

 3. If the machine produces abnormal odor, higher than normal temperature, abnormal color or shape Change, please stop
- using the machine immediately; using the machine mineratery, 9. If the battery is not replaced properly, there is a danger of burning, only the same type or equivalent type can be used
- The battery to replace;

 10. Using the machine at high volume for a long time may cause damage to your hearing.

Warm reminder

- 1. When the machine is not used for more than 3 months, it is necessary to charge the machine before use;
 2. When it is not used for a long time, it is recommended to charge the machine once every 3 months, which can be more effective The use of battery protection; 3. It is recommended to use the machine after it is fully charged

Power supply description a. Please use the charging head that supports 5V/2A and the original Type-C cable to charge;

- b. The charging state red light is steady on, and the red light is off when the battery is full;
- . When the voltage is too low, a beep tone is played.

Read Manual Before product Use. 🛕 🛣

ir battery discharged or unused for extended periods. Do not short circuit, Your ice may contain an internal, rechargeable battery that is not replaceable, Battery varies with usage. Non-operational batteries should be discarded according to

ass 1 Laser product: This product complies with Inte 325-1: 2014, Class 1 Laser product, and also complies with 21 CFR 1040.10 except ormance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated Ma

al laws. If no laws or regulations govern, dispose of your device in a waste bin for

erating temperature between 0°C and 40°C. WARNING! Use of controls, adjustments or performance of pr

ecified herein may result in hazardous radiation exposure. VARNING! Avoid prolonged direct eve and/or skin contact with the laser aperture av result in notential hurn injun

he product contains Class 1 LED. Operating temperature b Class 1M Laser product: This device complies with International Standard LEC/EN 325-1:2014.Class 1M Laser product, and also complies with 21 CFR 1040.10 except conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated lay 8, 2019. Emission of diverging beam of minimum+/-2° of infrared user-invisble tht: Maximum power of 1.4 milliwatts CW. Emitted wavelenght is 832-865 nm: erating temperature between 0°C and 40°C.

WARNING! Laser Radiation. Viewing the laser output with magnifying optical nstruments within a 100mm distance may pose an eye hazard.

Use Guidelines-Safe & Proper Use of Your Product:

not open or modify the product except for battery removal and replacement. o not disassemble or attempt to service this product because there is a risk of ation exposure, which could injury you.

ot immerse product in any liquid or expose to heat or moisture.

roduct is exposed to out-of-range temperature environments, power off the vice until temperature has stabilized within the specified operating temperatur

wer supply. Do not charge your product during an electrical storm. the product with listed/certified ITE computers and accessories

is not a Children >s Product and is not intended for use by children under 1

ndon or muscle injury in your hands, wrists, arms, shoulders, neck or back. See a

nditions. If the product is operating improperly, contact support, product mus e returned or any service or repair. ly changes or modifications to the product that are not expressly approved

y void the user's authority to operate the equipment and your warranty.

household waste. Wherever possible, they should be segregated and brough an appropriate collection point to enable recycling and avoid potentia impacts on the environment and human health. For more information, ontact your local authorities or place of purchase.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

asures: corient or relocate the receiving antenna. crease the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the followir two conditions: 1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

product is safe under normal any reasonably foreseeable misuse operating Batteries, electronic and electrical equipment should not be disposed of wi