

## ET-0358C New RC Dragon with Wing\_IM

## 08JUL22

# 正反兩面印刷 W:55mm x H:86.5mm




## FRONT



## BACK

**Batteries Installation** 




To install batteries into the Remote Control Mist Spraying Dragon, unscrew the screw on the battery box cover to open the battery compartment. Insert 3 x "AA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram.

Put back in place the battery box cover and tighten the screw

#### Notice:

When inserting the batteries, you must insert according to the correct polarity, the Remote Control Mist Spraying Dragon won't function if batteries are reversed.

### **Batteries Installation**



To install batteries into the Remote Control, unscrew the screw on the battery how cover to open the battery compartment. Insert 2 x "AAA" 1 5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram.

Put back in place the battery box cover and tighten the screw

#### Notice

When inserting the batteries, you must insert according to the correct polarity, the Remote Control won't function if batteries are reversed.

### Performance Tips

- . Do not drive the RC Mist Spraying Dragon on grass, sand or go through water 2. Do not drive the RC Mist Spraying Dragon in windy or rainy weather 3. Do not drive the RC Mist Spraying Dragon into any sharp object. 4. Keep fingers, hair and loose clothing away from RC Mist Spraying Dragon. **Care and Maintenance** 
  - Always use dry and soft cloth to clean this product
- Avoid this product from being exposed to sunlight or heat.

Avoid immersing these toys in water, otherwise, the electronic parts may be damaged. Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired and in good working condition.

### IMPORTANT: BATTERY INFORMATION

### **∆CAUTION:**

TO AVOID BATTERY LEAKAGE 1. The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222) 2. Always purchase the correct size and grade of battery most suitable for

 Aways follow the instructions carefully. Use only battery host solution for intended use.
Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings. 4. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.

5. Remove exhausted or dead batteries from the product

 Remove batteries if product is not to be played with for a long time.
Do not short-circuit the supply terminals.
Should this product cause, or be affected by local electrical interference. move it away from other electrical equipment. Reset (switching ON & OFF again or removing and re-inserting batteries) if necessary.

rning	FCC Statement
roduct is suitable to be used by people who has operating experience in toy or aged no less than 8 years old. do not put the product in your mouth to prevent choking hazard of small parts. It the screw on the battery cover. Never try to open the product by unscrew the crews of product. Nothing inside for service.	This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
do not put the finger into available interspaces.	NOTE: This equipment has been tested and found to comply with the limits for a
do not play the product in a brutal way such as throwing, crashing or twisting it.	Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a
store the smaller-sized product accessories in places that are out of reach of n, in order to avoid the occurrence of accidents.	residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may
placing the batteries in places in high temperatures and avoid exposure to heat.	cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to
young children are operating the product, it shall be ensured that the adults are and making sure the product control is within the viewing range of the controller ructor) so that it makes the control of the toy more convenient.	correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver.
the product is not in use, please switch off the power supplies of the toy, and the batteries from the product.	Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/ TV technician for help.
note that we won't take any responsibility for any wrong operation as this may n severe injury or loss of property, and we cannot control the operating process the time when the user assembles or uses this product.	RF warning statement: The device has been evaluated to meet general RF exposure requirement. The

Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.

"Caution": Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

War

This pr

Please d

Except t

other s Please of

Please of

Please :

childrer

Avoid pla

When y

guiding a

When th

remove

Please

result in during t

### WHITE: FCC ID: 2ADM5-ET-0358C-49 Æ

Class 1 LED product

BLACK: ECC ID: 2ADM5-ET-0358C-40

device can be used in portable exposure condition without restriction

ITEM# ET-03580

I	
	Keep All Relevant Information
For Future Reference	

istributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in Shantou, China

PDF