

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

- Pb = Battery contains lead
- Cd = Battery contains cadmium
- Hg = Battery contains mercury

Warranty

All Maisto R/C products have a 30 days limited warranty in function and performance. You may receive a new replacement product if the defective product is returned to Maisto freight prepaid and confirmed a factory defective. Maisto's 30 days warranty is limited to factory defects in material and workmanship only. The warranty does not cover unauthorized modification, accidents, abusive use, and consequential damages per our judgment. The warranty is limited to original purchaser with dated proof of purchase only. If you have a problem with our product, e-mail or call customer service first, RA # may be issued if the problem cannot resolved over the phone or email. Return for repair or replacement must be shipped prepaid/postage prepaid and insured, include dated proof of purchase, RA# and brief description of problem. If product is returned without a dated proof of purchase, it will be excluded from the coverage of this warranty. Allow 3 to 5 weeks for delivery of repaired or replacement per Maisto's discretion. Delivery is limited in U.S.A. or Canada only. Warranty is only valid for purchases in U.S.A and Canada only. Check the FAQ section before you return the product to Maisto.

FAQ (Frequently Asked Questions)

1) Why does my R/C Vehicle not start?

- Make sure the the vehicle is turned on.
- Make sure the battery pack is fully charged and the battery is full.
- Make sure the batteries are installed per polarity indicators.
- Make sure all 4 wheels are not obstructed by any foreign objects.
- Make sure the transmitter and the vehicle are set at the same channel.

2) Why does my R/C Vehicle make unusual noises?

- Check to make sure the battery pack is fully charged and the battery is full.
- Check to make sure all 4 wheels are not obstructed by any foreign objects.

3) Will my R/C tires wear out quickly like some other R/C cars?

- Tires on Maisto R/C vehicles should not wear out quickly under normal use. However if necessary, new tires can be purchased. See the Maisto contact information below.

4) How do I buy replacement parts for my Maisto R/C Vehicle?

- New parts can be purchased. See the Maisto contact information below.

5) What if I'm still having a problem?

- Check the FAQ and make sure all attempts have been made to make the unit work.
- Check your purchase receipt date and make sure it's within the 30 days warranty period at the time you intend to send it back.
- Contact Maisto (see below), and tell us the model that you have, the problem(s) you are having, your daytime phone number, and any other information that might be helpful for us to resolve the problem. If Maisto cannot solve your problem by mail, email or telephone, we will issue a return authorization number so you can return the unit to us for repair or replacement. **No returns will be accepted without a return authorization (RA) number issued by Maisto clearly marked on the outside of the package.** Pack the unit back in its original box or another box with sufficient protective material, include a copy of your dated store receipt and a description of the problem then send it freight prepaid to the address which we will provide when we issue the RA number.

6) Please refer to FAQ section in our website for more information.

Website: www.maisto.com
Email: customerservice@MayCheongGroup.com
Phone: (909) 357-7988
8:30 a.m. - 5:00 p.m. / Monday-Friday / Pacific Time



www.maisto.com
MADE IN CHINA Eng(R1)

Maisto International, Inc., Fontana, CA 92336, U.S.A.

Age 8+

#81152/#81156 (w/rechargeable)

CAUTION - ELECTRIC TOY
NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK.
INPUT : 100-240V AC 50/60Hz 0.4A ONLY.
OUTPUT : 7.2V DC 700 mA 5.1W.

Maisto Radio Control Vehicles

Please keep this owner's instruction manual for future reference. It contains important information. We reserve the right to improve/revise the product specifications without notice.


Warning! The antenna wires are not to be inserted into socket outlets.

Contents:

- RC Vehicle: x 1
- RC Transmitter x 1
- Antenna tube x 2
- 1-Hour Battery Charger x 1
- 6V Rechargeable Battery Pack (For Vehicle Use) x 1
- 1.5V "AAA" LR03/R03 non-rechargeable Battery (For Transmitter Use) x 2
- Owner's Instruction Manual x 1


Battery Charging: (Refer to Diagram 1)

- Connect the 6V battery pack and the charger connectors.
- Plug the charger into the AC socket.
- Initial charge: allow battery pack to be charged for a minimum of 2 hours for the first two times. Subsequent charging time is around 1 hour.
- When charging is complete, detach the connectors and remove the charger from the electrical outlet.




Battery installation for the Transmitter and Antenna Tube installation: (Refer to Diagram 2 & 3)

- Use screwdriver to loosen the screw on the battery cover and to open the battery cover. (Screwdriver is not included)
- Install 2 new 1.5V "AAA" LR03/R03 batteries with correct polarity (+/-) as shown inside the battery compartment.
- Install the battery cover and then tighten the screw on the battery cover.
- Insert antenna wire into the antenna tube. Then bend down the exposed wire and insert a cover to the top end of the tube.




Battery installation for the vehicle and Antenna Tube installation (Refer to Diagram 4, 5 & 6)

- Set the "channel & power switch" on the vehicle to OFF position.
- Rotate the battery cover latch aside and open the battery cover.
- Install the battery pack into the battery compartment and plug it into the connector correctly.
- Install the battery cover and turn the latch to lock it in position.
- Insert antenna wire into the antenna tube. Pass the antenna tube through the hole in the car body. Tie a knot at the top end of the wire.







How to play: (Refer to Diagram 7, 8 & 9)

- Match the transmitter with the vehicle channel (channel A to A, B to B, C to C).
- Pull the trigger switch in the transmitter to drive the vehicle forward. Push the trigger switch in the transmitter to drive the vehicle backward.
- Turn the steering knob in the transmitter to steer the vehicle to right or left.
- The vehicle is four-wheel driving in both forward and backward with strong crawling power and independent four-wheel suspension.
- If the vehicle does not run in a straight line, adjust the wheel alignment under the chassis.
- Turn the switch of the vehicle to OFF position when not in play.



Performance Tips:

- Do not drive the vehicle on grass, sand or go through water.
- Do not drive the vehicle in windy or rainy weather.
- Do not drive the vehicle into any hard object.
- Always switch the power to OFF on the vehicle when you are done playing.
- Keep fingers, hair and loose clothing away from the vehicle.



- The operating range can be affected by a variety of factors:
 - Weak transmitter or vehicle batteries.
 - Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
- Outdoor usage is recommended in order to get optimal control range (32 feet or 10 meters).
- Remove the package, take out all accessories and assemble the product before giving it to children to play.

Cautions :

- The 6V battery pack must be charged before use. Use only the battery pack charger that came with this vehicle.
- Do not overcharge the battery pack. Do not charge for more than 2 hours.
- Do not charge the battery pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.
- Do not cover the battery pack with any sort of material while charging.
- Do not touch the battery pack when it is hot. Wait until the Battery Pack cools before installing it in the vehicle and before recharging.
- Do not dispose of the battery in fire.
- Do not dismantle the battery or charger, and do not cut the battery or charger cables.
- The battery pack will be warm after charging, and hot after use in a vehicle.
- The supply terminals are not to be short-circuited.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged by an adult!
- Battery change must only be made by an adult!
- The charger is not a toy.
- Only use the Charger to charge the 6V 700mAh Max. battery pack that comes with the product. Other types of battery may burst causing injury to persons and damage. This power unit charger is intended to be used in a vertical/or floor mount position. This Quick Charger is intended to be used for charging 6V Rechargeable Battery Pack with capacity 700mAh Max. Regular examination of Battery Charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the Charger or Battery Pack charge until such damage has been repaired.
- Note that the 1.5V "AAA" Battery is non-rechargeable and is not to be recharged. Only Batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor. Alkaline AAA batteries are recommended to be used for the transmitter. Do not mix alkaline, standard or rechargeable batteries. Do not mix old and new batteries or different type of batteries. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
- Exhausted batteries must be removed from the product.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Size: A4_297mm(W) x 210mm(H)
Color: 1C (Black)

| MAY CHEONG TOY PRODUCTS FTY. LTD. | | | | DIECUT | |
|--|--------------------|--------------------|-----------|--------|--|
| Job Item: N-Art 172/12 (Rev 3)Ins_Eng | Finished by: Qiang | Date: 08/10/2013 | Test No.: | | |
| Item No.: Maisto #81156 - R/C Rock Crawler Extreme | Check by: | DWN Name: yangming | Material: | | |