


## 7. Wireless Microphone

**MALIBU** M ^ X  
M S - 1 0 8 L T



1. Grill
2. ON/OFF Switch
3. Battery level indicator
4. Battery cover - battery acces

## 8. TWS

With the TWS function, connect two units of this model wirelessly! Follow these instructions to pair the units:

Turn on both units and set them to BT mode.

One unit will act as master speaker. Press and hold the button play/pause for 5 seconds.

When the connection is established, you will hear the "Right Channel" prompt on the master speaker and "Left Channel" on the secondary speaker.


Then connect your BT device normally. If you turn off the unit secondary or change playback mode, when you return to BT mode, The speakers will connect automatically. If you turn off the master unit, the TWS connection will be cut off.

NOTE: For TWS Connection to be possible, both units must be disconnected from any BT devices (connection must be free)

M S - 1 0 8 L T

**MALIBU**  
M ^ X

## USER'S MANUAL



**moonki**<sup>®</sup>

@moonki.sound  
www.moonki.com

## 1. Welcome to choose our speaker


## 2. Packaging content

- 1 speaker
- 1 remote control
- 1 user guide
- 1 power cable
- 2 wireless microphones

## 3. Specifications

- 8" active speaker
- Input: AC 100-240V, 50/60Hz
- Woofer: 8", 30 Oz (120mm) Woofer
- 1.5" (38mm) voice coil
- Tweeter: 25 mm
- Sensitivity: 92 dB (+/- 3dB)
- Remote control included

## 4. MP3



**Play/Pause:** Press to play a song or pause it while playing the song.

**Previous/Volume (-):** Press once to skip to the previous song / Press and hold to decrease the volume level.


**Next/Volume (+):** Press once to skip to the next song / Press and hold to increase the volume level.

**Cycle play:** To select a play mode, the options are:

1. One: Select this to play the current song indefinitely.
2. All: With this option you can repeat all the music.
3. Random: Songs will be played in random order.

**Mode:** Select an operating mode.

## 5. Back panel of the speaker



## 6. Wireless Connection

To pair the speaker with a phone or BT audio device, Press "MODE" repeatedly on the MP3 player until selecting this way.

Put your phone or device to be used in discovery mode of BT Connection.

When your phone or device displays "Malibu MAX" device, confirm the connection.

**CAUTION:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment