




Package



The diagram shows the LED indicator light on the left, which can be either blue (LED on) or red (LED off). To the right is a close-up of the device's control panel, showing a hand pressing the power button. Dashed lines connect the power button to the '2s Power on' and '5s Power off' states of the LED indicator.

02 Power off

Long press MFB for 5 seconds, with red light flashing until you hear the voice "power off".

Drücken Sie bitte lange Zeit die Multifunktionentaste ca. 2 Minuten, das blaue Licht wird 1 Sekunde blinken, bis Sie „power on“ hören.

Drücken Sie bitte lange Zeit die Multifunktionentaste ca. 5 Minuten, das rote Licht wird blinken, bis Sie „power off“ hören.

Appuyez longuement sur MFB pendant 2 secondes, avec la lumière bleue clignotant pendant 1 seconde jusqu'à ce que vous entendiez la voix "allumer".


Appuyez longuement sur MFB pendant 5 secondes, le voyant rouge clignotant jusqu'à ce que vous entendiez la voix "éteindre".

Mantenga presionado MFB durante 2 segundos, con la luz azul parpadeando durante 1 segundo hasta que escuche la voz "power on".


mantenga presionado MFB durante 5 segundos, con la luz roja parpadeando hasta que escuche que la voz "power off".

02 Active la función Bluetooth en el teléfono, busque "Mpow H20" y haga clic para conectarse. La voz "connected" se escuchará después de la conexión exitosa.

Lautstärkesteuerung / Musiksteuerung
Contrôle du volume / Contrôle de la musique
Control de volumen / Control de música
Controllo Volume / Controllo Musica
音量調整/音樂調整



Play / Pause / Answer / Hang up / Reject
Jouer / Pause / Réponse / Raccrocher / Rejeter
Reproducir / Pausa / Contestar / Colgar / Rechazar
Riproduzione / Pausa / Risposta / Riaggancia / Rifiuta
再生 / 一時停止 / 着信応答 / 切る / 拒否する



Die Verbindung Lösen
Effacer le Couplage
Cancelar Emparejamiento
Cancellare Accoppiamento
ペアリング履歴を削除する

 (Waste Electricals and Electronic Equipment)

This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Operation is subject to the following three conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.