

USER GUIDE

Send AUC

Download the Skullcandy App

© 2019 Skullcandy Inc. All rights reserved. Skullcandy, the Skullcandy logo, and all other marks contained herein are trademarks of Skullcandy Inc. in the United States and other countries. All other marks contained herein are the property of their respective owners.

Auto Power - On/Off

When the headphones are removed from the case, they will automatically power on. To turn them off, place them back in the case and the lid will close. The headphones will enter a low power state and will automatically power on again when the lid is opened.

Power - On

Press the power button on the side of the headphones to turn them on. The power button is located on the side of the left earcup.

Power - Off

Press the power button on the side of the headphones to turn them off. The power button is located on the side of the left earcup.

Pairing Mode

Press and hold the power button on the side of the headphones for 5 seconds. The headphones will enter pairing mode and the LED indicator will flash red and blue.

Pair New Device

Press and hold the power button on the side of the headphones for 5 seconds. The headphones will enter pairing mode and the LED indicator will flash red and blue.

Play/Pause

Press the play/pause button on the side of the headphones to play or pause music. The play/pause button is located on the side of the left earcup.

Volume Up

Press the volume up button on the side of the headphones to increase the volume. The volume up button is located on the side of the left earcup.

Volume Down

Press the volume down button on the side of the headphones to decrease the volume. The volume down button is located on the side of the left earcup.

Track Forward

Press the track forward button on the side of the headphones to skip to the next track. The track forward button is located on the side of the left earcup.

Track Back

Press the track back button on the side of the headphones to skip to the previous track. The track back button is located on the side of the left earcup.

Activate Voice Assistant

Press and hold the voice assistant button on the side of the headphones for 3 seconds. The headphones will activate the voice assistant. The voice assistant button is located on the side of the left earcup.

Water Resistance

The headphones are water resistant and can be used in the rain or near water. However, they are not waterproof and should not be submerged in water.

Stop Answer Mode

Press the power button on the side of the headphones to stop answer mode. The power button is located on the side of the left earcup.

LED Status

The LED indicator on the side of the headphones shows the status of the headphones. A solid blue light indicates that the headphones are fully charged. A flashing red light indicates that the headphones are in pairing mode. A solid red light indicates that the headphones are in low power state.

Re-Sync Earbuds

Press and hold the power button on the side of the headphones for 5 seconds. The headphones will enter pairing mode and the LED indicator will flash red and blue.

Pair With TV

Press and hold the power button on the side of the headphones for 5 seconds. The headphones will enter pairing mode and the LED indicator will flash red and blue.

Clear Pairing Device

Press and hold the power button on the side of the headphones for 5 seconds. The headphones will enter pairing mode and the LED indicator will flash red and blue.

Charge Earbuds

Place the earbuds in the charging case and close the lid. The earbuds will be charged and the LED indicator will show the charge level.

Change the Case

Press the power button on the side of the headphones to turn them on. The power button is located on the side of the left earcup.

© 2019 Skullcandy Inc. All rights reserved. Skullcandy, the Skullcandy logo, and all other marks contained herein are trademarks of Skullcandy Inc. in the United States and other countries. All other marks contained herein are the property of their respective owners.

1 YEAR GLOBAL WARRANTY

Skullcandy warrants that the product is free from defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty is valid in all countries where Skullcandy products are sold. The warranty is limited to the original purchaser and is non-transferable. Skullcandy will repair or replace the product at its discretion. This warranty does not cover damage caused by misuse, accident, or unauthorized repair. For more information, please visit www.skullcandy.com/warranty.

© 2019 Skullcandy Inc. All rights reserved. Skullcandy, the Skullcandy logo, and all other marks contained herein are trademarks of Skullcandy Inc. in the United States and other countries. All other marks contained herein are the property of their respective owners.