

GETTING TO KNOW YOUR COOLPAD TATTOO

Navigate your new **Coolpad TATTOO** easily and effortlessly the instant you turn it on. Witness how the phone's features lend themselves smoothly to your life every time you manage your apps-with just a tap.

Now it's exactly how it should've always been: simple and smooth. Now it's **Coolpad TATTOO**.



POWER ON & SCREEN LOCK


Get off to a running start with your new **Coolpad TATTOO**.

Connect the charger cable to the phone for a complete charge.

Turn on your phone by pressing and holding the Power Key for a few seconds.


Press the Power Key to turn on the screen and swipe the Padlock icon up to unlock your phone.

To change Screen-lock Security options, tap  >  to enter Settings screen. Then, tap **Personal** > **Security** > **Screen Lock** to select the option you want by tapping it.



GETTING FAMILIAR WITH YOUR EMAIL

Tap  >  to enter the Email screen. When using it for the first time, you need to enter your email address and password to configure an account. After your email account is configured, you can archive, delete, label or perform other mail operations. On the Email screen, you can tap  > **Settings** to add a new email account. Tap an email account and customize your Email settings.




CUSTOMIZING YOUR HOME SCREEN

The Home screen displays widgets, favorite apps, and more.

To add an app, tap and hold it from the Apps screen, and then drag it to the Home screen. To add widgets, tap and hold an empty area on the Home screen, tap **Widgets**, tap and hold a widget, and then drag it to the Home screen.

To move an app, tap and hold an item on the Home screen, and then drag it to a new location. To move the item to another panel, drag it to the side of the screen. To remove an item, tap and hold the item. Then, drag it to **Remove** at the top of the screen.




SENDING TEXTS

To send a text, tap  on your Home Screen. Enter the recipient's phone number, type your message, and then tap  to send.

To attach a file or any media such as photos or videos, tap  before sending your message.

Note: Unsent messages are automatically saved as drafts.




WLAN & BLUETOOTH

For WLAN, tap  >  to enter Settings screen.

Then, choose **Wireless & networks** > **WLAN** to turn WLAN on. Tap the name of a desired network to connect, entering the password if necessary.

For Bluetooth, choose **Wireless & networks** > **Bluetooth** to turn Bluetooth on. Your phone will begin searching for nearby Bluetooth devices. Within the list, tap the ID of the Bluetooth device so as to pair with it. Ensure that both devices show the same passkey and tap **Pair**.



When Bluetooth is turned on, your device can communicate with other nearby Bluetooth devices.

CREATING AND SHARING VIDEOS AND PHOTOS

Tap  >  to enter Camera screen.

To take a photo, focus on your subject by looking through your phone screen. Tap  to take a photo. Or swipe to the left to activate the Pro mode and tap  to take a photo.

To create a video, swipe to the right to activate the Video mode. Tap  to start recording a video. Tap  to stop when you finish recording.

To share a video or photo, tap  >  to enter the Photos screen. Select a video or photo and tap  to share.

LEARN MORE...

Download new apps by tapping the Play Store icon on the Home Screen.

Sync your Google/Gmail account by tapping Existing (or New) Gmail account. Here you can download apps, games, music, movies and other media by following the online instruction.

Take screenshots by pressing the Power key and lower Volume key at the same time.

STAY CONNECTED & GET UPDATES

Get updates, user guides and more information for your **Coolpad TATTOO** at www.coolpad.com/us. Discover what's going on right now in cell phone news, trends, techniques & other cool stuff by connecting with us at:



@CoolpadAmericas

coolpad

Copyright © 2016 Coolpad Technologies Inc. All Rights Reserved. All materials in this document including, without limitation, the design, the text, and any and all marks (unless otherwise indicated) are the property of Coolpad Technologies, Inc. Coolpad and the Coolpad logo are registered trademarks of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. Google and Android are trademarks of Google Inc. Other trademarks and trade names are the property of their respective owners.

Note: Pictures shown are for illustration only and do not represent actual devices.