

P185

80mm

SELFISTICK
使用说明

48mm



取出自拍器
从向上滑动取出遥控器。

图1

可充电电池
Type-c充电。直接充电无需更换电池。手机充电宝可充电。

图2
Type-c

夹子可旋转
自由翻转，横竖拍实现多角度拍照，拍照更随心

怎么打开四脚架
在手柄的位置向外打开，即可变成四脚架模式

稳固云台上手就拍
拍摄不用小心翼翼，画面很稳很清晰

360°旋转稳固云台
平滑顺畅。轻轻松松拍出全景大片

四脚架模式
自拍杆变四脚架模式时候，注意将杆子最后一节拉出并调整至四脚架稳固。

手机音量键拍照设置

1

2

3

单按键自拍器教程

怎样使用

1.开机:长按拍照键3秒开机，指示灯闪烁进入搜索状态。

2.蓝牙连接:打开手机蓝牙搜索"VIP"点击连接，连接成功后指示灯熄灭。

3.拍照:遥控器与手机处于连接状态时，单击拍照键，指示灯闪烁并拍照。

4.无连接关机:遥控器在无连接状态下，无操作，约5分钟自动关机。

5.已连接关机:遥控器与手机处于连接状态时，约10分钟无操作进入休眠状态，再过约10分钟无操作自动关机。

6.休眠:进入休眠状态后，按一下拍照键，回连手机。

7.关机:开机及休眠状态下，长按拍照键3秒，指示灯闪烁熄灭并关机。

8.回连功能:遥控器有记忆连接功能，手机蓝牙打开时，遥控器会自动连接已经匹配过的手机。

产品参数
夹持手机宽度:65-90mm
支持手机尺寸:4.7-7英寸

遥控器参数
电池型号:401020聚合物(可充电电池)图2
充电条件:5V1A
电池容量:55mAh
充电电流:约50mA
充满电时间:约30-60分钟
蓝牙版本:5.2
蓝牙名称:VIP

关于遥控器连接手机失败的个例问题解决方案
1)打开手机蓝牙，清除掉一部分已经配对过的设备。
2)手机关机重启。
3)蓝牙遥控器关机重启。
4)重新打开手机蓝牙进行连接。
5)打开手机蓝牙，遥控器开机，手机界面搜索到VIP时，点击连接，界面显示“正在连接/配对”时，连续快速按遥控器按键，即可正常连接(。只有第一次连接时需要激活，以后都是自动连接正常使用)


关于安卓系统手机个别出现按遥控器为加音量/调焦距/或无反应的问题的解决方案。
1)打开相机进入拍照界面。
2)向左滑动或者找到相机设置。
3)点击音量键功能。
4)将音量键功能设置为快门(不要选缩放或者对焦)。
5)个别手机相机设置路径不同，请自行查找。

本遥控器仅支持手机相机视频录制功能。暂不支持直播APP录视频功能。

操作方法:
1.蓝牙遥控器连接手机
2.进入手机自带相机或者下载其他相机APP软件
3.切换到视频界面
4.单击遥控器按键进行视频录制
5.再单击按键结束视频录制
6.使用状态:蓝灯闪烁连接手机后熄灭单击拍照，闪烁。
7.充电状态:红灯长亮,充满电,灭灯。

操作模式:
1.远程遥控,有效距离10米
2.三脚架模式
3.手持模式

SELFISTICK
INSTRUCTIONS



Remove The Self Timer
Slide the remote control up and out.

Figure 1

Rechargeable battery
Type-c charging. No need for direct chargingReplace the battery. The mobile phone charging treasure can be charged.

Figure 2
Type-c

Clip can rotation
Flip freely and shoot horizontally and vertically to take photos from multiple a

How to open the quadruped
Open the handle outward to change to quadruped mode

Stable platform
There is no need to be careful in shooting. The picture is very stable and clear

360 ° PTZ panorama
Smooth and smooth. Take a panoramic picture with ease

Quadruped mode
When changing the selfie stick to quadruped mode, pay attention to pulling out the last section of the stick and adjusting it until the quadruped is stable.

Phone volume key photography settings

1

2

3

Scan the code to learn more about remote control operation details

HOW TO USE

1. Startup: press and hold the camera button for 3 seconds to start the machine, and the indicator flashes to enter the search state.

2. Bluetooth connection: open the mobile phone Bluetooth search "VIP" and click the connection. After the connection is successful, the indicator light goes out.

3. Photographing: when the remote control is connected with the mobile phone, click the photographing button, the indicator flashes and takes pictures.

4. Shutdown without connection: when the remote control is in the state of no connection and no operation, it will automatically shut down for about 5 minutes.

5. Connected shutdown: when the remote control is connected with the mobile phone, it will enter the sleep state without operation for about 10 minutes, and then automatically shut down without operation for about 10 minutes.

6. Sleep: after entering the sleep state, press the photo key to connect the mobile phone.

7. Shutdown: in the power on and sleep state, long press the photo key for 3 seconds, the indicator flashes off and shuts down.

8. Back connection function: the remote control has memory connection function. When the mobile phone Bluetooth is turned on, the remote control will automatically connect the matched mobile phone.

Product parameters
Width of holding mobile phone: 65-90mm
Supported mobile phone size: 4.7-7 inches

Remote control parameters
Battery model: 401020 polymer (rechargeable battery) Figure 2
Charging condition: 5v1a
Battery capacity: 55mAh
Charging current: About 50mA
Full charge time: about 30-60 minutes
Bluetooth version: 5.2
Bluetooth Name: VIP

Solution to the case of failure of remote control to connect to mobile phone
1) Turn on the Bluetooth of the mobile phone and clear some pairedEquipment.
2) Turn off and restart the phone.
3) Turn off and restart the Bluetooth remote control.
4) Turn on the Bluetooth connection again.
5) Turn on the mobile phone Bluetooth, turn on the remote control, and search the mobile phone interface/When you get the VIP, click Connect, and the interface displays "connecting"/When "connect / pair", press the remote control button continuously and quickly, that istt can be connected normally / Excitation is only required for the frst connectionLive, automatic connection in the future, normal use)

For Android phones, press the remote control to add soundSolution to the problem of quantity / focus adjustment and / or no response.
1) Open the camera to enter the photographing interface.
2) Swipe left or Pnd the camera settings.
3) Click the volume key function.
4) Set the volume key function to shutter (do not select zoom or zoom Focus).
5) The setting path of individual mobile camera is different, please Pnd it yourself.

This remote control only supports the video recording function of mobile camera, and does not support the video recording function of live app.

Operation method:
1. Connect the Bluetooth remote control to the mobile phone
2. Enter the camera on the mobile phone or download other camera App software
3. Switch to video interface
4. Click the remote control button to record the video
5. Click the button again to end the video recording
6.Usage status: the blue light flashes, turns off after connecting the mobile phone, click to take pictures, and flashes.
7.Charging state: the red light is on for a long time, fully charged and off.

Operating mode:
1. Remote control, effective distance 10m
2. Tripod mode
3. Handheld mode

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.