TECH SUPPORT
support@ivtin.com

www.ivtin.com

VTIN

# PUNKER

## Wireless Speaker

# USER MANUAL

MODEL:VBS008B

Thank you for purchasing this product! Please carefully read this instruction manual before use.

English

## SPECIFICATION

| | |
|---|---|
| Output Sound Channel | 2.0 |
| Input Voltage | DC-5V/1.5A |
| Output Power | 10W*2 RMS |
| Battery | 18650 battery 3.7V/4400mAh |
| Speaker | 50mm 4Ω/10W |
| SNR | ≥80dB |
| Pairing Range | Up to 10 meters under barrier-free condition |
| Playing Time | About 15 hours at 70% volume (depends on diffirent music) |
| Standy Time | 4200 hours |
| Charging Time | About 8 hours |
| Material | ABS / Silicone/ Metal |
| Product Dimension | 180mm(L) x 71mm(W) x 70mm(H) |
| Net Weight | 458g |

## ACCESSORIES




×1

Wireless Speaker

×1

User manual





×1

AUX Audio Cable



×1

USB Charging Cable



×1

Hook

## PRODUCT DIAGRAM




① AUX Input(external input)
② USB Charging Socket
③ Power on/off
④ Microphone
⑤ Play/pause/Hands-free
⑥ Previous Track/Volume down
⑦ Next Track/Volume up
⑧ Working indicator light
⑨ Charging indicator light

## CHARGE THE SPEAKER

You must charge the speaker fully before using this product for the first time. When the sound begin to trail off or distort, the red working indicator light will light up, it is time to charge the speaker .



6-8 hours

Charging light:

Note: In order to prolong the battery life, please do not use it while it is being charged.

1. Connect one end of the provided USB charging cable to the USB charging socket on the speaker.
2. Connect the other end of the provided USB charging cable to computer or adapater.
3. The charging indicator light is red when the speaker is being charged.
4. It takes about 8-10 hours to fully charge it if it is connected to computer. About 6-8 hours if connected to adapter(5V 1.5A).
5. The charging indicator light will turn to green when the speaker is fully charged.

## POWER ON/OFF

1. Power on: long press the button" ⏻ " to turn on the speaker.
2. Power off: long press the button" ⏻ " again to turn off the speaker.



## BLUETOOTH PAIRING

1 Long press the power button" ⏻ " to turn on the speaker, the blue working indicator light will flash fast.



2




Turn on the Bluetooth function on your phone. Search for Bluetooth devices and select "VTIN Punker". (Enter code "0000" if needed.)

3 You will hear sound prompt when it is connected.




5 Now, you can play music, long press the power button once again to turn off the speaker when it is playing music.

Remark: The speaker has memory function. When you turn on the speaker next time, it will automatically connect to pre-paired phone if the Bluetooth function on your phone is on. (Please make sure your phone is in the range of pairing.)

## BLUETOOTH PLAYING

1. Hands-free call function: when a call comes in, short press " " to answer it, long press it to reject, short press it again when you finish the call.
2. Redailing: double press the button " " to redial the last called number. And short press it again when you finish the call.
3. Long press " " to disconnect with the paired Bluetooth devices.
4. Short press the button " + " to skip to next track, long press to turn up the volume; short press the button " − " to skip to previous track, long press to turn down the volume .

## AUX PLAYING

Some devices(such as MP3, MP4) have no Bluetooth function, so you can use the 3.5mm AUX audio cable to connect your device to the speaker to play music.

You can adjust volume on the speaker.

Note: After the speaker is on and without any operation for 10 minutes, it will turn off automatically.

## CAUTIONS & WARNINGS

1. It is normal that the speaker will produce slight heat when it is working or being charged.



2. DO NOT disassemble, dismantle, repair, modify, open, incinerate, paint, or insert foreign objects into the speaker without approval. Such actions may result in damage.
3. DO NOT expose your speaker to extremely high or low temperatures.
4. DO NOT leave your speaker in direct sunlight for extended periods of time.
5. DO NOT leave your speaker near open flames such as cooking burners, candles, or fireplaces.
6. DO NOT put the speaker on high places such as shelves. For safety, please put the speaker out of reach of children.
7. DO NOT make your speaker to be in contact with any sharp objects. It could cause scratches and damage.

## CLEANING & MAINTENANCE

1. If you need to clean the speaker, please turn off the speaker and disconnect it with all external devices before cleaning.
2. Please use dry and clean cloth to clean the speaker.
3. DO NOT use alcohol, benzene or other chemicals to clean the speaker.
4. If your speaker has malfunction, please turn to professional personnel. Wrong operation may lead to damage to the speaker.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.