


MainMenu



1. HOME widget

Display the current source, click to enter the source interface. Click on the widget on the right to enter the device connections settings interface

2. All Menus

Click all menu icons on the widget interface to display all items.

Phone: Operates bluetooth hands-free and audio function.

Apple CarPlay: Runs Apple CarPlay function.

Radio: Converts to the last played radio mode.

USB Video: Converts to the last played USB video mode.


Android Auto: Runs android auto function.

Media : Converts to the last played USB music mode.


Voice Memo: Enter recording mode.

Settings: Moves to the settings menu.

Phone




Click [add new]button to enter the Bluetooth connection interface, search for the Bluetooth name of the car on the mobile phone, and click pair.



[Add New]: Click to enter the Bluetooth pairing interface.

[Delete Device(s)]: Click to enter the Bluetooth device record deletion interface.




Click menu to display the bluetooth menu window.

[Display off]: Click to enter the standby interface.

[Privacy Mode]: Turn on private mode, hide Bluetooth contacts, call history, favorites list.

[Bluetooth Settings]: Click to enter the Bluetooth settings interface.

[user's manual on web(QR Code)]: Click to enter the QR code interface.



[All]: Click to show all call logs

[Dialled]: Click to display dialed call records

[Received]: Click to show received calls


[Missed]: Click to show missed calls




Show favorite phone numbers.



Display the address book interface, the upper search box can search for contacts, and the letters on the right can be quickly retrieved.



Enter the number through the dial pad, and then click the dial button to dial. If you press the wrong number, press  to delete one digit of the entered number.



Mute:

- Turns the Mic On/Off

Outgoing volume:

- Set the outgoing volume during a call.

Keypad:

- Click to pop up the keyboard interface, enter numbers

Speaker:

- Switches a voice call from the car hands-free to the mobile phone

End button:

- Ends a call

Carplay



Note

- The Bluetooth source of the machine is not available when the carplay is connected.

Connect wireless carplay

1. press [setup-device connections-phone projection] to wireless carplay connection interface




2. Click [add new] to search for available wireless carplay devices. Press the cancel button to stop the search. You can pair up to 8 devices. Click the Connect button to connect to the paired device, and click the Delete button to delete the paired device.

Radio



[FM/AM]: Click to switch FM/AM mode.

[Menu]: Click menu to display the tuner menu window.

[Favorite button] :click this button to bookmark the current channel in the list on the left.

[SCAN]: This function scans all stations and plays only stations with good signal strength for 5 seconds each.

- Press **[SCAN]** to begin the scan.
- Press **[SCAN]** again to stop the scan function.



[Display off]: Click to enter the standby interface.


[enter station]: Click to enter the digital search interface.

[station list]: Automatically search for available stations in any frequency band in sequence.

[info]: Switch ps name, pty and rt information display.

[delete favourites]: Click to enter the favorite list delete interface, you can delete the favorite channel.

USB video



Pause

- You can pause the playing file
- Press [||] on screen .

Play

- Press [▶] on screen to play it again.

Previous button

When it is pressed for a short time.

- Press the previous button to switch to the previous video (playing progress does not exceed 5 seconds).
- Press the previous button, the currently playing video will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing video

Next button

When it is pressed for a short time.

- Press a button to cut to the next video

When it is pressed and held.

- Fast forward the currently playing video

Repeat

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

Info

- Show the detailed information of the current video

List

- Click to enter the video list interface

Menu

- Click to display the USB video menu window


Return key

- return to the previous interface

HOME Button

- Back to the HOME widget interface

Android Auto



Connect wireless Android Auto

press [setup-device connections-phone projection] to wireless carplay connection interface



Click [add new] to search for available wireless carplay devices. Press the cancel button to stop the search. You can pair up to 8 devices. Click the Connect button to connect to the paired device, and click the Delete button to delete the paired device.

Media

Press the [Media] icon on the All Menus interface to enter the media interface .After entering the media interface, click the media button on the panel again to enter the reorder icons interface.



Close

- Close the current box


Bluetooth Audio

When Bluetooth is connected, the Bluetooth music icon will be highlighted. Click to play Bluetooth music.



Menu

- Display Bluetooth music menu pop-up box



Display off

- Click the [Display off] button to enter the standby interface

Privacy Mode

- Switch to privacy mode

Bluetooth Settings

- Switch to Bluetooth setting interface

8:09 AM: Click the time icon on the titlbar to enter the diagram stand by interface

USB Music

When the USB disk is inserted, the USB music icon is highlighted. Click USB music to enter the USB music interface.



List

- Click list to enter USB music player list

Repeat

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

Shuffle

- Press the random button to switch the random mode.

Previous button

When it is pressed for a short time.

- Press the previous button to switch to the previous song(The playback progress does not exceed 5 seconds).
- Press the previous button, the currently playing song will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing song

Next button

When it is pressed for a short time.


- Press a button to cut to the next song

When it is pressed and held.

- Fast forward the currently playing song

Menu

- Click menu and the USB music menu will pop up

**Display off**

- Click the [Display off]button to enter the standby interface

Media sources

- You can enter the Reorder Icons interface

Songs by this Artist

- Enter the artists category in USB music

Songs from this Album


- Enter the Album category in USB music

Sound settings

- Enter the sound settings interface


Apple Carplay

When the Apple Carplay is connected, the reorder icons interface apple Carplay icon is highlighted, and clicking apple Carplay will enter the apple Carplay interface.




Android Auto

When Android auto is connected, the Android auto icon in reorder icons interface is highlighted. Click Android Auto to enter the Android auto interface.



USB Video

When the USB disk is inserted, the USB video icon is highlighted. Click USB video to enter the USB video interface.



List

- Click list to enter USB video player list

Previous button

When it is pressed for a short time.

- Press the previous button to switch to the previous video (playing progress does not exceed 5 seconds).
- Press the previous button, the currently playing video will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing video

Next button

When it is pressed for a short time.

- Press a button to cut to the next video

When it is pressed and held.

- Fast forward the currently playing video

Repeat

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

Return key

- return to the previous interface


Menu

- Click menu and the USB video menu will pop up

Voice Memo

Press the [Voice Memo] icon on the All Menus interface to enter the Voice Memo

interface.



: Click the red button to start recording

: Click the white box to pause recording

Menu

- Click the white menu and the voice memo source menu box will pop up.



Display off

- Click the [Display off] button to enter the standby interface

Delete

- Delete recorded audio files

Save to USB Device

- Recording files can be saved to USB device

Storage Information

- You can enter the recording and storage interface

08:10:07 AM
VoiceMemo0001

: Click to play the corresponding recording file

Setup

Press the [Setup] icon on the All Menus interface to enter the setup menu interface.




Display off

- Click the [Display off] button to enter the standby interface

Menu

- Click menu to open the user manual option

Sound



Speed dependent volume control

- the audio volume will be automatically adjusted according to the vehicle speed.

Beep

- Click beep button to turn beep on / off.


Menu

- Click the menu button to open the user manual option




Position

- You can adjust the sound position by clicking the up / down / left / right arrow.




You can press media / navigation / voice recognition / phone / ringtone / beep by clicking the plus / key.



This menu allows you to set the [Treble]/[Midrange]/[Bass]. It can be adjusted by clicking the plus / key button.

Center

- Press [Center] to initialize the settings.




Parking Safety Priority

- Turn down the volume when reversing

Start-up Volume Limit:

- When starting the vehicle, if the radio and media volume is higher than the factory set maximum start level, the volume will be reduced



Reset

- Click the [Reset] button to reset all audio settings

Device Connections



Bluetooth Connections

- After entering the Bluetooth device management interface, you can add / delete / manage the Bluetooth device

Privacy Mode

- If you switch the privacy mode, Bluetooth contacts / call logs / contact collections will not be displayed

Bluetooth System Info


- Enter the Bluetooth information interface to modify the Bluetooth name/passkey

Reset

- Reset Bluetooth settings

Menu

- Click menu and the Bluetooth menu box will pop up



Display off

- Click the [Display off]button to enter the standby interface

Privacy Mode

- If you switch the privacy mode, Bluetooth contacts / call logs / contact collections will not be displayed

User's Manual on Web(QR Code)

- Click to enter the user manual interface



This interface will display the connected Bluetooth record, and click Connect to connect to wireless Carplay / Android auto.


Add New

- Add a new device

Delete

- Delete connected device records

Display



Display off

- Click the [Display off]button to enter the standby interface

Menu

- Click the menu button to open the user manual option

Automatic


- Automatically adjust brightness

Daylight


- Brightness remains in daylight mode

Night

- Brightness remains in night mode



This interface sets the headlight brightness.



Diaital Clock

- when the screen turn off, , the digital clock is displayed

Analog Clock


- when the screen turn off, , the Analog clock is displayed

None

- When the screen turn off, nothing is displayed




This interface is used to edit the home interface widget.




Display Media Change Notifications

- Non media play screen interface, when the play content changes, the media information will be displayed briefly. (When using a hard button or control to change the selection, the media information is displayed regardless of this setting.)




When the vehicle speed exceeds the preset factory set speed, the rear camera is off.




This interface is used to reset display settings.

General



Display the version number of the device.



Storage


- Display storage information

User's Manual on Web(QR Code)

- Display network user manual

Reset

- Factory settings can be restored



GPS Time

- Synchronize GPS time

Time Zone

- Press the [zone time] button to enter the Time zone Settings interface to set the time zone

Daylight Saving Time


- It will be adjusted an hour earlier in summer.

24 Hours

- Check the 24-hour format, the current time will be switched to the 24-hour format



Press the [Language] button to enter the multilingual world, and click the check box to switch to other languages.




MODE Button (Steering Wheel)

- Select media can be accessed using the steering wheel Mode button. Only active/available media can be accessed.

Custom Button (Steering Wheel)

- select a function for the custom button.



Use Wi-Fi for Phone Projection

- Using Wi-Fi for telephone projection switch

Note

- This setting is only used for wireless Android Auto/CarPlay data transmission.

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.