



USER MANUAL

MODEL: G900 4K+1080P



**REGISTER
WARRANTY**

Warm Tips:

Please scan the code or visit below link to register your 12-month warranty for free in first 30days.



CUSTOMER SUPPORT

- ▶ Item NOT As Describe?
- ▶ Item Damage or Defective?
- ▶ Missing Items or accessories?
- ▶ Problem with installation?
- ▶ Any issues what so ever.....

CONTACT US BEFORE RETURNING THE ITEM

WE WILL HELP YOU SOLVE ANY ISSUES

EMAIL US:

Dashcamhelp@outlook.com

Usually response in 8hours

Email to us directly by scanning the QR code.



Message/Call US:

Message or Call us directly by scanning the QR code.



INDEX

1. Important Tips.....	05
2. Resgiter Warranty.....	07
3. Box Contents.....	08
4. Dash Cam Overview&Buttons.....	09
5. Power on(Start Recording).....	12
6. Power Off (Stop Recording).....	13
7. Menu Setting.....	14
7.1 Enter/Exit Menu.....	15
7.2 Menu Settings.....	15
8. How to use WiFi&APP.....	18
9. Playback the recorded video.....	23
10. Installation.....	27
11.1 Install Front Camera.....	28
11.2 Install the External Camera.....	35
11. Important Functions.....	41
<i>G-sensor&Loop Recording.....</i>	41
<i>Time-lapse Video&HDR&Take Photos.....</i>	42
12. FAQ(Frequent asked questions).....	43
13. Warranty and After-Sales.....	45
14. Thanks for your Purchasing.....	46

1. Important Tips

Please read and understand warnings & safety instructions before operating

a. insert SD card

- 64GB SD Card is inserted in the dash cam already.
- The SD card can only be inserted from one direction. Before insert it, Please make sure the direction is correct as the figure photo.




IMPORTANT NOTES


b. Time Lapse video Mode and **24H Park Monitor** will be triggered only when the Hardwired Kit is connected.



GMAIPOP Hardwire Kit:
ASIN: **BOBRSNWKTV**

c. Open WiFi Quickly

Step ① Press  stop recording

Step ② Long Press on  to open WiFi

d. Battery & Charger

- The dash cam batter(200mAh)is just to maintain and save settings. It should be connected to the car charger or USB to get constantly powered, if the power is interrupted to the unit, it will shut down.
- Please use the original car charger provided to avoid fault or incompatibility.

e. Cautions for High Temperature

- Don't leave this product where the temperature may exceed 70°C (160°F)for an extended period.
- When using a sunshade, please do not place the dash cam between the windshield and sunshade, it may cause damage from heat buildup

f. Getting a rear camera cable extension

If the length(19.7feet) of the rear camera cable is too short for your car,please get a GMAIPOP extension cable by ASIN:**BOBB6VXNHV**

2.Register Warranty

G900 dash cam is coming with 1-year warranty.

Please kindly register the warranty with your AMAZON **Order #** by:

- Scran the QR code to register on your phone



- Or enter the web and register on the PC:

<https://www.gmaipop.com/col.jsp?id=115>

GET BENEFITS FROM WARRANTY

- *30-day money-back guarantee for any reason*
- *12-month warranty for quality-related issues*
- *Free user technical support*
- *Firmware version update*
- *New release promotion*

3.Box Contents



Dash Cam G900



64GB SD Card
**inserted in dash cam*




360° Suction Bracket



Car Charger



3M Sticky Mount



**Installation Kit
& Cable Hiding Clip
& Electrostatic film**




External Rear Camera
**19.7 Feet length cable
& 1 Feet length cable*



Manual

4.Dash Cam Overview&Buttons




Multiple Function Buttons



In different status, the button have different functions, please kindly refer to the button icon on the screen

In Recording Status



①

②

③

④


① Lock/Unlock Current Video

③ Take Photo

② Mute/Unmute Audio

④ Stop Recording

In NON-Recording Status



⑤

⑥

⑦

⑧


⑤ **Short Press** to enter menu
Long press to open WiFi

⑦ Switch the front/rear display window

⑥ Enter File Management

⑧ Start Recording

In Menu Status



① Exit Menu

② Scrop UP

③ Scrop DOWN

④ OK

In Filemanagement Status



⑤ **Exit Filemangement**

⑥ Scrop to Left


⑦ Srop to Right

⑧ OK

5.Power On(Start Recording)

The dash cam will automatically start recording when the car is powered on.

Engine the car, the dash cam will start and record automatically. The Recording icon will flash as “●”(Red).



- ① **Recording Icon** Red Icon in normal recording
Yellow Icon means the emergency recording and video recorded will be locked

- | | |
|------------------|--------------------------|
| ② Date&Time | ⑥ Stop Recording |
| ③ Lock/Ulock | ⑦ Battery/Charger Status |
| ④ Mute Recording | ⑧ WiFi icon |
| ⑤ Take Photo | ⑨ Audio icon |

If the dash cam doesn't start and record automatically, Please kindly go through the steps below:

- a. Make sure car charger connection is correct***
- b. Whether SD card is full, if yes, please format***

If there are still problems after checking, please contact us for replace/refund.

6.Power Off (Stop Recording)

a.Stop recording and turns off automatically:

When Car is Off, the dash cam will stop recording and turns off automatically.

Some car cigarette lighters will delay to power off when the engine is off, then the dash cam will delay off automatically as well.

b.Stop recording manually:

When Car is Off, the dash cam will stop recording and turns off automatically.



Short-Press on
to manually stop
recording

7.Menu Setting

7.1 Enter/Exit Menu



Step ①

Press  button stop recording



Step ②

Short Press  button enter menu



Exit UP Down OK

Step ③

- Press  to scroll to **UP**.
- Press  to scroll to **DOWN**.
- Press  to **EXIT**.
- Press  to **CONFIRM**.

7.2 Menu Settings

Setting Name	Setting Options	Instruction
Resolution	4K(Default)	Choose the video resolution you like. Higher resolution videos will take more storage space.
	2K	
	1080P	
Loop Recording	1MIN(Default)	Set Loop recording time, the video will be saved in increments (Details in Page 24)
	3MIN	
	5MIN	

(Refer to more settings in next page.....)

HDR	On(Default)	Improves the exposure by taking the combinations of over exposed and under exposed image into one robust wide range of lighting with higher depth image
	Off	
Time-Lapse Recording	Off(Default)	It will be triggered only when the Hardwired Kit is connected. (Details in Page 42)
	1s	
	2s	
	3s	
Plate NO.	Off(Default)	Turn on/off displaying the car plate NO. in the recorded video
	On	
Audio Recording	Off(Default)	Turn on/off the audio recording when recording video
	On	
Date Stamp	Off	Turn on/off the date display in videos
	On(Default)	
G-Sensor	Off(Default)	Setting G-Sensor's sensitivity level. (Details in Page 41)
	Low	
	Medium	
	High	
24H Parking Monitor	Off(Default)	Turn on/off the Parking Guard
	On	

(Refer to more settings in next page.....)

Screen Saver	Off(Default)	Over the set time and no operation, the display screen will automatically turn off. If you want turn on,press any button
	1Min	
	3Min	
	5Min	
RearCam Image Mirror	Off(Default)	Over the set time and dash cam stops recording, it will automatically shut down.
	On	
Volume	Mute	Setting the Volume of the camera
	Low	
	Middle(Default)	
	High	
Boot Sound	Off	Turn on/ff the operation sound when camera is on&off
	On(Default)	
Buttnon Sound	Off	Turn on/ff the button sound
	On(Default)	
Language	English(Default)	Select Language for dash cam
	Spanish etc..	
Date/Time	Setting the date&time.	
Format	Cancel	Format SD card. If G-sensor is on, please format the SD card regularly
	Cofirm	
Restore Settings	Cancel	Restore All the Settings
	Cofirm	

(Refer to more settings in next page.....)

WiFi&APP	Enter to open the G900's WiFi and Scran the QR code to dowload the APP.
Customer Service	Find our 24H Customer Service here

8.How to Use WiFi&APPs

Please kindly scan the QR code to view video guidacne of using WiFi.

Or search the web address on PC

Step 1. Download APP:

Please Search in Google Play or Apple Store for free APP **"Viidure"** to download APP

Or Scan the QR code as below to download.



ISO/APP Store



Android/Google Play

Step 2. Turn on the G900's WiFi:


Method 1: Stop Recording Firstly, Long Press on the  button.



Step ①

Press  button stop recording

Step ②

2-3s **Long Press**  button enter menu



EXIT

Step ③

WiFi Opened.
& Information showed
on screen.

Method 2: Open the WiFi in the Menu Setting



Step ①

Press  button stop recording

Step ②

Short Press  button enter menu



Step ③

Find the "WiFi&App"
in the menu