

Appendix II Internal Photographs



Open View of EUT



Internal View of EUT-1





Internal View of EUT-2




Internal View of EUT-3





Internal View of EUT-4



Internal View of EUT-5





Internal View of EUT-6



Internal View of EUT-7






Internal View of EUT-8



Internal View of EUT-9





Internal View of EUT-10



RF Module Location





Antenna & Antenna Location

