

INSTRUCTION MANUAL GUIDE OUTSIDE PAGES

This product works with Google and Amazon Alexa® devices. In order to use this feature you need to ENABLE this Device Skill with your device. Please check with your device instructions to enable the Brookstone Smart Home Skill. You will be asked to enter your login information to your app, to sync it correctly.

works with Google Home

works with alexa

©2024 BYTECH INC. Brooklyn, NY 11223. The BROOKSTONE® trademarks, names and logos are owned by BKST Brand Holdings LLC. ©2024. All rights reserved. Manufactured, marketed and distributed by Bytech NY INC. under license.

12 Month Warranty
Please Visit our website www.bytechintl.com/warranty

Alexa is a registered trademark of Amazon, Inc., Google Play® and Google Assistant® are registered trademarks of Google, Inc., App Store® is a registered trademark of Apple, Inc. Wi-Fi™ is a trademark of Wi-Fi Alliance®. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All trademarks and registered trademarks are property of their respective owners.

Customer service contact information:
2585 West 13th Street, Brooklyn, NY 11223
(718) 449-9700 www.bytechintl.com

INSTRUCTION MANUAL

INSTRUCTION MANUAL GUIDE INSIDE PAGES

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

FCC compliance statement

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

The following information is for the user of a Wi-Fi router. Please refer to the Wi-Fi router's user manual for more information.

Getting Started

- Remove the Smart Baby Monitor and its accessories from the box
- Remove any packaging from the product
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list

Key Features

- HD Wi-Fi Smart Baby Monitor makes it simpler to keep an eye on your baby and nursery room
- App supports up to 16 Cameras (sold separately)
- Full HD 1920x1080 pixels resolution
- Easy to install and set-up
- Support baby and nursery room through your phone
- High-definition video streaming
- 100° Degree wide-angle view
- Wi-Fi option. **This device does not currently support 5GHz Wi-Fi bands.** Please see that your phone is connected to 2.4GHz Wi-Fi band of your router.
- Motion detection
- Support ONVIF & Siren
- Sound detection
- Two-way audio for communication
- Search and download
- Support Micro SD (TF) card memory card slot (supports up to 128GB card, memory card not included)
- App available on iOS and Android

Package Contents

- HD Wi-Fi Smart Baby Monitor
- Wall Charger
- Type-C Power Cord with Temperature sensor
- Instruction Manual
- Quick Start Guide

Safety Instructions

- Keep the monitor away from extreme heat sources or fire.
- Do not use the monitor if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the monitor free from dust, lint, etc.
- Do not use this monitor for anything other than its intended use.
- Keep the monitor out of reach of children.
- This product is not a toy

Charging Cable Connections

Connect the Type-C power cord to the power port of the monitor and insert the other end into the Wall Charger.

It will take about 15 seconds for the monitor to start-up.

Compatibility

This HD Smart Baby Monitor is compatible with the Brookstone App, and with the devices using iOS 8.0 and above with Wi-Fi option, or Android 5.0 and above with Wi-Fi option. **This device does not currently support 5GHz Wi-Fi bands.** Please see that your phone is connected to 2.4GHz Wi-Fi band of your router.

Operating Instructions

Search and download Brookstone App from App Store, Google Play or SCAN QR CODE HERE. Open the App, and it will ask you to register your device. Select your country, enter your email, get Verification Code and input your password to confirm.

Baby Monitor parts and description

- Micro SD card slot. Use 128GB or less Micro SD card to enable recording. The Micro SD card has to be formatted in advance as FAT32 file system.
- Reset slot. Press and hold the Reset key for 5 seconds to reset the camera.
- Light sensor.
- Microphone. Use the App to converse for 2-way audio.
- Camera lens.
- Camera activity indicator. Red color: camera system started; Blue blinking: ready to pair; Solid Blue: camera online, Night Lamp ON/OFF function is controlled by App.

8. Type-C USB power port (Input power: 5V DC, Max.1-1.5A). 9. 1/4" Screw socket for mounting the flexible bracket or other tripod accessories.

10. Speaker

11. Temperature Sensor (is attached to the charging cable, not shown).

Note: If reset is required, use the Reset Key to press into the Reset slot on the top of the monitor (No.2) for several seconds until the monitor starts beeping.

Adding a new Baby Monitor to your network via App

Power the camera by using the supplied Wall Charger and the Charging Cable. The camera will be turned on automatically. Check to be sure the camera is in pairing mode. The Camera activity indicator (6) will turn Red and then start flashing rapidly in Blue color. If it's not already flashing, press and hold the Reset slot (2) with the Reset key until you hear an audible tone.

- Launch the "Brookstone" App and click "Add" icon and your Baby Monitor should be automatically discovered by the App.
- Once connected successfully, the App will show "Done". Click "Done" to enter next step.
- Select the same 2.4GHz Wi-Fi network (does not support 5GHz) of your phone or tablet and input your network password, then tap "Next". In the event that the monitor does not automatically connect, please check that the Bluetooth™ on your phone is turned on and you gave

permission for the App to access the Bluetooth™ & Wi-Fi.

4. Wait for about 10 seconds until you hear voice message "Doing prompt", then 20 ~30 seconds later "Please configure network".

Troubleshooting Monitor connection:

Make sure the Camera activity indicator is flashing. If the Wi-Fi signal is not flashing, you will need to press and hold Reset. Make sure the Wi-Fi network is a 2.4GHz network, the device will not connect to a 5GHz network. Test your Wi-Fi network connection with other devices such as your phone or computer to make sure it is operation properly. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection. Your Wi-Fi network password is case sensitive, make sure you are entering it correctly. There could be a temporary issue with your Internet connection (e.g., service disruption). Please try again in a few minutes.

Make sure your Wi-Fi router is turned ON. The Monitor may not have power, make sure the wall switch and breaker is in the ON position.

Make sure the Monitor is getting a good signal from your Wi-Fi router. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection. The Monitor may have been disconnected from your Wi-Fi network, press and hold Reset until you hear an audible tone.

App Main Functions

- Location Management.
- Add a New Device.
- Location Weather Information.
- Display management.
- Add new device.
- Me, Your Personal Information: Home Management.
- Motion: read Message Center FAQ & feedback.
- Smart Scene with conditions of other smart devices.
- Home device list.


