

JOWAY
POWER BANK
JP268
使用指南
ENERGY DRIVE TECHNOLOGY
User Guide

AC 充电器
AC: Power adapter connect AC.

笔记本电脑USB接口
Computer USB port

(1)

(2)

Discharge: Plug and play. When the mobile power supply in standby mode, the power bank will charge the mobile when the mobile phone connected to the power bank. The power bank will enter into the normal discharge working state, until the electric equipment such as mobile phones or tablets is fully charged or pull out the charging cable after 55 to 65 seconds, the power bank will stop discharge automatically. When the power bank didn't continue to discharge in 55-65 seconds (i.e., no electricity), power display will automatically pull out, shut down output, and enter into power saving mode. During the power saving mode, the power display will not display the power in real time without pressing the button (for a while, the interval period shall not exceed 55-65 seconds, otherwise the mobile power will turn off the output and enter the power-saving mode. The power bank will display the power in real time without pressing the button when the power bank is charging the mobile phone, tablet computer or other electric devices.



● 维护：“移动电源”享有从您购买日期开始，为期一年的保修。

■ 保修和保养：您的设备具有优良的品质，为了延长产品的寿命，请确保您执行以下操作：

- ★ 请存放在干燥并远离潮湿和腐蚀性物品的地方。
- ★ 不要试图拆开设备。
- ★ 不要将设备存放在过热或过冷的地方。
- ★ 不要扔、敲打或强烈震动设备。

■ 保修条款：使用前请仔细阅读使用说明，错误的使用方法和人为的损坏，本公司将不承担任何责任。维修时必须出示相关单据，否则本公司有权不提供维修服务。非本公司人员曾经振动或修理过产品，本公司一概不担保。所有产品均经过严格检验，如果您在使用过程中发现产品有过热、变形、破损或者其他异常现象的，请立即停止使用并与销售商或与我们联系。

■ Guarantee: We guarantee 1 year since you buy this product.

■ Maintain: Your product possess of perfect quality. To extend the productlife, please do as follows:

- Be dry and keep away from damp and erosive goods. Don't disassemble the product. Don't store it under over-heat or over-cold.
- Don't try to open the product.
- Don't throw or knock or shake the product.

■ Warranty Clause: Please read carefully the user guide. We will not be responsible for any wrong operating or damage by human. Please provide the original invoice, or we have rights to reject to offer warrant service. If your device had been dissembled or repaired by others people, we'll not warrant for it. All of the products have been tested and verified. If it occurs over-hot, out of shape, breakage or other abnormal cases, please stop to use and contact with sales agent or our company.

物料编码 : WSMS-JP268-1



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ? -Reorient or relocate the receiving antenna.
- ? -Increase the separation between the equipment and receiver.
- ? -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ? -Consult the dealer or an experienced radio/TV technician for help.

The distance between user and Wireless charging mat should be no less than 20cm