

BACK

ON/OFF

To turn it ON you should press and hold the Power Button 2 seconds. To turn it off you should press the Power Button 3 seconds at any time.

BLEETOOTH® PAIRING

Turn ON the speaker and it will start pairing mode automatically, find the corresponding name (JOY AQUA) from the Bluetooth® list on your device and click pairing.

CALLS

After connecting the speaker to your phone, or a device that allows calls, simply press the Phone Button to hang up or answer an incoming call; Double click Phone Button to redial the previous call; Long press to reject an incoming call.

MUSIC

When playing music through Bluetooth®: Press the Play/Pause Button to pause the music, press it again to continue playing.

Press the Play Button to play the previous song; press the Forward Button to play the next.

Press and hold the Play Button to Low Volume; press and hold the Forward Button to increase volume.

OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep cables away from babies and children. This product is not a toy.

Do not treat this product as household waste. Dispose of this electronic properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.

ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator's effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, www.gojoy.com

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Cautions: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES

