

# INSIGNIA™

NS-CAHBTEP01

Bluetooth Earpods

## Package contents

- Bluetooth Earpods
- USB charging cable
- Quick Setup Guide

## FIND YOUR USER GUIDE ONLINE!


We are going green so a copy of your *User Guide* is not provided in the box but is available online.

Go to [www.bestbuy.com/modal](http://www.bestbuy.com/modal), then click **Support & Service**. Enter your model number in the box under **Manual, Firmware, Drivers & Product Information**, then click ►.

Before using your new product, please read these instructions to prevent any damage.

## QUICK SETUP GUIDE

## Features



#	Item	Description
1	+ Volume Up Next Track	Press + to increase the volume. Press + to Skip to Next Track.
2	MFB (Power/talk/Play/Pause/pairing) button	Press to turn on your stereo headphones. If you receive a phone call, press to talk. Press to turn off your stereo headphones.
3	Indicator led	Shows current status of the headphones.
4	- Volume Down Previous Track	Press - to decrease the volume. Press - to Previous Track.
5	Cable clamp	The Cable clamp on the collar.
6	Micro USB port	Plug the micro USB connector into this port to charge your headphones.
7	Microphone	Allows you to talk on the telephone.

## Method of use

1. Place Headphone on the neck, insure the same of length of both sides.
2. Place clip on collar which could be keep the Headphone wouldn't be drop.
3. Wear the earpods, at that time the controller will nature hang front of right shoulder.

## BT basic indication

Bluetooth Function Indication			
Item	Operation	LED Indication	Tone
Power on	Long press ② MFB more than 2s	Blue LED on 1.5s	"power on"
Power off	Long press ② MFB more than 3s	Red LED on 1.5s	"power off"
Pairing mode	Long press ② MFB more than 4s on power off stage	Blue and red LED blinking alternant	2 short beeps tone
Play/Pause	Short press ② MFB button	/	/
Volume Up /Down	Short press ① + / ④ - button	/	2 high beeps tone for max volume 2 low beeps tone for min volume
Next Track/ Previous Track	Long press ① +/ ④ - button	/	/
Incoming call	/	Blue LED blinking 3 times until pick up	Some ring tone
Answer call	Short press ② MFB when have a calling	/	1 short beeps tone
Reject call	Long press ② MFB when have a calling	/	1 long beeps tone
Redial	Double press ② MFB	/	2 short beeps tone
Reset device list	Long press ② MFB button more than 10s in power off stage	All LED off then power off	/
Charging Indication			
Charging	Connected USB cable	Red LED on	/
Full charging	/	Red LED off	/
Low battery	/	Blue LED blinking fast 3 times at every 1min	"battery low" at every 1 min

## Setting up your stereo headphones

### Charging your stereo headphones

- Connect the charging cable to your stereo headphones ⑥ **Micro USB port**, then plug the USB connector into your desktop computer, notebook or Smartphone AC adapter. The red LED stays on while your stereo headphones are charging and turns off when they are fully charged.

## Using your stereo headphones

### Turning your stereo headphones on and off

- Press and hold the ② **MFB** button for two/three seconds. The LED blinks blue (when turned on) or red (when turned off), and the voice prompt says "Power on", or "Power off."

## Pairing your stereo headphones

### Notes:

- Range is 33 feet (10 meters).
- Supports easy pairing.
- Prompts you by saying "Device Connected," when connected.
- Supports a battery indicator icon on an iOS device.

## Pairing with a cell phone or MP3 player

- 1 With your stereo headphones turned off, press and hold **MFB** for four seconds. The blue and red led blinking alternant.
- 2 On your phone or MP3 player, select **INSIGNIA NS-CAHBTEP01** from the list of discovered devices, then enter the password **0000**(four zeros) (if required) to pair your headphones.

For more information on pairing Bluetooth devices to your cell phone or MP3 player, see the device's documentation.

**Note:** After the headphones have been successfully paired with the cell phone or MP3 player, the headphones will automatically reconnect to the phone or MP3 player.

## Pairing with a computer running Windows

**Note:** Before you pair the headphones with the computer, make sure that the computer is equipped with Bluetooth.

Refer to the computer's documentation or contact the computer manufacturer for more information. If your computer is not Bluetooth compatible, install a Bluetooth USB adapter (dongle).

- 1 Turn on Bluetooth on the computer. For instructions, see the computer's documentation or contact the computer manufacturer.
- 2 Double-click the **Bluetooth** icon in the system tray, then click **Add a device (Add Wireless Device)** using Windows Vista).
- 3 With the headphones turned off, press and hold **MFB** for four seconds. The LED blinks blue and red led alternant, then pairing mode is activated.
- 4 Double-click the **INSIGNIA NS-CAHBTEP01** icon on the computer or highlight the icon, then click **Next**.  
**Note:** If you are unable to locate the **INSIGNIA NS-CAHBTEP01** icon, click the **Search Again** button.
- 5 If required, enter **0000** (four zeros) in the **Bluetooth security code** field, then click **Next**.
- 6 After the headphones have been paired, click **Close**. If you are using Windows XP, continue with steps 7 through 9.

- 7 Select one of the Bluetooth hands-free types shown on the **Add a Bluetooth Device Wizard** screen, then click **Next**.

- 8 Select the services shown on the wizard screen to use with your Bluetooth headphones, then click **Finish**.

- 9 To connect the device, double-click the **INSIGNIA NS-CAHBTEP01 Hands-Free Unit** icon or the **INSIGNIA NS-CAHBTEP01 Stereo Audio** icon.

**Note:** The headphones should be automatically selected as the default playback device (Windows® 8, Windows® 7, or Windows Vista®) or the default recording and playback device (Windows XP). To make those settings manually, refer to the *User Guide*.

## Pairing with a Mac computer

**Note:** Before you pair the headphones with the computer, make sure that the computer is Bluetooth compatible. Refer to the computer's documentation or contact the computer manufacturer for more information. If your computer is not Bluetooth compatible, install a Bluetooth USB adapter (dongle).

- 1 Turn on Bluetooth on the computer. For instructions, see the computer's documentation or contact the computer manufacturer.
- 2 Click the **Bluetooth status** menu.

- 3 Click **Set up Bluetooth Device**. The **Bluetooth Setup Assistant** opens.

- 4 Click **Continue**.

- 5 Select **Headset** as the device type, then click **Continue**.

- 6 With the headphones turned off, press and hold **MFB** for four seconds. The LED blinks blue and red led alternant, then pairing mode is activated.

- 7 Select **INSIGNIA NS-CAHBTEP01**, then click **Continue**. The computer gathers information.

- 8 Click **Continue**.

- 9 Enter **0000** (four zeros) into the **Passkey** field, then click **Continue**.

- 10 Click **Quit** to finish.

**Note:** To use the headphones, they must be selected as the default input and output device on the computer.

- 11 Click **System Preferences**, then click **Sound**.

- 12 Under **Input**, select **INSIGNIA NS-CAHBTEP01**, then under **Output**, select **INSIGNIA NS-CAHBTEP01**.

For information on using your headphones with Skype, refer to your *User Guide*.

## Resetting your stereo headphones

To reset your headphones, With your stereo headphones turned off, press and hold **MFB** for 10 seconds.

## Specifications

**Bluetooth version:**

Bluetooth 4.1+EDR

**Supported profiles:**

A2DP, AVRCP, HFP, HSP

**Frequency spectrum:**

2.4 ~ 2.4835 GHz ISM Band

**Working distance:**

Up to 33 ft. (10 m)

**Operating temperature:**

23 ~ 122° F (-5 ~ 50° C)

**Operating time:**

Talk: 6 hours;

music: 6 hours, playback music track

**Standby time:**

200Hours

**Size:**

**Ear shell :**

0.67 x 0.68 x 1.26 inches

(1.7 x 1.72 x 3.2 cm)

**Mic controller :**

2.2 x 0.41 x 0.31 inches

(5.6 x 1.05 x 0.8 cm)

**Overall length :**

31.5 inches (80 cm)

**Weight:**0.423 oz(12g)

**Average charging time:**  
2Hours

**FCC ID:**MV3-CAHBTEP01

**FCC statement:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation." (Or in manual if product too small)

**FCC Caution:**

Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

## FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

## One-year limited warranty

### Contact Modal:

For customer support, call 1-800-499-3402 (U.S. and Canada)

[www.bestbuy.com/modal](http://www.bestbuy.com/modal)

MODAL is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC  
©2015 Best Buy. All rights reserved.

**Made in China**