

## Instructions for using Power bank

### Charging:

1. Connect the charger to the IN/OUT port, charge the power bank, and the power indicator light shows the corresponding power.
2. Stop flashing after full charge, and the four white power indicator lights are constant.
3. When fast charging the power bank, the green fast charging indicator light is always on.

### Discharging (charging mobile phones or other electronic devices):

1. Click the switch to turn on the discharge output, and the power indicator light shows the current power. When the power is less than 5%, the first power indicator light flashes.
2. When there is no load, turn off the output in 32 seconds and turn off the power indicator light. When the output is loaded, when the output current is less than the 'discharge cut-off current', the output is automatically turned off.
3. When the wired fast discharge is on, the green fast charging indicator light is always on.
4. When the wireless charger is working, the green wireless charging indicator light is always on.
5. When the whole machine is in sleep mode, click to wake up the whole machine.
6. When in standby mode, insert a mobile phone or other device to be charged, the power bank automatically wakes up and charges the device.
7. When a wireless charging phone is placed in the coil position, the wireless charging function is automatically activated.
8. When wired charging and wireless charging are working at the same time, the wired charging will return to the 5V output mode, and the wireless charging will be reduced to 5W output.

### Charging and discharging status:

1. Connect the charger to IN/OUT to charge the power bank. At the same time, use the wireless charger to charge the phone, and the wireless charging will be reduced to 5W output.

### Power on/off

1. Short press the button to turn on and display the current power. Double-click the switch, the power indicator and output power will be turned off.

If there is no load connected to any interface in the standby state, the power indicator will automatically turn off after 32 seconds and enter the sleep state