iLuv

True Wireless Gaming Earbuds with 60ms Low Latency, Microphone & Charging Case

English

Low Latency 60ms

IPX6

SG100

User Manual

Bluetooth 5.0

WHAT'S INCLUDED



POWER ON AND PAIRING

1. Before Using

Please charge your earbuds before use. Simply take the earbuds out of the charging case and insert them into your ears. The earbuds will automatically power on and become ready to pair to your device.

The earbuds are rated IPX6 Waterproof which means that the earbuds can resist high pressure water sprays however they shouldn't be submerged under water for a long period of time.

2. Wear Earbuds

Both earbuds are marked with a L or R to indicate the appropriate ear side; earbuds are differently angled to fit either the left or the right ear.

The proper fit will ensure the best sound quality. Insert the earbud into your ear and rotate slightly clockwise (as shown in image below); adjust for comfort.



3. Power On and Pairing

Earbuds will automatically turn on whenever the charging case is open.

A. A "***Power on***" prompt will be heard through the earbud within the first few seconds of wearing.

B. A "***Please pair to your device***" prompt will be heard through the earbud if the previously paired device is not found.

C. Turn on Bluetooth on your device

a. Go to Settings > Bluetooth.

b. Turn on Bluetooth.

c. Scan for and select "**iLuv SG100**".

d. Wait for successful pairing

LISTENING TO MUSIC

Once paired, open a music app on your device to Play/Pause music, adjust Volume Up/Down and Track Next/Previous.

You can Play/Pause your music by simply touching the touch area of either earbud once;

You can adjust the Volume Up/Down by touching and holding the touch area of the earbuds. The Right earbud will adjust the Volume Up and the Left earbud will adjust the Volume Down; a sound prompt "Du..du..du.." will be heard from both earbuds.



You can skip tracks by double touching the touch area of the earbuds. The Right earbud will skip to the next track and the Left earbud will skip to the previous track.

HANDS-FREE CALLING

Please follow the instructions below to answer/hang up/ reject calls.

1. Answer Call
Double tap the touch area of either the Right or Left earbud

2. Hang Up Call
Double tap the touch area of either the Right or Left earbud

3. Reject Call
Touch and hold the touch area of either the Right or Left earbud for 2 seconds

Game/Music Mode

Earbuds support game/music mode, the default mode is music mode, you can triple tap the touch area of either the Right or Left earbud to switch the mode to game mode.



CHARGING

1. To charge your earbuds
Place both earbuds into the charging case whenever not using; Make sure to keep the lid closed.

2. To charge your case
Plug the USB-C side of the charging cable into the charging port located on the backside of the charging case. Then plug the USB-A side of the charging cable into a standard USB-A charger or port.



3. Checking the Battery Level



A.Earbuds
- The side LED lights will pulse when the lid is closed and will continue to pulse until the earbuds are fully charged.
- The side LED lights will turn off once the earbuds are fully charged.

B.Charging case
- The bottom LED will indicate the battery level of the case whenever connected to a charger.
- All four bottom LEDs will be lit when charging is complete.
- The bottom LED will display the battery level of the case for 10 seconds when the lid is opened.

BATTERY LIFE

The SG100 earbuds will provide a playtime of 18 hours. Get up to 5 hours on a single charge and an additional 13 hours from the included charging case. For a quick charge, place both earbuds back into the charging case for 20 minutes and get 1.5 hours of listening time.

	Earbud	Charging Case
Listening Time	5 hrs (Music mode)** / 4.5 hrs (Game mode)**	13 hrs (Music mode) / 11.5 hrs (Music mode)
Charging Time	2 hrs	2 hrs
Play time after charged for 20 minutes	1.5 hrs (Music mode) / 1.25 hrs (Game mode)	

** Listening time measured on a single charge at an 80% volume level.

POWER ON/OFF

1. Power On the Earbuds

The earbuds will automatically power on and connect to the previously paired device whenever the charging case is open.

To power on the earbuds without the charging case, hold the touch area of both earbuds for 2 seconds until a "Power on" prompt is heard.

2. Power Off the Earbuds

To power off the earbuds, place both earbuds into the charging case and close the lid.

Please hold the touch area of both earbuds for 5 seconds to power off the earbuds without the charging case; a " Power off "prompt will be heard. Please make sure that all music/audio is paused before powering off.

3. Auto Power Off

To conserve battery, the earbuds will automatically power off when it's out of range from your device for more than 5 minutes.

TROUBLESHOOTING

Place both earbuds into the charging case and leave the lid closed; take earbuds out of charging case after 15 seconds.
This simple trick will resolve most problems which include but isn't limited to L/R channel disconnection or pairing/connectivity issues with devices.



FAQ (FREQUENTLY ASKED QUESTIONS)

1. How can I power on/off the earbuds?
The earbuds will automatic ally power on when the charging case is open and power off when placed back into the charging case with the lid closed.
Whenever the charging case isn't near the earbuds, hold the touch area of both earbuds for 2s to Power on and hold the touch area of both earbuds for 5s to Power off.

2. How can I play/pause music or receive calls?
Simply touch the touch area of either earbud to Play / Pause music. Double touch either earbud to receive phone calls.

3. How can I control the volume of the music or call?
Touch and hold the touch area of of the Right/Left earbud to turn Up/Down the volume.

4. What will affect the total playtime?
Playtime will vary by the volume level, type of audio and connection status.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, iLuv Creative Technology declares that the radio equipment type iLuv earbuds is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the follow internet address: www.iluv.com

TROUBLE SHOOTING: When the battery is completely drained while
charging, the charging process may take up to 30 minutes for the earbuds to resume its normal charging process. Notice that it is a long process if the battery is drain out completely and it requires a full 30 after a few minutes.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ONE YEAR LIMITED WARRANTY
GARANTIA LIMITED D'UN AN

EUROPEAN UNION
TWO YEARS LIMITED WARRANTY
GARANTIE LIMITEE DE DEUX ANS

Printed in China.