

[illegible]

### Important Safety Precautions

You are recommended to use the projector in a dark room to achieve the best effect.

1. Please don't breathe in places that directly blow air by cold and warm air or air conditioning, otherwise you will be temporarily irritated. Please be aware of the following:
2. Ensure adequate ventilation and vent are not blocked to prevent heat accumulation inside the machine.
3. Please prevent foreign materials such as nails or paper scraps from falling into the machine. Do not insert any metals such as iron wires or screwdriver into the machine. Please turn off the power immediately and turn back to professional technicians to remove it if any foreign materials fall into the body.
4. Do not place any liquid or flammable materials to avoid fire or electric leakage.
5. Please use only packaging materials to move the projector. Keep the projector from being damaged.
6. Avoid use the projector with flammable hot drying and other use the projector. It may lead to scald if we touch the body.
7. Please don't watch how directly when it's on as it protect our eyes from damage.

**Note:**

Don't open the shell to prevent electric shock. Please turn qualified professional maintenance personnel for the maintenance as there are no parts in the machine that users can repair themselves.

Don't expose the machine to moisture as it may prevent mechanical or electric shock. The projector is applicable to be used under a temperature of 0-35°C for a safe site.

### Important Safety Precautions

Don't install in places with poor ventilation

Don't install in places that hot and humid

Don't block the vent (Inlet or Outlet)

Don't install in dusty and windy areas

### Projector Part Name and Function

### Installation and Adjustment

#### 1. Device Power-On and Power-Off

**Power-On**  
Method 1: Press the power button on the projector to start.  
Method 2: Press the power remote control to the projector and press the "Power" button.

**Power-Off**  
Short press the power button on the "Power" key on the remote control, once disconnection point light appears, please press the power button or the power key on the remote control again.

#### 2. Adjusts Focal Length

Focus Length: When the picture image is blurred (shown as the right picture), adjust the lens focus through "F" "+" "-" on the remote control to achieve the best definition.

### Projector hanger installation steps

1. Remove the 4 pads.
2. Adjust the hanger ring to align with the hole and then tighten the screws.
3. Fix the hanger.

### Remote Control

图纸号	X3(1+1)-SMS01-004	类型	X3(1+1) 英文说明书
颜色	黑白印刷	尺寸	折前尺寸: 720*120mm; 折后尺寸: 90*120mm
材质工艺	128g铜版纸 白色; 8页风琴折双面		
备注	更新认证警告		

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

#### Radiation Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.