

TWS XY-80

功能操作说明

产品示意图



产品参数

- 型号: XY-80
- 蓝牙版本: V5.1+EDR
- 耳机电池容量: 30mAh
- 充电仓电池容量: 230mAh
- 电源输入: 5V
- 产品重量: 约28g
- 工作时间: 3小时
- 工作电压: 3.3V-4.2V
- 充电时长: 70分钟
- 喇叭阻抗: F10/32欧
- 频率响应: 20-20KHZ
- 传输距离: 10米以上

产品包装明细

- 蓝牙耳机本体(2PCS)
- 耳机充电仓
- Type-c充电线
- 使用说明书
- 精美包装盒



使用方法

1.开机

- 自动开机(第一次使用)
- 步骤一:打开充电仓上盖。 ,
- 步骤二:拿出耳机, 此时耳机自动开机匹配,两个耳机蓝灯慢闪,等待连接手机
- 手动开机
- 耳机不在充电仓里并且耳机是关机的状态, 长按左右耳机3秒开机

2. 关机

- 耳机自动关机
- 步骤一: 使用后,将耳机从耳朵上拿下来。
- 步骤二:将左右耳机放入充电仓,关上充电仓上盖, 会自动关机并充电。
- 手动关机
- 步骤一:如果耳机处于开机并且相互连接状态,单击任意一只耳机5秒关机。
- 步骤二:将左右耳机放入充电仓, 关上充电仓上盖关机并充电。

3.蓝牙配对

- 步骤一:将耳机从充电仓拿出来。
- 步骤二:将手机蓝牙打开。
- 步骤三:找到耳机蓝牙名"【XY-80】"。
- 步骤四:点击连接, 连接成功后语音提醒。

注意: 如果已有配对设备信息, 耳机会在2-4S内自动回连设备; 若未连接到设备, 耳机待机3分钟后自动关机。

4. 耳机常见操

- 接听/挂断:
- 单击任意一只耳机一次接听/挂断电话。
- 长按任意一只耳机1.5S为拒绝接听电话。
- 暂停/播放:
- 音乐播放过程中单击任意一只耳机即可暂停/播放音乐。
- 上一曲/下一曲:
- 音乐播放过程中双击左边耳机即可完成上一曲操作。
- 音乐播放过程中双击右边耳机即可完成下一曲操作。
- 音量加减:
- 点击三下左边耳机可提高音量。
- 点击三下右边耳机可减弱音量。
- 唤醒语音助手:
- 长按3秒唤醒SIRI。

指示灯工作状态

耳机工作状态	耳机指示灯状态
充电	亮红灯
充满	灭灯
连上手机	灭灯
充电仓工作状态	充电仓指示灯状态
USB-5V充电	红灯闪烁充满后常亮
充电仓给耳机充电	绿灯常亮
充电仓低电状态	绿灯闪烁

使用注意事项

- 1、耳机需存放在干燥通风的环境下, 避免与油、水汽、蒸馏水接触, 以免影响产品性能。
- 2、避免使用刺激的, 有机溶剂或含有这些成份的物品清洁。
- 3、耳机需按要求正确规范的使用, 注意使用环境对耳机的影响, 为保证连接顺畅, 建议手机和耳机之间的距离在10米范围内。
- 4、如耳机有连接不上或通讯不畅等其他问题, 请勿私自拆卸耳机本体及其配件, 否则不予保修。
- 5、给耳机充电, 请选用标配的车载充电器或本公司指定的符合要求的充电器。
- 6、为保证您正常使用耳机, 请确保耳机的电量充足。

TWS XY-80

Function Instructions

Diagrammatic Sketch



Specifications

- Model: XY-80
- Bluetooth version: V5.1 + EDR
- Earbud battery: 30mAh
- Charging case battery: 230mAh
- Power input: 5V
- Product weight: about 28g
- Working time: 3 hours
- Working voltage: 3.3V-4.2V
- Charging time: 70 minutes
- Speaker impedance: F10/32Ω
- Frequency response: 20-20KHZ
- Transmission distance: over 10 meters

Package List

- Bluetooth headset
- Earphone Charging box
- Type-c charging cable
- User's manual
- Gift package



How To Use

1 . Power On

- Automatic Power On For First Time User
- Step 1: Open the Charging case cover
- Step 2: The earbuds are automatically turned on and paired when taking out; Then earbuds Indicator light flashes slowly with blue color to connect the phone
- Manual Power On When Earbuds Are Out From Charging Case
- If the earbuds are not in the charging case, long press the earbuds individually for 5 seconds to power on.

2 . Turn Off

- Automatic Turn Off The Earbuds
- Step 1: After use, remove both left and right earbuds from your ear.
- Step 2: Put them back into the charging case, they will automatically turn off and charge them selves.
- Manually Turn Off The Earbuds
- Step 1: If both earbuds are on & connected with each other, long press either left or right earbuds for 5 seconds to manually power off.
- Step 2: Place them back into the charging case to charge the earbuds.

3 . Connection Mode - Ear buds connect with smartphone

- Step 1: Take the earbuds out of the charging case.
- Step 2: Make sure your smart phone's bluetooth function is turned on.
- Step 3: find out earbuds device name" 【XY-80】 " on your smart phone.
- Step 4: Click it to connect.

4 . Normal Functions Operation

- Incoming call / Reject Call:
- Touch the earbud once to answer/hang up the call.
- Long touch the earbud to reject the call.
- Play/ Pause
- When playing music, touch the earbud once to play or pause the music.
- Volume +/-
- Touch the left earbud 3 times to increase the volume.
- 2. Touch the right earbud 3 times to decrease the volume.
- Previous/Next song
- Touch the left earbud twice to skip to previous song.
- Touch the right earbud twice to jump to next song.
- Voice Assistant
- Long touch on either left or right earbud for 3 seconds to wake up

Indicator working status

Headphone work status	Headphone indicator status
charging	Bright red light
A full charge	Lights out
Connect the phone	Lights out
Working status of charging bin	Indicator status of charging bin
USB-5V charging	Blinking red It is steady on after it is filled
The charging bin charges the headphones	Green light normally on
Low power status of charging bin	Green light flashing

Precautions for use

1. The earphones should be stored in a dry and ventilated environment, to avoid oil, water, moisture and dust affecting product performance.
2. Avoid using stimulus, organic solvents or items containing these ingredients to clean the earphones.
3. The use of earphones should be correctly as per the specification, pay attention to use the influence of environment on the earphones.
- In order to ensure the smooth connection, it's recommended that the distance between the earphones and phones with in 10 meters.
4. If the earphones failed to connect or with poor connection, pls do not take apart the earphones or the accessories on your own. Otherwise, no warranty.
5. Regarding charging earphones. Pls use the standard usb cable or pointed charging cable from our company to charge the earphones.
6. In order to ensure normal use, please ensure sufficient power of the earphones.

<div>FCC Warning</div> <div>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement.</div>	<div>FCC警告</div> <div>该设备符合面心立方规则的第15部分。操作应符合以下两种条件： 此设备可能不会造成有害的干扰，并且（2）该设备必须接受接收到的任何干扰，包括可能导致不良操作的干扰。 注1:根据FCC规则第15部分，本设备已经过测试，并符合B类数字设备的限制。 这些限制旨在为住宅设施提供合理的保护，防止有害干扰。 该设备产生、使用并能辐射射频能量，如果不按照说明书安装和使用，可能会对无线电通信造成有害干扰。 但是，不能保证在特定的安装中不会发生干扰。 如果该设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定，鼓励用户尝试通过以下一种或多种措施来纠正干扰： -重新定位或安置接收天线。 -加大设备与接收器之间的距离。 -将设备连接到与接收器连接的电路不同的电路插座上。 -向经销商或有经验的广播/电视技术人员寻求帮助。 该设备已经过评估，以满足一般的射频暴露要求。</div>				
--	---	--	--	--	--