


8. EUT Testing Position and Antenna Location

Test Position 1-Back



Test Position 2-Front



Test Position 3-Left



Test Position 4-Right

