



50867_IS
Designer: LM
Docket: 06-088-24
Factory: DIYA

PRINTING SPECIFICATIONS FOR SKU:
印刷品颜色要求



CARD DIMENSION
卡片尺寸



w (width): 297 mm
h (height): 210 mm

FRONT

正面

BACK

反面



“B” IS FOR BEACON



Unlike Wi-Fi products, your Beacon smart products connect to your phone using Bluetooth. Here are a couple of tips to help you get the most out of them:

Proximity: Beacon allows for full local control from up to 20 meters (65 feet) away.

Automation: Beacon is great at home automation! Schedules and Timers will continue to run even when your phone is not connected.

Group Control: Group your products and control them together. Beacon products can only be grouped with other Beacon products of the same type.

CONNECTING INSTRUCTIONS

1 Download the Globe Suite™ app from the iOS or Android store

Create an account and log in. Ensure your mobile device is running iOS 9.0/Android™ 4.4 or higher.

2 Set your Smart Plug in pairing mode

Insert your smart plug into the desired outlet. The blue indicator light should be blinking rapidly. If not, hold down the power button for 5 seconds.

3 Ensure all requested permissions are enabled on your mobile device: Bluetooth, Location Services.

On the app's home screen, select the icon in the top-right corner and select "Add a device". If your plug's indicator light is flashing rapidly, the app will detect it within a few seconds. When discovered, select the plug icon, and select "Next."

4 Set up and enjoy!

Name your plug and choose which room to place it in. You can now control it directly from the app.

Need help?

Select the "How do I set device into pairing mode?" link on the "Scan" page and follow the in-app instructions.

CAUTION: This plug has a 1 year manufacturer warranty from date of purchase. If the plug fails within that time, please contact our customer care team, or visit our website to submit a warranty request. This warranty is void if the product is misused in any way. This replacement is the only option available and liability for incidental or consequential damages are expressly excluded. Please see remaining CAUTION text for proper use.

For use only in 120V/60HZ circuits. Risk of electrical shock. Do not open, no user-serviceable parts inside. This device is not intended for use with emergency exit fixtures or emergency exit lights, photocells and electronic timers. This device can be used under the eaves. Do not use where directly exposed to water. Minimum operating temperature is -10° C (14°F).

USER MANUAL NOTICE FOR LICENSE-EXEMPT RADIO APPARATUS:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1. This device may not cause interference. 2. This device must accept any interference, including interference that may cause undesired operation of the device.

RADIATION EXPOSURE STATEMENT:

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20 cm between the radiator & your body.

SAFETY WARNING: Make sure to use this product together with 15A circuit breaker in the upstream.

CONTROLLING THROUGH THE APP



Please note that the device UI panel is subject to change without any prior notice.

BASIC CONTROL

Power

Turn your smart plug on or off directly.

Child lock status

View if the child lock is enabled or disabled.

HARDWARE SETTINGS

Restart status

Set the default state of the plug when reconnected to a power source. Choose from OFF, ON, or Last status.

Light mode

Turn the blue indicator light on the physical device on or OFF.

Child lock

Disable the physical power button.

ROUTINES *

Timer

Set a countdown for your plug to turn ON or OFF once the timer runs out.

Add a new schedule

Set a time and date for your plug to either turn ON or OFF to create additional routines that fit your specific needs.

APP FEATURES

Device sharing

Share access to your connected devices with another Globe Suite™ app user from the same home or account.

Device grouping

Group multiple same-type Beacon devices together to control them in unison, rather than individually.

Create a Smart Scene

Automate your plug to turn ON or OFF based on factors such as climate, time and other devices' status.



« B » POUR BEACON




Contrairement aux produits Wi-Fi, vos produits intelligents Beacon se connectent à votre téléphone par Bluetooth. Voici quelques conseils pour vous aider à en profiter au maximum :

Proximité : Beacon vous donne un contrôle local complet jusqu'à une distance de 20 mètres (65 pieds).

Automatisation : Beacon est génial pour la maison intelligente ! Les programmes et les minuteries continueront à fonctionner même si votre téléphone n'est pas connecté.

Contrôle de groupe : Regroupez vos produits et contrôlez-les ensemble. Les produits Beacon ne peuvent être groupés qu'avec d'autres produits Beacon du même type.

CONTRÔLE PAR L'APPLICATION



Veuillez noter que le panneau IU de l'appareil peut être modifié sans préavis.

INSTRUCTIONS DE CONNEXION

1 Téléchargez l'application Globe Suite™ dans le magasin d'applications iOS ou Android.

Créez un compte puis ouvrez une session. Assurez-vous que votre appareil mobile fonctionne sous iOS 9.0/Android™ 4.4 ou une version ultérieure.

2 Mettez votre prise intelligente en mode d'appairage

Branchez la prise intelligente sur la prise murale de votre choix.

Le voyant bleu sur la prise intelligente devrait clignoter rapidement.

Si ce n'est pas le cas, activez le mode couplage en enfonçant le bouton d'alimentation pendant 5 secondes - le voyant bleu devrait maintenant clignoter rapidement.

3 Sur votre appareil mobile, donnez toutes les autorisations requises : Bluetooth et localisation.

Sur l'écran d'accueil de l'application, appuyez sur le symbole dans le coin supérieur droit et sélectionnez « Ajouter un appareil ». Si le voyant clignote, l'application la détectera en quelques secondes. Une fois trouvée, cliquez sur l'icône de prise, puis appuyez sur « Suivant ».

4 Configurez et profitez-en !

Donnez un nom à votre prise intelligente et choisissez dans quelle pièce la placer. Vous pouvez maintenant la contrôler directement par l'application.

Besoin d'aide ?

Sélectionnez le lien « Comment mettre le dispositif en mode d'appairage ? » sur la page « Scan » et suivez les instructions de l'application.

Les programmes doivent être créés dans un rayon de 20 mètres de la prise. Lorsque votre téléphone n'est pas à portée, elles continueront à être exécutées mais ne pourront pas être modifiées.

MISE EN GARDE : Cette prise est couverte par une garantie du fabricant d'un an à compter de la date d'achat. Si la prise se brise pendant cette période, communiquez avec l'équipe du service à la clientèle ou visitez notre site Web pour soumettre une réclamation. Toute mauvaise utilisation du produit annulera la garantie. Le remplacement du produit défectueux est le seul recours qu'offre cette garantie. Toute responsabilité pour des dommages accessoires ou indirects est expressément exclue. Prière de consulter la MISE EN GARDE pour connaître l'utilisation adéquate.

Convient uniquement aux circuits de 120 V/60 Hz. Risque d'électrocution. Ne pas ouvrir. Ne renfermez pas de pièces dont l'entretien peut être assuré par l'utilisateur. Ne convient pas aux voyants et lampes de sortie d'urgence, aux récepteurs photoélectriques, ni aux minuteries électroniques. Ce dispositif peut être utilisé sous l'avant-toit. Ne pas utiliser dans un endroit où il y a risque d'exposition directe à l'eau. La température de fonctionnement minimale est de -10 °C (14°F).

NOTICE D'UTILISATION DE MATÉRIEL RADIO EXEMPT DE LICENCE : Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux flux RSS exemptés de licence du Canada pour l'Innovation, la Science et le développement économique (ISDE). Le fonctionnement est soumis aux deux conditions suivantes: (1) Ce dispositif ne peut pas causer d'interférence. (2) Ce dispositif doit accepter toute interférence, y compris les interférences pouvant causer un fonctionnement indésirable du dispositif.

DÉCLARATION D'EXPOSITION AUX RAYONNEMENTS : Cet équipement est conforme aux limites d'exposition aux rayonnements établies par ISSED pour un environnement non contrôlé. Cet équipement doit être installé et utilisé de façon à ce qu'il y ait une distance minimale de 20 cm entre la source de rayonnement et votre corps.

Ce produit est conforme à la partie 15 des règlements de la FCC. Son fonctionnement est sujet aux deux conditions suivantes: 1) ce produit ne doit pas causer de brouillage préjudiciable et 2) ce produit doit pouvoir recevoir toutes les interférences, notamment celles qui peuvent entraîner un fonctionnement non souhaité.

AVERTISSEMENT : L'utilisation de ce produit pourrait être proscrite à la suite de toute modification apportée sans le consentement exprès de la partie responsable de la conformité.

N.B. : Ce produit a été évalué et jugé conforme aux limites fixes pour les appareils numériques de classe B, selon la partie 15 des règlements de la FCC. Ces limites visent à assurer une protection raisonnable contre le brouillage préjudiciable en milieu résidentiel. Ce produit génère, utilise et peut émettre de l'énergie de radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, peut nuire aux communications radio. Cependant, rien ne garantit qu'aucun brouillage ne se produira dans une installation donnée. Si le produit nuit aux communications radio ou télévisées – ce qui se vérifie en allumant ou en éteignant le produit –, l'utilisateur peut essayer de régler le problème par l'un ou l'autre des moyens suivants:

- Réorienter ou déplacer l'antenne de réception.
- Éloigner l'appareil du récepteur.
- Brancher le produit sur une prise d'un circuit distinct de celui sur lequel le récepteur est branché.
- Consulter le détaillant ou un technicien expérimenté en radio et télédiffusion.

Cet équipement est conforme aux limites d'exposition aux rayonnements établies par la FCC pour un environnement non contrôlé. Cet équipement doit être installé et utilisé de façon à ce qu'il y ait une distance minimale de 20 cm entre la source de rayonnement et votre corps.

AVERTISSEMENT DE SÉCURITÉ : Veillez à utiliser ce produit avec un disjoncteur de 15A en amont.