

## RS80 (E7165S) External photo


### Front



### Back




Left side



Right side



Top




Bottom



USB cable



Adapter for USA



Adapter for EU

