


说明书, 折叠后尺寸: 270 * 115 mm, 300g双铜纸+过哑膜, 双色印刷

正面

背面

Tri-Mode Wireless Mechanical Keyboard User Guide



Tri mode connect/RGB light effect/Brown switch/Knob button/Smart screen display

FCC Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Packaging List:
1 x Keyboard
1 x Instruction card
1 x Warranty card
1 x Data cable
1 x Key remover
1 x Receiver

Driver download URL:
www.scorich.cn

Safety Precautions

To avoid hazards such as fire, personal injury, electric shock, or damage to equipment, please do not immerse the product in water or other liquids. Do not spray liquid on this product or drip liquid inside the product. If there is severe damage, do not use it.
Note: Do not use a fast charger to charge directly. Please make sure to plug it into the computer's USB port for charging.

Wired Connection/Rechargeable

1. Slide the mode switch to **W**.
2. Connect the keyboard and computer with a Type-C data cable to charge while using.
Note: Do not use a fast charger to charge directly. Please make sure to plug it into the computer's USB port for charging.

Side Connection Mode Switch

W : 2.4G wireless mode
W : Wired mode
W : Bluetooth mode

USB Connection(2.4G)

1. Slide the mode switch to **W**.
2. Remove the receiver on the right side.
3. Insert the receiver into the USB port of the computer to use it.

Bluetooth Connection

1. Slide the mode switch to **BT**.
2. Press **Fn+F12** for 5 seconds, entering Bluetooth paired status, indicator will flash quickly.
3. Turn on Bluetooth on your computer or other device, search or select "MK-010 Keyboard-1MK-010 Keyboard-2MK-010 Keyboard-3", and start Bluetooth pairing, until the connection is complete.

Note: The computer (Bluetooth) hardware configuration requires a Bluetooth 4.0 or higher version Bluetooth adapter

FN + Multi-function Key Description

Fn+F1 : Screen brightness	Fn+F9 : Previous track	Fn+F9 : Volume down
Fn+F2 : Screen brightness	Fn+F6 : Play/Pause	Fn+F10 : Volume up
Fn+F3 : Open Task View	Fn+F7 : Next track	Fn+F11 : Search
Fn+F4 : Task Switcher	Fn+F8 : Mute	Fn+F12 : Lock screen

Instruction to adjust backlight

Fn+Del : ON/OFF light effect
Fn+PgUp : Previous light effect
Fn+PgDn : Next light effect
Fn+1 : Light effect brightness
Fn+2 : Light effect speed
Fn+3 : Light effect speed

Instruction to Compact OS

Press and hold the **Fn+M** keys for 5 seconds to switch between Windows(Android/default) and macOS/iOS systems.

Instruction of indicator

Charging indicator light: light will be on during charging and goes off after fully charged.
Low battery indicator light: flashing when the battery is low, and the backlit effect will be turned off.

2.4G indicator
BT indicator
Wired indicator

Smart Screen Display

Smart screen display, which can instantly display time, date, battery level, system and other information. You can also customize manager and OS. When return to the software driver, download software driver website: www.scorich.cn

Windows system/Apple system
Bluetooth/2.4G/Wired mode
Capital letters on/off status
Caps Lock Indicator

Fn+F5: Return to the screen main page
Fn+F6: Short press to switch to the uploaded picture. Long press to delete the current image on screen.
Fn+F7: Play gif animation
Fn+F8: Display the corresponding light effect on the screen
Fn+F9: Previous track
Fn+F10: Volume down
Fn+F11: Search
Fn+F12: Lock screen

Instructions for Hot-Swap Operation steps
1. Remove the keyboard key pin.
2. Use the tool to clean the back of the key pin.
3. Calculate the pin number of the new switch.
4. Tap the new switch in to the slot vertically.
5. Install the keypad.