

CamShow™ Remote

For use with VK73A VGA Picture Sender

The CamShow Remote works with the VK73A CamShow system for situations where you want to have an additional remote, or if you are replacing a lost or broken remote. The remote lets you access all the features of the CamShow application from the comfort of your easy chair. It can also adjust the color, brightness, contrast, etc., of the picture sent from the Picture Sender to the Receiver that you connect to your TV. See VK73A owner's manual for more information.



1. Push the tab and lift off the battery cover.



2. Insert four AAA alkaline batteries, taking care to match the + and - marks in the battery compartment.

1. Press A to List photo albums.
2. Press B to View thumbnail views of the pictures in the album you selected when you pressed A.
3. Press C to Search through collections of photos you have grouped together.
4. Press D to access Help.

5. Press A to select an album, then press B to view thumbnail views of the pictures in the album, then press a number button corresponding to the thumbnail number of the photo you want to view.

6. Moves forward and backwards through the selected album.

8. Zooms in and out on the picture being displayed.

7. Moves through your albums.

BUTTON DESCRIPTIONS

Indicator light

The indicator light flashes when you press any button.

Start

Launches the CamShow application.

A, B, C, D

Selects the four main functions of the CamShow application.

Up, Down, Left, Right Arrows

Moves picture on screen.

OK

Selects a selection.

Zoom In/Zoom Out

Zooms in and out on the picture being displayed.

0-9

Enters picture numbers directly.

Forward/Backward

Selects direction to move through your picture album.

Page Up/Page Down

Goes to the next or previous page in your photo album.

Subtitles

Turns subtitles on and off.



F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

LIMITED 1-YEAR WARRANTY

Please visit www.x10.com/warranty to complete your on-line warranty registration. Thank you. For help or more information on setup, please visit: www.x10.com/support