

WIRELESS KARAOKE MICROPHONE SPEAKER



USER MANUAL

- Safety Instructions
- Read this manual carefully before use and keep this manual for future reference.
- Keep the device away from heat, direct sunlight and sharp edges.
 - Keep the device away from moisture and water.
 - Keep the device away from open flames.
 - Do not insert any metal object into the device. Risk of short circuit!
 - To avoid a static charge, do not use the device in an extremely dry climate.
 - Do not repair the unit yourself but contact an authorized specialist.

1. Button Functions



2. Package contents
- Karaoke microphone speaker
 - Micro USB cable
 - Audio cable
 - Instruction manual



USB cable



Audio cable

3. How to use
1. Turn the device on, a blue indicator light will illuminate.
 2. Bluetooth connection: turn on the Bluetooth on the mobile phone and scan. The Bluetooth searching name is "A08".
 3. Upon successfully connecting, you will hear a short tone. (The password is "0000" if needed.)
 4. Playing music: Go into the music player APP on your mobile phone. Download and play the music or accompaniment. Sing along through the microphone & perform like a rock star. Adjust the volume via the mobile phone.
 5. Use echo function to add extra rock star sound.
 6. To listen via Karaoke microphone speaker without using the Bluetooth function, simply use the audio cable to connect your phone to the device.

Remark:

After successfully connecting with a mobile phone, the Bluetooth will automatically connect with the mobile phone next time. If you need to disconnect, you can disconnect through the mobile phone.

4. How to charge the speaker
1. When the speaker's battery is low, the speaker will power off automatically.
 2. Charge the speaker using the provided USB cable. When the speaker is charging, the red indicator light will be on.
 3. The speaker will be fully charged after about 2 hours.

5. How to charge with a power bank
1. Always turn the speaker off before charging with a power bank.
 2. Connect the speaker to a power bank using the provided charging cable.

6. Specification
- Headphone output: 10mW
 - Speaker output: 3W
 - Frequency range: 100Hz~10KHz
 - Maximum sound pressure level: >115dB 1KHz THD<1%
 - Power supply: rechargeable battery
 - Battery capacity: 1200mAh
 - Input: DC5V

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

044-15-1167*17
STYLE#SM-50599
MADE IN CHINA