


Label Format and Location



<Bottom view of EUT>

- * 15.19 requirement will be written on the manual due to its size.
- * The label will be placed inside the battery compartment.