

Smart

XMCOZY+

Low Voltage Mushroom Lights

User Manual

Download Free APP:

App Store

Google Play

XMCOZY+

XMCOZY

Can't connect? Need help?

Email:service.2@xmcosy.com

INTRODUCTION

Thanks for choosing XMCOZY+ Low Voltage Mushroom Lights. Please read the user manual carefully and keep it for future reference.

SAFETY INSTRUCTIONS

Read and follow all safety instructions before installing the low voltage mushroom lights.

●Sockets used to power mushroom lights should comply with all national and local electrical codes. If you are unsure of compliance requirements, please consult your local electrician.

●Do not use in water. Please connect power cords in deep together and tighten the protective cover. Especially for the interface at the end, please be sure to put on the protective cover. Keep the plug and socket dry.

●Please keep children away from these lights.

●Keep lights away from flammables and fire sources.

●Avoid placing the lights near potentially dangerous sources.

DO NOT EXCEED RATED CAPACITY.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

CONTENT

Specifications _____ 1

Package Contents _____ 2

Assemble _____ 3

Button Function Introduction _____ 5

Service & Warranty _____ 6

APP Download & Registration _____ 7

Distribution Network & APP Connection _____ 10

APP Functions _____ 14

Alexa Pairing Instruction _____ 18

Google Assistant Pairing Instruction _____ 23

Troubleshooting _____ 26

Contact _____ 27

SPECIFICATIONS

| | |
|---------------------|---------------------------------|
| Brand | XMCOZY+ |
| Model | YJ-312-4-MG |
| Dimension | 6" D x 22" H/EA |
| Total Length | 48FT(14.6M) |
| Weight | 3.66 KGS |
| Material | Aluminum + Stainless steel + PC |
| Light Source | Integrated LED |
| Luminous Flux | 200 Lumens/EA |
| Color Temperature | 2700K Warm White + RGB |
| Input Voltage | 120V AC, 50/60Hz |
| Output Voltage | 12V DC Max. 3A |
| Wattage | 6W/EA |
| Max. Of Connections | 36 Wattage |
| Controlled By | Button/APP Control |
| Dimmable | YES |

PACKAGE CONTENTS

1. Mushroom Light * 4

2. Aluminum Light Cap * 4

3. Aluminum Ground Stake * 4

4. 8.2FT Light Cable* 4

5. 13.1FT Extension Power Cable * 1

6. 36W Power Adapter * 1

7. User Manual * 1

Notes:

After unpacking, please check the product accessories. If there are any missing or damaged accessories, please contact us as soon as possible, and our customer service team will solve it in time.

service.2@xmcosy.com

ASSEMBLE

Step - 1

1. Rotate the light cap clockwise and tighten it.

2. Connect the light pole and ground stake.

Step - 2

Connect the light cables in turn.

1. Align the positioning point.

2. Tighten connectors.

3. Tighten the waterproof cover.

Notes:

1. If the connectors are not aligned, the color of the mushroom lights will be different or be inconsistent with the color setting in the APP.

2. Without the waterproof cover, the light cable may submerge in water, which will cause a short circuit.

ASSEMBLE

Step - 3

Connect the installed mushroom lights and the light cables in turn.

Step - 4

1. Connect the extension power cable to the light cable & power adapter.

2. Plug the power adapter into the power outlet.

BUTTON FUNCTION INTRODUCTION

Button Function Introduction:

1. Long press - Enter the APP connection & network mode.

Long press the button for 5S, the light flashes quickly, and the product enters the distribution network mode. (When the product is used for the first time, it will automatically enter the network distribution state after connecting to the power supply, without pressing any buttons.)

2. Short press - ON/OFF & Change scene modes

8 modes(4 kinds of warm white and 4 kinds of color light) Short pressing the button, the mode changes in turn as follows:
* ON(Gorgeous)
* Good to night
* Reading
* Working
* Leisure
* Grassland
* Colorful
* Dazzling
* Gorgeous
* OFF

For more scene modes and functions of the product, please connect to the XMCOZY APP.

SERVICE & WARRANTY

Thank you for your support of XMCOZY+! XMCOZY+ provides a regular 1-Year Warranty.

Not Satisfied?

If there is any problem with our product while using, Please Contact
service.2@xmcosy.com

We will provide you with a 100% Satisfied Solution!

Satisfied?

We are glad that you didn't encounter any problems with our low voltage mushroom lights. XMCOZY+ is committed to providing better products and service, so we provide an additional 1-year warranty.

Please Email to register a 2-YEAR-WARRANTY
warranty@xmcosy.com
or scan the QR code

APP DOWNLOAD & REGISTRATION

Step 1: Download the XMCOZY App from App Store or Google Play.

Scan the QR code to download

APP DOWNLOAD & REGISTRATION

Step 2: Register

1. Enter your mobile phone number or email address.

2. Enter the verification code.

APP DOWNLOAD & REGISTRATION

3. Create a password and Log in the App.

4. Please enable the XMCOZY App to get your Bluetooth while using the App.

DISTRIBUTION NETWORK & APP CONNECTION

Step 1: Plug - In

Plug XMCOZY+ smart mushroom path lights power adapter into any standard outlet.

Notes:

1. After power on, the light will automatically enter the connecting state (fast blinking);

2. If there is no connection after 3 minutes, the indicator lights will remain on. If you want to add a device at this time, you need to press and hold the power button on the controller for about 5 to 7 seconds until the lights blink rapidly.

DISTRIBUTION NETWORK & APP CONNECTION

Step 2: Register

1. Click the "+" in the home page upper right corner. The devices in the connecting state will be displayed at the top of the page. Click "Add".

2. Click the device you want to add and please make sure that the network you connected is 2.4GHz.

DISTRIBUTION NETWORK & APP CONNECTION

3. Fill in your 2.4GHz network name and password, then click "Next".

4. The product starts to connect until it is 100% completed.

Please keep the router, mobile phone, and product as close as possible to ensure a good reception signal.

DISTRIBUTION NETWORK & APP CONNECTION

5. After you edit the product name and save it, click "Done" at the top right.

Congratulation!

Now you can use XMCOZY App to control your mushroom lights.

APP FUNCTIONS

WARM WHITE MODE& COLOR MODE

You can choose to turn on the mushroom lights in color light or warm white light.

RGB Color Mode

* Color Wheel - Slide the color wheel up and down to adjust the color of the lights from a broad spectrum of colors. Drag the button on the wheel from right to left to adjust the color temperature.

* Brightness - Slide the brightness bar to adjust the brightness from 1% to 100%.

* Default Color - There are 7 default colors, you can click the round color icons to choose a default color.

Warm White Mode

* Brightness - Slide the "brightness" bar to adjust the brightness of low voltage mushroom lights from 1% to 100%, you can freely brighten or dim the lights.

APP FUNCTIONS

* Scene Mode:

XMCOZY App has a scene selection function. Press the scene button to enter the scene selection interface. You can choose your favorite scenes from 32 default scenes. You also can customize a new scene based on your favorite.

APP FUNCTIONS

* Music Sync Mode: The low voltage mushroom lights react in real-time when your app detects the songs.

2. Sign in or register a new account

* Plan: You can set the time and customize favorite light mode when you fall asleep/wake up.

OTHER FUNCTIONS

* Schedule: Turn on/off automatically at preset times.

* Left Time: The lights will turn off automatically after the countdown.

* Power-on Behavior: Power Memory mode.

ALEXA PAIRING INSTRUCTION

1. Download the Amazon Alexa APP

Search the keywords "Amazon Alexa" in the App Store for iOS device and in the Google Play for Android device.

2. Sign in or register a new account

3. Pair the Amazon Alexa APP to Amazon Echo Device (follow the Amazon Echo User Manual)

4. Log in your Amazon Alexa APP

Important tips: please make sure the "XMCOZY" app, Amazon Alexa APP "Amazon Echo" are connected to the same Wi-Fi network.

ALEXA PAIRING INSTRUCTION

5. Enable "XMCOZY" skill in Alexa APP

a. Click "Skills & Games" in the MORE MENU on the Alexa APP's home page.

ALEXA PAIRING INSTRUCTION

b. In the popup page, input "xmcozy" in the search bar.

c. Click "Agree and link", then "Your XMCOZY account has been successfully linked".

ALEXA PAIRING INSTRUCTION

c. Click "Agree and link", then "Your XMCOZY account has been successfully linked".

ALEXA PAIRING INSTRUCTION

6. Enjoy Amazon Alexa Control

Now with Amazon Alexa, you can take control the mushroom lights by asking it to change colors, turn lights on and off by using simple commands.

For example, using these Alexa commands below:
"Alexa, Turn on/off (Specific light)"
"Alexa, Set the (Specific light) to green"
"Alexa, Set the (Specific light) to red"
"Alexa, (Specific light) lights fifty"
"Alexa, (Specific light) out"

Tips:
(Specific light) is the device name you named on XMCOZY APP.

GOOGLE ASSISTANT PAIRING INSTRUCTION

1. Download the APP

Search "Google Home" in the App Store for iOS device and in the Google Play for Android device to install.

2. Sign in or register a new account

3. Pair the Google Home APP to Google Home Device (follow the on-screen steps)

4. Link XMCOZY account in set up devices

a. Click the "+" icon in the upper left corner of home page, then click "set up device".

Important tips: please make sure the XMCOZY app, Google Home APP and Google Home devices are connected to the same Wi-Fi network.

GOOGLE ASSISTANT PAIRING INSTRUCTION

b. Click "Works with Google"

c. Input "XMCOZY" in the search bar.

d. In the new window, select your XMCOZY account's region, input your XMCOZY account and password, then click "Next Step" and "Authorize".

GOOGLE ASSISTANT PAIRING INSTRUCTION

5. Enjoy Google Home Control

Now you can take control the smart mushroom lights through Google Home by asking it to change colors, turn lights on and off by using simple commands.

For example, using these voice commands below:
"Google, Turn on/off (Specific light)"
"Google, Set the (Specific light) to green"
"Google, Set the (Specific light) to red"
"Google, (Specific light) lights fifty"
"Google, (Specific light) out"

Tips:
(Specific light) is the device name you named on XMCOZY APP.

TROUBLESHOOTING

Question

Solutions

1. Why the colors of lights are different or can't respond to the same color in the APP?

The cables are connected incorrectly. Please check all connectors and connect them by aligning the point. (Include the connection to the power controller)

2. Could the power adapter hold more than 6 lights?

No. The power adapter is 36W max and only can hold 6 lights in total. For more lights connecting, please contact XMCOZY+ Customer Service Team [service.2@xmcosy.com]

3. The lights can't connect to the APP.

1. Please update the APP to the newest version.
2. Please turn on Bluetooth, 2.4GHz Wi-Fi, mobile data, and locations when connecting the devices.
3. Please try to connect the phone with a hotspot rather than Wi-Fi to see whether it's the problem with Wi-Fi.
4. If the routing security level is very high or incompatible with the APP, it will cause the problem of can't connecting to the APP. Please lower the security level of your router to make it compatible with XMCOZY APP. Or send us your router model for further solutions.

4. Home network is 5GHz.

The wall penetration capability of 5.0GHz is weaker than 2.4GHz, which means that the outdoor signal of 5.0GHz is worse than 2.4GHz. Therefore, most smart devices support 2.4GHz networks or dual-frequency networks of 2.4GHz and 5.0GHz. You can log in to the management page of your router and change the SSIDs of the 2.4 GHz and 5 GHz networks to differentiate them.

CONTACT

For questions, assistance, or support, Please Contact:
service.2@xmcosy.com
or scan to email

* Required Information

1. Amazon Order ID

2. Product Model NO.

XMCOZY+ Customer Service Team will reply within 24 hours.

For more info. or news about XMCOZY+, pls follow XMCOZY+ social website.

@xmcosy+ @xmcosy+ @xmcosy

WE CAN HELP!

YOU DON'T NEED TO RETURN IT TO AMAZON WE WILL PROVIDE YOU WITH A 100% SATISFIED SOLUTION

Lighting Expert, Brighten up Your Life

8.9x12.7cm 2022.06.06