

Front

Back

billboard® CHARGING TRUE WIRELESS CASE EARBUDS



TWS function supported
(Pair 2 earbuds to play as one)

USER MANUAL

INSTRUCTION GUIDE



KEY FUNCTIONS

Power on/off
Play/pause
Receive/hang up/refuse/re-dial phone calls
Activate Siri by long press the Multifunction button for 2 seconds

INSTRUCTION

Power on: Take the earbuds out from the charging case it will turn on automatically or long press the Multifunction button to turn on.
Power off: Long press the Multifunction button to turn off or put the earbuds into the charging case it will turn off automatically.
Playing music: In play mode short press the Multifunction button to pause playback, and press again to resume.
Answering calls: when there is a call, you can hear the ringing from both of the earbuds. During the call both earbuds can hear, but only the master earbud can talk.
Answer an incoming call by short press the Multifunction button on either side, and press again to hang up.
Refuse an incoming call by long press the Multifunction button on either side.
Re-dial the last number by double-click the Multifunction button on either side.

CHARGING DEVICE

Charging earbuds
1. put the earbuds into the charging case, the earbuds will be charged automatically.
2.The earbuds will solid red during charging and turn off once charging is completed.
Charging the charging case
1.Plug the charger cable into the charging case.
2.Connect the charger to a USB power source, the charging case will flash blue during charging. If charging does not start, disconnect the charger plug it in again and try. Charging the batteries may take hours.
3.When the battery of the charging case is fully charged, the four indicator light on the charging case will be solid blue. Disconnect the charger from the USB power source and the charging case.

FCC Information

FCC ID:2AML6KR303

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.
Federal Communications Commission (FCC) Statement
This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard, FOR HOME OR OFFICE USE.

Warning :

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

WIRELESS EARPHONES

Thank you for purchasing these Billboard® True Wireless Earphones. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.

Package contains

- Charging Case
- TWS Earbuds
- USB charging cable
- User manual



Bluetooth® Connect with a new device

- Take the earbuds out from the charging case the earbuds will turn on automatically.
- Two earbuds will paired automatically when you turn on the earbuds. (If they don't paired automatilly, please double click either side of Multifunction button) One of the earbud will flash blue every few seconds once pairing successfully.
- Activate Bluetooth® of mobile phone and search for device name "BB-BT-EP" then connect it. The earbuds will flash blue every few seconds once connected successfully.
- Play the music from your mobile phone and enjoy.

Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.
Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.
Never use any charger that is damaged.
Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.



BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle battery according to local, state and national regulations.



It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for listening to music.

LIMITED WARRANTY

ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect and replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.
This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor at any product the exterior of which has been damaged or defaced which design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW.
Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases & Accessories, Inc.
The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases & Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases & Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liabilities and responsibilities of ESI Cases & Accessories, Inc. be liable or in any way responsible, for any incidental or consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.
This warranty does not cover cables that have become frayed, cracked, or broken from use. The user should immediately replace this, or any, charge cable that has become frayed, cracked, or broken, as it may constitute a serious safety risk, including electrocution, if it is continued to be used.

Send product with \$11.95 shipping & handling fee to:
Manufactured by ESI Cases & Accessories 44 East 32nd Street New York, NY 10016
Tech Support : (212) 883-8838 <https://esicellular.com>
TechSupport@ESICellular.com

PLEASE FOLLOW DIE CUT & FOLD LINES

FOLD
CUT