

AUKEY INTERNATIONAL LIMITED

Web: www.aukey.com E-mail: support@aukey.com

Add: No.102, Building P09, Electronic Trade Center
Huanan City, Pinghu Town, Longgang District

Shenzhen, Guangdong 518111 CN C E RoHS 🕸 🗵



Introduction

Thank you for choosing Aukey BR-C8 Bluetooth car kit. Please read the user manual carefully and save it for future reference. If you need assistance, please contact Aukey support by email to support@aukey.com with details.

Product Overview

1. Multi-function Button

2. Mic

3. Previous Track


4. Next Track

5. LED Indicator

6. Sticky Gel Pad

7. 3.5 mm Audio Output

8. USB power connector



Specifications

Standard	4.1
Supported Profiles	A2DP, AVRCP
Operation Range	33 ft / 10m

- Getting Started
 Setting up the receiver

 1. Place the receiver at desired location using the sticky gel pad.

 2. Plug the car charger into your cigarette lighter and power the receiver using the USB connector.

 3. Connect the receiver to your car stereo AUX port using the 3.5 mm connector.

Power on/off

Connect the receiver power to the cigarette lighter charger. The unit automatically power on when you start your vehicle engine and automatically power off when you turn off your vehicle.

You can manually power off the receiver by disconnect the USB from the charger.

Note:When the receiver is turned on, you can manually turn off the receiver by pressing and holding the multi-function for 5 seconds. If you want to restart the receiver, press and hold the multi-function for 3 seconds.

- Pairing to new device

 1. When you start your vehicle, the receiver will automatically turn on

 2. If you have not paired the receiver with any device, it will automatically go into pairing mode with white White LED flashing

 3. Bring your device into pairing mode and search for connection

 4. "Aukey BR-C8" should appear in the search result

 5. Tap on the name to connect

 6. Once pairing is successful, the white LED will stay on

- Note:

 1. If a code or pin is required for pairing, please enter "0000".

 2. The receiver will stay in pairing mode for 10 minutes at most if no pairing device is found.

 Afterwards, it will power off automatically. If you want to restart the receiver, press and hold the multi-function for 3 minutes.

 3. When the receiver is successfully connected with one device, simultaneously press and hold the
- << and >> button for 2 seconds, the receiver will switch to pairing mode.

Pairing with connected devices
If you have successfully paired the receiver with your device previously, simply bring your device into pairing mode. The receiver will pair to your device by itself.

The receiver has a built-in microphone for making/answering phone calls.

Answer a call	Press the multi-function button once
End a call	Press the multi-function button once
Redial last number	Long press the >> button for 2 seconds
Reject an incoming call	Press and hold the multi-function button for 2 seconds
Mute / Resume a call	During a call, press and hold the << button for 2 seconds
Voice Switching	During a call, Press and hold the multi-function button for 2 seconds
	to switch between the receiver and your phone for talking

Note:
You can't adjust the volume from the receiver when streaming music and answering a call. Please adjust the volume from your mobile phone or car audio system directly.

- FAQ
 Q: The receiver does not turn on after starting my car.

 Make sure the USB cable is plugged into the car charger

 Make sure the car charger is connected to cigarette lighter

Q: I am having trouble pairing and connecting to my device

- Make sure your device supports A2DP
 Check if the receiver is in pairing mode (white LED flashing)
 Take your device closer to the receiver and make sure your device is into paring mode.
 If your device is asking for a "PIN" or "Code", please enter "0000"

- Q: I cannot hear any music from my sound system.

 Make sure the receiver is connected well with your car audio system via AUX input

 Check your sound system settings to ensure that you have selected "AUX" or "Line-in" setting

 Volume is at an audioble level on both your audio device and on your sound system

 Please check your audio device is playing music through connection

Q: The music sometimes cuts off while playing.

Make sure your phone/music player is in direct line of sight from the receiver.

Q: There is a delay in the music.

• A variable delay exists between when the music is played on your device and when you hear

- 05 -

the sound from speakers. This is completely normal.

Q: Can I power the receiver using another charger/power source?

We recommend using the car charger inside the package to power the receiver. However, you can still use another charger / USB power source to power the receiver.

- Care and Maintenance
 For driving safety, we recommend place the receiver at a convenient spot where you can reach easily with your orm.
 Avoid placing the receiver in high temperature areas
 Do not use chemicals or detergents to clean the product

Warranty

We warrant this device for 24 MONTHS from date of the original purchase. If the device fails due to a manufacturing defect, please contact Aukey support by emailing to support@aukey.com with your purchase order ID and details of the problem. If you have purchased the product from a seller other than Aukey, please contact your seller for warranty cover.

Contact
For additional assistance or warranty cover claim, please contact us:
E-mail: support@aukey.com (all enquires)
Website: www.aukey.com

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.