// maxpower

MPD515L

<u>user manual</u>



PECIFICATIONS

Output Power: 5W

SNR:≧80dB

THD: ≦ 10%

Battery:Built-in 1200 mAh rechargeable battery

Power supplied:Power adapter 5.0V/1A

Loudspeaker:4 inch x 1,magnetic resistant 3 ohms.

DEVICE FEATURES

1.Product dimensions:7.95"H x 6.5"W x 6.5"D

2.BT,wireless stream music from any BT-enabled devices such as mobile phone notebook.

and

3.Built-in MP3 digital decoder for decoding and playing MP3 files.It brings you perfect sound quality.

4.External TF card and USB socket to enjoy music.

5.Micro DC 5V charging, supply with charging cable.

6.1500 mAh rechargeable battery.

7.FM digital radio(87MHZ-108MHZ), listen to the latest news and music.

8. Able to connect to any audio output equipment, such as mobile phones/MP3/MP4/laptops, etc.

9. Microphone input to enjoy outdoor KTV.

WARNINGS

1. Do not allow water to spill onto the surface or into the product

2. Unless the relevant regulatory instructed or has been directed by a person whom responsible for thesafety of the products they use,otherwise the product is not available for the person with body weakforce,or there is a lack of sensory capabilities persons(including children)

3. This product is not intended for using by childrenplease take care of children,do not let them play withthe product .

4. If the product surface is damaged or the case of mechanical or electronic equipment malfunction,do not use this product, please contact with our service center.

5. Do not shake or up-down dumped about this product.

6. Do not place the product immersed in water.

7. Do not place the product in light exposure to the location,to be placed in a dry and ventilate place.

8. Do not place heavy objects on the product.

Thank you for choosing our products!

INSTRUCTIONS

1. Mr o Shortly pressing for switching the light effects or turning off the LED light.Long pressing for switching among BT ,FM.Aux in ,TF Card,USB modes.

2.I Nortly pressing to play the previous music under BT,TF Card,and USB modes. Shortly pressing to play previous radio station under FM mode. Long pressing to down the volume under BT,TF Card,and USB modes.

 »_{II}/sCAN : Shortly pressing for music play/pause.Long pressing for radio station automatic searching under FM mode.

4. ▶►/IV+: Shortly pressing to play the next music under BT,TF Card,and USB modes.Shortly pressing to play next radio station under FM mode.Long pressing to up the volume under BT,TF Card,and USB modes.

5.DC 5V:Charge Jack for built - in battery.When the DC 5V cable plugs in,the indicating LED lights up 6.Aux:AUX IN can connect to PC.mp3,Phone.or other aux facilities.

7.USB Port:Support USB and can play MP3 format music in U disk.

8.TF card Port:Support TF CARD and can play MP3 format music in CARD.

9.OFF/ON Switch:Turn it to the "OFF" side to turn off or the "ON" side to turn on speaker.

10.MIC jack:Plug in a wired microphone to play Karaoke.

FUNCTION

1.How to connect to BT:

When you turn on the speaker, it should already be on the BT mode.

Please go on your smart device or cell phone and search for the BT connections.

You should seem, MPD515L. Please select it and you will be connected and ready to enjoy the tunes.

Short pressing the |◄◄/V- button to play last music.Long pressing to down the volume.

Short pressing the ►►/V+ button to play next music.Long pressing to up the volume.

Short pressing the ►II /SCAN button to play/pause music...

2.How to pair two speakers with the TWS function:

Turn on speakers,double press the "▶ || /SCAN" button on one of the speakers. And then an indication voice would sound. Speakers would enter TWS mode in 1-3 seconds. Two speakers could be connected with a same BT device and then play music together. When double press the

"▶| /SCAN" button again to cancel the TWS function.

3.Radio function:

Long press the M/♥ button and switch to Radio mode.

Long pressing the MI/SCAN button for station automatic searching.(Automatic searching will be finished in 2-5 minutes.)

Short pressing the |◄◄/V- button to play last station.Long pressing to down the volume.

Short pressing the ▶▶∤V+ button to play next station.Long pressing to up the volume.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator your body.