	PRINTER SLUG FOR TECH PACK
BRAND: XTREME CATEGORY: POWER PRODUCT NAME: XWC8-1042-BLK Vent/Suction Mount FILE NAME: XWC8-1042-BLK_UserManual ITEM NUMBER: XWC8-1042-BLK	ADDITIONAL PRINTING PROCESSES: UV SPOT: GLOSS METALLIC FOIL: DEBOSS: EMBOSS: VARNISHING TECHNIQUE: MATTE LAMINATION
PRESS WORK: PRINT 1/1. TRIM TO SIZE, SCORE, FOLD WHEN SPECIFIED	PRESS SPEC COLOR REFERENCES
SCALE: 100%	DIELINE
ASSEMBLED PACKAGE DIMENSIONS (in Inches)	GLOSS UV SPOT
WIDTH: 3"	EMBOSSING (RELIEF)
HEIGHT: 4.9"	DEBOSSING (SUNKEN)
DEPTH:	F-1
DIELINE OVERALL DIMENSIONS (in Millimeters) WIDTH: 78.065mm	FOLDING LINE
HEIGHT: 124.873mm	PRODUCT PLACEMENT
MANUAL MATERIAL, THICKNESS & SIZE	FOILING
SUBSTRATE TYPE:	GLUE FOLD
MATTE ART PAPER C2S, 100gsm	Ø20mm SECURITY STICKERS PLACEMENT
WINDOW:	F - 1
INNER TRAY:	BLISTER OR INNER TRAY PLACEMENT
BLISTER:	CLOTH LIFT TAG
PLASTIC BAG:	
MAGNET:	ADDITIONAL PANTONE COLORS (NOT CMYK)
VELCRO:	SOLID COLOR NAME:
SECURITY STICKERS:	NEON COLOR NAME:
HANG TAB COLOR/ MATERIAL/SIZE:	METALLIC COLORS:
FOAM	VENDOR'S FOIL NAME/NUMBER:
CORRUGATED BOARD: PAPERBOARD:	
USER MANUAL: PRINT 1/1 IN BLACK ONLY	FILE SAVED AS: .ai = FULLY EDITABLE
OSER MANOAE. TRINT 1/1 IN BEACK ONE!	-OUT.ai = OUTLINED
PACKAGING TYPES	.pdf = Acrobat .jpg = Flat image
FOLDING CARTON:	.jpg = Flat Image .png = DIGITAL (transparent background)
FOLDING CARTON WITH DOOR PANEL:	
RIGIT GIFT BOX:	APPROVAL CHECKLIST:
CLAMSHELL:	PRIMARY DESIGNER: Rita Manukyan DATE: 06/28/2024
SLIDING/SLIPCASE:	SECONDARY DESIGNER: Heather Hui
TRAPPED BLISTER CARD	DATE: 09/18/24
BLISTER CARD: OTHER:	PROOF READ: DATE:
	APPROVED BY: DATE:

Printer Slug

PRINTABLE LAYER:

Manual Artwork

AUTHORIZATION SIGNATURES:

Press Ready Artwork.

DO NOT PRINT THIS LAYER:

FRONT PAGE

SAFETY AND CARE INSTRUCTIONS

Read all the instructions before using the product and them store them for future reference. Failure to follow these safety instructions, could lead to fire, electrical shock, personal injury, property damage, or damage to the product.

- Do not expose to rain, moisture, or other liquid. Do use near water such as swimming pools, bathtubs, or sinks, If it becomes wet, immediately unplug the product from a power source. Do not handle the unit, USB cord or wall charger with wet hands.
- Do not charge, or use, the product if it has been submerged in water, of if water has got inside the product.
- Do not expose to heat sources, the sun, or leave in a hot vehicle. Do not
- · Do not expose the product to extremely high or low temperatures. Use this product in a location with a temperature of 32°F - 95°F. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 170°F could cause serious damage and
- · Do not dissemble, there are no serviceable parts inside
- ${\boldsymbol{\cdot}}$ This product is not a toy. Keep out of reach of children or those that
- Do not use abrasive cleaning solvents to clean the unit.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

FCC STATEMENT

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the

- This device complies with part 15 of the ECC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undesired operation.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures: • Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

ONE YEAR LIMITED WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Scan the QR code on the front of the manual to extend your warranty from 1 Year to 2 Year Limited.



Made in China for Jem Accessories. Edison, N.J. 08817



When folded, please make sure that this title page is visible and not folded inside.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service: customerservice@xtremecables.com





PRO SERIES

BACK PAGE

INTRODUCTION

Thank you for purchasing this wireless phone charger with included suction cup and vent mounting options. This Qi compatible wireless charger features up to 15W of power depending on your device's

SPECIFICATIONS

WHAT'S INSIDE

Vent Clip Base

Manual

Suction Cup Base

USB-C Power Cable

LED Smartphone Mount

USB-C Input: 5V/3A, 9V/2A; PD2.0, QC3.0 -Wireless Charging Power: 15W Compatible with Oi enabled smartphones.

GETTING TO KNOW YOUR PRODUCT



· With locking nut in place, attach either the vent mount or suction mount into the back of the wireless charger and tighten the locking nut.

- Attach the wireless charger to the vent, dashboard or another suitable
- Connect the USB-C cable to the wireless chargers USB-C port and to a compatible power source.

OPERATION

- · When the wireless charger has an adequate power supply source and no device is connected, the clear bezel will illuminate blue.
- · When a compatible device is successfully connected and actively charging, the bezel will illuminate green.
- · Slide in your compatible smartphone adjusting the bottom sliding arm to the adequate position and locking the clamping arms by pushing them inwards toward the device to secure the phone in place,
- · Press the release button on top, opposite the side of the bottom adjustable clamp, to release the clamping side arms.
- Once your device is fully charged, disconnect the USB-C cable from the wireless charger or remove your device.

WARNINGS

- · Remove metal cases, or cases with any magnet/metal components, from phone before charging
- Do not ever place metal objects on the charger when charging or not charging. - Read all the instructions before using the product, and use the
- product as intended. • If using the product in a motor vehicle, check with all applicable laws
- and compatibility with your motor vehicle before use. · Consider tuning off your phone's vibrating notifications during charging, as vibrations may cause your phone to shift position on the
- charger and stop charging. - Disconnect the USB cable once the product is fully charged.
- · Qi wireless chargeable phones with metallic looking finishes will charge normally.

WARNINGS

855.999.8041 | WWW.XTREMECABLES.COM

- · Keep close supervision of this product if being used around children. - Do not expose to rain or moisture, and do not use near any water
- source such as swimming pools, bathtubs, or sinks. • Do not expose to heat sources, the sun, or leave in a hot vehicle. Refer to user manual of device to be charged to ensure compatibility.
- Do not modify or use the charging station other than its intended • Do not cover the product with paper or other materials. Use in a
- well-ventilated area when charging. · Wireless chargers generate heat when charging, and the wireless
- charger may temporarily stop charging if it gets too hot. · Do not use if damaged or modified.
- Do not dissemble. There are no serviceable parts inside.
- Do not place magnetic strip cards or similar magnetically sensitive items between the phone and the charger. Wireless charging uses magnetic induction that could damage these items.
- Multiple devices cannot be charged at the same time on the same charging areas.
- · Your phone will not charge wirelessly if it is connected to your computer's USB port, or if it is not connected to a compatible power
- Do not use abrasive cleaning solvents to clean the unit.
- If you have a pacemaker or other such device, consult a physician before using this product.
- Do not leave the charger unattended while charging a device.
- Do not fall asleep while the device is in use. Disconnect devices before going to bed.
- · Use caution to not operate phone while connected to charger as pressure to phone could cause the phone to detach and fall from the
- Do not place anything on product other than compatible devices to be charged.

charging station.