Common product faults

Cannot start charging	1.The power supply does not meet requirements 2.Unstable connection of power interface 3.The charging distance is out of range 4.There are other metal objects in the charging area	Replace the adapter that match Reinsert the power socket Susing within the specified distance Remove metal foreign bodies	
Charging is slow	The temperature of product is too high	Please wait until the temperature drops to room temperature before using the device	

Hazardous Substance Declaration

107

This mark is the product pollution control mark, the number of which represents the environmental service life. In this period of time, under normal conditions of use harmful substances will not cause greater pollution to the environment or damage to human life and property.

×						

This form is in term of Stipulation SJ/T 11364

Ot It means that the content of the harmful substance in a part of the

requirements specified in GB/1 265/2.

X It means that the content of the harmful substance in a part of the part exceeds the limit requirements specified in GB/T 26572.

Product Warranty Instructions

Wireless charger product after-sales service strictly in accordance with Law of the PRC on the Protection of the Rights and Interests of Consumers, and Product Quality Law of the People's Republic of China Adopted to provide After-sales service.

1.Within 7 days from the next day after purchase (sign for), if this product has performance failure, you can enjoy free return or exchange service after being tested and determined by the after-sales service center:

2. Within 15 days from the next day after you purchase (sign for), if this product has performance failure, you can enjoy free exchange or repair service after being tested and determined by the after-sales service center:

Within 1 year from the next day after you purchase (sign for), if this oduct has performance failure, you can enjoy free repair service after

Non warranty regulations

In one of the following cases, we don't offer three guarantees and only

- 1.Damage caused by improper use, maintenance and storage of consumers
- 2. Damage caused by unauthorized service provide
- .Damage caused by majeure.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

11 This device may not cause harmful interference, and

1) This device must accept any interference received, including interference that may cause undesired operation.
We show the provided and the provide

wold the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against
harmful interference in a residential installation. This equipment generates uses and can radiate radio
frequency energy and, front installed and used in accordance with the instructions, may cause harmful
interference to radio communications. However, there is no guarantee that interference will not occur in a
particular installation. If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to ty to correct the

Reorient or relocate the receiving antenna.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connecte Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Manufacturer: GCteq Wireless (Shenzhen) Co., Ltd Website: http://www.gcteq.com

> Checked Certificated of qualification




Power freer• 用电更自由

GF-01Mini Series
Product instruction

Introduction

240.00 mm





Open a 59.5-60mm diameter through-hole in the appropriate position of furniture, such as table, sofa armrest, etc..

(Note: The overall thickness of the product is 15mm, the thickness of the soft material of the hole should not exceed 5mm)



2. Adjust the position of the product and install it into the hole



pecification

Matters need attention

using this product:

Please use the original power adapter of this product to provide power for the wire-free charger.

2. Make sure there are no metal objects between the wireless charger and mobile phone while phone is charging, to prevent metal objects from being

Please do not place magnetic cards such as bank cards and corporate card in the charging area to avoid damaging.

In the charging area to avoid damaging.

4. In order to get a better wire-free charging, please do not exceed the maximu charging distance of the product.

Instructions

 Make sure that your phone supports wireless charging, because the wirele charging requires the support of the wireless induction coil built into the phone(hardware);

When you power on the wireless charger, please make sure there is no magne object (metal, magnet, etc.) in the charging area, then switch on the power, and place the mobile ohone in the charging area;

3. The wireless coil of different phones is located in different locations. The sensor area is generally located in the center of the phone. You need to make sure that the wireless coil of the phone is aligned with the center of the wireless charging area. When charging starts, the screen will light up to show the charging prompt;
4. You need to pay attention to the limitation of charging distance for wireless charging. The distance between the phone and the wireless charger should not exceed the maximum charging distance of the product.

材质工艺要求: 材质: 70g普

材质: 70g普通书写纸 工艺: 单色双面印刷、风琴折 印刷要求: 色相正确、印迹牢固、套印准确、各色套印不漏杂色、套印误差≤0.1mm 说明书边角为直角、不做R角