


## Self-use

After leaving the factory, the Bluetooth headset is fully tested after startup, so the battery is not fully charged. It is recommended that you first fully charge the Bluetooth headset with a 5V-1A charger or an electric car. After the first use of the Bluetooth headset, all the power is used up and then fully charged, so that the service life is longer. Note: do not use fast charging to avoid damage to earphone battery.



user's manual

## 首次使用:

蓝牙耳机出厂后经过开机全面检测，故电量是未满电状态，建议您先将蓝牙耳机用5V-1A充电器或者电脑USB充满电。第一次使用请将电池用完再充满电，这样使用寿命更长。

注：禁止快充，以免对耳机电池造成损伤。



用户手册

## Introduction to headset functions

### Power:

When the machine is out of the warehouse, the white light will flash for 3 seconds, and then the white and green lights will alternate to enter the pairing state, and the prompt tone is "The machine is started and paired successfully".

### Shutdown:

After charging and shutting down, the green lights will flash for a long time, press and hold the MFB key for 3 seconds, and the green light flashes three times, and the prompt tone is "shutdown".

### pair:

After leaving the warehouse, the white light flashes three times, the white and green lights of the main and auxiliary ears flash alternately, and the white and green lights of the main ear flash alternately, and the auxiliary ear turns off the lights and enters the matching state.

### Pairing connection:

After leaving the warehouse, the main light flashes 3 times, the white and green lights of the main and auxiliary ears flash alternately, and the left and right ears enter the pairing state. After pairing, the white and green lights of the main ear flash alternately, and the auxiliary ear turns off the lights and enters the matching state.

### Answer the phone:

When calling, press MFB key to answer the call.

### Hang up:

In case of emergency, long press the MFB key briefly to hang up the phone.

### Call number:

When calling, the headset will automatically report the number via prompt, incoming call "1.....".

### Reject calls:

When calling, press and hold the MFB key for about 2s.

## Voice: "Bluetooth connected"

### Play/pause:

During playing, double click MFB key for a short time to pause the music.

### Disconnect:

When connected, turn off the Bluetooth or Bluetooth headset of the mobile phone, and the prompt tone is "Bluetooth disconnected". The white and green light on the main ear flashes, and the light on the auxiliary ear goes off.

### Automatic playback:

When the machine is turned on or when the connection range of Bluetooth device is automatically connected with the power Bluetooth device, and the "Bluetooth connected" will sound.

### Answer the phone:

Put the earphone into the bin for charging, and turn off the light after the earphone is full of green light.

### Charging of charging bin:

Plug in the 5V power supply to charge the bin, and the display screen shows the power.

### Voice wake-up function:

Three touch

## Low power shutdown:

When the battery voltage is lower than the battery voltage, the headset will turn off automatically.

### Volume up and down:

Single click the left ear MFB key to reduce the volume, and single click the right MFB key to increase the volume.

### Up and down:

Long press 2s MFB key on the left ear to achieve the previous song, and triple long press 2s MFB key on the right ear to realize the next song.

### Headphone compartment charging:

To disconnect the phone from the headset, turn off the headset in any of the following ways: disconnect the headset from the phone using the Bluetooth menu; move the headset away from the phone 10 meters (about 30 feet).

### Maintenance and maintenance:

Please keep the product out of the reach of children. Water and other liquids will void the warranty of the headset. If the headset has been wet, please dry the headset thoroughly before use. Do not disassemble, modify or squeeze the headset without permission, otherwise it may cause the headset to malfunction or break.

### Note that when:

you tear up or lose the warranty card, you will lose the chance of warranty. Our company has the right of final explanation.

## notes:

In accordance with the relevant provisions of the relevant laws and regulations of the people's Republic of China, the people's Republic of China on the protection of consumers' rights and interests and other relevant laws and regulations of the state, we protect the repair and replacement of the sellers and producers of consumer goods. For the relevant goods, earnestly fulfill the responsibility and obligation of repair, replacement and return.

- The warranty service is only limited to the manufacturer-made damage caused by the quality of the product under normal use.
- Within 30 days from the date of purchase, if there is any performance failure, arrival, artificial damage, the product will be returned and replaced free of charge.
- The product subject will provide warranty within one year from the date of purchase.
- If the company still needs to repair the product beyond the warranty date or beyond the warranty period, We charge for maintenance at our discretion.

**Note that when:**  
you tear up or lose the warranty card, you will lose the chance of warranty. Our company has the right of final explanation.

## Product quality warranty card:

Product model	
Commodity origin	
Username	
Sale location	
Date of sale	
Name of seller	
Sales contact number	
Maintenance records	

• The warranty card must be provided when making claims. Please keep it properly.

## 耳机功能介绍

### 开机:

当全开机，白灯闪3下，然后白绿灯交替进入配对状态提示音“开机配对成功”。

### 关机:

进入充电关机，绿灯长亮，长按MFB键5秒绿灯闪3下，提示音“关机”。

### 配对连接:

当耳机与手机进入连接状态后白灯闪3下，主副耳白绿灯交替闪，左右耳进入配对，配对完成后，主耳白绿灯交替闪，副耳灯灭，进入与手机配对连接状态。

### 配对连接:

当耳机与手机进入连接状态后白灯闪3下，主副耳白绿灯交替闪，左右耳进入配对，配对完成后，主耳白绿灯交替闪，副耳灯灭，进入与手机配对连接状态，打开手机蓝牙点击蓝牙配对设备名进行配对配对成功后，提示音“蓝牙已连接”。

## 音：“蓝牙已连接”

### 播放/暂停:

播放中，双击MFB键，音乐暂停。

断开连接: 连接状态下，关闭手机蓝牙或蓝牙耳机，提示音：“蓝牙已断开”。主耳白绿灯闪，副耳灯灭。

### 自动回连:

在连接蓝牙内开机后，自动连接已配对后蓝牙设备提示音，“蓝牙已连接”。

### 接听电话:

来电话时，短按MFB键一下可接听电话。

### 挂断电话:

在通话中或充电中，长按MFB键可挂断电话。

来电报号: 来电话时，耳机自动报号；语音提示。来电“1.....”。

### 拒接来电:

来电话时，长按MFB键约2s。

## 低电关机: 各种开机状态下当地地电压低于3V

### 后:

耳机自动关机。

加减音量: 单击左MFB键，实现减音量单击右MFB键，实现加音量。

### 上下曲:

长按2s左MFB键，实现上一曲，长按2s右MFB键，实现下一曲。

### 耳机仓充电:

耳机放入仓充电，耳机绿灯长亮充

### 满后灭灯。

### 充电仓充电:

插5V电源给仓充电，显示屏有

### 电量显示。

### 充电语音唤醒功能:

三击触控。

## ■ 注:

当耳机进仓充电时，请使用不超过5V 1A输出的充电器。禁止使用快充，以免对耳机电池造成损伤。充电前请先检查充电桩的型号是否适用耳机。

耳机在潮湿时会自动脱电，建议每个月给耳机充电一次。请勿将耳机放入水中或水里。

### ■ 断开手机和耳机连接:

要断开手机和耳机连接，请采用以下任何

方式关闭耳机。

使用手机的“蓝牙”功能表断开耳机与手机的连接。

将耳机移至距离手机30米（约30尺）以外的位置。

### ■ 维护和保养:

请所有配件放在小孩接触不到的地方。

雨水等液体都会使湿耳机的电路，如果耳机

已经被弄湿，请将耳机彻底擦干再使用；

请勿私自拆卸、改装或挤压耳机否则可能导

致耳机发生故障或破裂。

耳机损坏后请到正规维修点维修。

## 产品质量保修卡:

产品型号	
商品产地	
用户名	
销售地点	
销售时间	
销售商名称	
销售联系电话	
维修记录	
销售商名称	
销售联系电话	
维修记录	

• 该质量保修卡适用于本公司生产的商品。根据《中华人民共和国消费者权益保护法》及《中华人民共和国产品质量法》等法律法规的规定和规定，凡经我公司销售的商品，因质量问题造成的损害，由我公司负责修理、更换、退货或赔偿损失。

• 本质量保修卡适用于本公司生产的商品，不适用于本公司生产的商品，修理者未经生产者同意，修理、更换、退货或赔偿损失的，由修理者承担责任。

• 对于超过保修期的商品，修理者可以收取修理费。

• 本公司保留对本质量保修卡的最终解释权。

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction