

**RS06(B75)**

## Wireless Charging Bluetooth Speaker with Alarm Clock

### INSTRUCTION MANUAL



### WHAT'S INCLUDED

- 1 X Bluetooth Speaker
- 1 X USB to Micro-USB Charging cable
- 1 X Instruction manual

### BLUETOOTH PARING INSTRUCTION

(Note: The Bluetooth code is **B75**, pair code:0000)

1. Keep the distance between the phone and speaker within 10 meters. (for pairing only)
2. Press and hold the round power button for **2** seconds to power on, hear the prompt sound, the display turns on.
3. Turn on the Bluetooth function on the mobile device, search for Bluetooth devices, and select "**B75**".
4. If you are prompted to enter a password to complete pairing (Note: some mobile phone can be connected directly without entering pairing code), enter "0000".
5. The **B75** will connect to your device and you will hear "paired".
6. It is ready for use.  
\*Speaker will automatically be paired if the mobile device has been paired before.
7. Press and hold power button for **4** seconds to power off.  
\*Press and hold "pause" button for 2 seconds can disconnect the Bluetooth connection.

## WIRELESS CHARGING FUNCTION

- Connect to the power supply 5V/2A by micro USB cable, the red LED light in the USB port will on.
- Put your mobile phone which supports wireless charging on the top of the center charging area.
- It starts to be charged and will show battery volume on your phone during charging.

## SPEAKER CONTROLS

### PLAY/PAUSE/ANSWER/REFUSE THE CALL

Press “pause (MFB)” button to answer the call, press it again to hang up. Press and hold “pause (MFB)” button to refuse the call. Double press “pause (MFB)” button to call back the last number.

### MUSIC/VOLUME

During a call or when listening to music

Volume + Press and hold “+” button

Volume - Press and hold “-” button

Go to next song Short-press “+” button

Go to previous song Short-press “-” button

## ALARM CLOCK FUNCTION

### EDIT CLOCK TIME

HOURLY EDIT: Double-press Clock button to enter editor interface. Press “+” or “-” to Adjust hour.

MINUTE EDIT: After hour edit, short-press Clock button to switch to minute edit. Press “+” or “-” to Adjust minute. Short-press Clock button to confirm and exit edit mode. No operation for 5 seconds will automatically confirm and exit.

### ALARM CLOCK SETTING

Alarm Clock 1: Press and hold Clock button for 2 seconds to enter alarm setting interface. After the display showed “ALA1”, short-press “+” or “-” to switch on/off the 1<sup>st</sup> alarm. Press the clock button then press “+” or “-” to adjust hour, short-press the clock button again to switch to minute. Press “+” or “-” to adjust minute. No operation 5 seconds will automatically confirm and exit.

Alarm Clock 2: After alarm1 setting confirmed, short-press Clock button to switch to alarm 2 “ALA2” setting. The operation method is the same as alarm1.

### ALARM CLOCK RINGS

When the time runs to the alarm clock setting time, the alarm bell rings for 30 minutes.  
Short-press the “clock” button to stop the alarm;  
Snooze mode: Short-press “Power” button, the alarm will ring again in 9 minutes later.

## CHARGING THE BLUETOOTH SPEAKER

(Be sure to fully charge the speaker before using for the first time.)

-Plug the standard USB charging cable into the speaker and a powered USB port.

-The LED light is red when charging. The light will turn off when the battery is fully charged.

Remark:

1. The Bluetooth speaker can be used during charging.
2. The LED flash red quickly and there is prompt sound when it is a low battery.
3. Please use the offered 2.1A cable to charge the speaker.

## SPECIFICATIONS

Speaker:40mm (120-20KHZ)

Power out: 3W\*2 4Ω

SNR:90±5dB

Built-in battery: 2000mAh

Charging time: up to 4.5 hours

Playing time: up to 7 hours

Product net weight: 330g

Charging standard: DC 5V, 1A

Wireless Charging Input: DC 5V, 2A

Wireless Charging Output: DC5V, 1A, 5W

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.