




| Step. | Description  | Screen Display  |
|-------|--|---|
| 1.    | Connect power supply and wait 40 seconds around for the system booting. When A08S first time booting, Setup Wizard will automatic execution. Press the [next] button to the next step when the welcome screen display.   |   |
| 2.    | Language setting: the system default Language is English. If you want to change to others, click [ Set Language ] button, you can scroll the list and choose from the next screen. Select the Language then click [next] button  |   |
| 3.    | Date and Time Zone setting: the system will automatic synchronous the date and time from your local internet access. If the date and time are not correct, please turn off the synchronous with internet, then select [ Change ] button to go to next screen for manual setting. |  |


4.

Wi-Fi Connection Setting: Turn on the Wi-Fi [On/Off] button, the screen will list all of AP that could be found. Click which one you has authorized to connect, you may be requested to input the password for the AP connection.



5.

My Location Setting: Choice one of the location service then press [Next] button



6.

Press [OK] button to finish Setup Wizard, the system Home Page will showing on the screen.



7.

Setting your Google Account: Choice [Settings] icon from Home Page. Scrolling the list on the left, and click [+ Add account]. Choice [Google] and following the instruction to sign existing google account or create a new one.



## Product Interface



USB port1 is OTG.

USB port2 is HOST.

Using Port1 for device software upgrade.

Any peripherals need to install software driver that should connect USB port2, but it is not guarantee that can work on Android system .

USB Maximum Output Voltage: 5V / 500ma

## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.