



Pro-Kart Racer

Instruction Manual

Item No.0223
Ages 4+

PRO-KART RACER
4 x AA
BATTERIES NOT INCLUDED
REMOTE CONTROL
1 x 9V
BATTERIES NOT INCLUDED


SAFETY AND PLAYING TIPS:

Please read instructions carefully before operating Pro-Kart Racer.


1. NEVER drive your vehicle on streets.
2. DO NOT pick up vehicle while in motion.
3. Keep fingers, hair, and loose clothing away from the tires and the wheel hubs while the vehicle is switched ON.
4. Keep vehicle and parts out of reach of very young children. Adult supervision is recommended.
5. Do not play outdoors during thunderstorms.
6. Do not drive your vehicle in sand or through water or snow.
7. Always turn your vehicle and transmitter "OFF" when not in use.
8. Do not store near heat or direct sunlight.

DRIVING YOUR PRO-KART RACER


To start up the engine, turn the Pro-Kart Racer and transmitter to ON. Then fully extend the antenna on the transmitter. Now you are ready to race!



1. To go forward, pull the trigger.



2. To go in reverse, push the trigger forward.




3. To stop, release the trigger.


- Helpful tips:
- For maximum speed, fully pull the trigger.
 - Control the speed by releasing slowly.
 - Be a Pro! Practice at different speeds and stopping by varying the amount you pull the trigger.

TURNING


When the motor is running (trigger is pulled), Pro-Kart Racer turns with the turning angle of the steering wheel.




1. For wide turns towards the left, QUICKLY turn the wheel left and release.



2. For wide turns towards the right, QUICKLY turn the wheel right and release.



3. For sharp left turns, turn & hold (briefly) the wheel to the left while the trigger is pulled.



4. For sharp right turns, turn & hold (briefly) the wheel to the right while the trigger is pulled.

Helpful tip: Remember that when Pro-Kart Racer is coming towards you, the steering is opposite to the way you turn.


Please note: The illuminated red light on the hand controller indicates that the remote controller is in operation.

ASSEMBLY


1. Before you begin to play, screw-in the transmitter antenna into the transmitter. For further details see Battery and Power ON/OFF Diagram.

Contents

Pro-Kart Racer



Transmitter (controller)



SPARE PARTS

