



MOTOROLA

MOTOSTART

H700 Bluetooth® Handsfree Headset

Get Connected in 4 Quick Steps

- 1 - CHARGE
- 2 - START
BLUETOOTH
FEATURE
- 3 - PAIR
- 4 - TEST AND
USE

For help, contact us at **1-877-MOTOBLU**
or visit us at www.hellomoto.com

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com
1-877-MOTOBLU
1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States for
hearing impaired)
1-800-461-4575 (Canada)

Guide Number: 6809495A68-O

MOTOROLA and the Stylized M Logo are registered in the US
Patent & Trademark Office. The use of wireless devices and
their accessories may be prohibited or restricted in certain areas.
Always obey the laws and regulations on the use of these
products. The Bluetooth trademarks are owned by their
proprietor and used by Motorola, Inc. under license. All other
product or service names are the property of their respective
owners.


© Motorola, Inc. 2005.



BEFORE YOU BEGIN

Before using this product, read the Important Safety and Legal
Information pamphlet and follow its instructions.

Take a moment before you get started to
familiarize yourself with your new
H700 Headset.



1



CHARGE

Your Headset's Battery



- 1 Plug the Motorola charger into the end of
the headset.

The indicator light turns red when the
battery is charging. It may take up to 1
minute for the indicator light to turn on.
When the headset's battery is fully charged
(about 2 hours), the indicator light turns
green.

- 2 Disconnect the charger.

Note: Headset is not functional while charging.

2



START BLUETOOTH FEATURE

Your Phone

Your phone's Bluetooth feature is off by default.
To use your headset, you must turn on the
Bluetooth feature in your phone.

For most Motorola phones:

- 1 Press **[Menu]** > **Settings** > **Connection** >
Bluetooth Link > **Setup**.
- 2 Scroll to **Power**.
- 3 Select **Change**.
- 4 Scroll to **On**.

- 5 Press **Select** to turn on the Bluetooth
feature. The Bluetooth feature remains on
until you turn the feature off.

*Note: These steps are for most Motorola phones. For other
phones, see your phone's user's guide.*

3



PAIR

Your Headset

Before you can use your headset, you must pair
(link) it with your phone.

Step A - PUT THE HEADSET IN PAIRING MODE

- 1 Ensure the headset is turned off (indicator
light not blinking and headset boom is closed).
- 2 Press and hold the Call **[Call]** button. After about
4 or 5 seconds, the indicator light becomes
steadily lit in magenta.
- 3 Release the Call **[Call]** button and immediately
open the headset boom. The indicator light
remains steadily lit in magenta.

If the indicator light is flashing in blue or not
steadily lit when opening the headset boom,
repeat **steps 1 through 3** on this page.

3



PAIR CONTINUED

Your Phone

Step B - SET YOUR PHONE TO LOOK FOR YOUR HEADSET

For most Motorola phones:

- 1 On your Motorola phone, press **[Menu]** >
Settings > **Connection** > **Bluetooth Link** >
Handsfree > **Look for Devices**.
The phone lists Bluetooth devices it finds.
- 2 Select **Motorola H700**.
- 3 Select **OK** or **Yes** to pair your headset with
your phone.
- 4 Enter the passkey: **0000**
- 5 Select **OK**.

When your headset successfully pairs with
your phone, the indicator light changes from
steadily lit to flashing blue.

*Note: These steps are for most Motorola phones. For other
phones, see your phone's user's guide.*

4



TEST AND USE

Your phone and headset are now paired
and ready to make and receive calls.
To make a call:

- 1 Open the headset boom and place the
headset over your ear.
- 2 On your phone, dial the number you want
to call and press the **SEND** key.
- 3 If your phone and headset are successfully
paired, you will hear ringing on the headset.

After you have successfully paired your
phone and headset, you don't need to
repeat these steps. For daily use, ensure
that your headset is turned ON and that
your phone's Bluetooth feature is ON.

To save battery power, turn OFF the
headset when you don't use it for an
extended time.

USING YOUR H700

See
**Features and
Functions Guide**
on the reverse side
for information on
using your H700.

TROUBLESHOOTING

My phone doesn't find my headset.

Make sure the indicator light on your headset is
on (lit in blue) and steady when your phone is
searching for devices (see step 3).

My headset worked before but now it's not working.

Make sure your phone is on and the Bluetooth
feature is turned on in your phone (see step 2).
If the Bluetooth feature was turned off or was
turned on only temporarily, you may need to
restart the Bluetooth feature (see step 2) and
pair your phone and headset again (see step 3).

Support.

If you need more help, contact us at
1- 877-MOTOBLU.

FOR DETAILS ABOUT YOUR HANDSFREE DEVICE

See the user's guide or visit us at
www.hellomoto.com/bluetooth and click
Support.

Features and Functions Guide

H700 Bluetooth® Handsfree Headset


IMPORTANT:
Be sure to first follow the **Quick Start Guide** on the reverse side to complete initial setup of your H700.

TURNING ON AND OFF

To turn your headset on, open the headset boom. The indicator light flashes blue.


To turn your headset off, close the headset boom. The indicator light will turn off.

To conserve battery power, turn off your headset when you don't plan to use it for a while.



WEARING THE HEADSET



- 1 Open the headset boom, then open the earhook (45° from the headset).
- 2 Loop the earhook over your ear.
- 3 Press the headset to your ear.
- 4 Point the headset boom towards your mouth.



CHANGING FOR USE ON OTHER EAR

You can wear your H700 headset on your left or right ear. The headset comes ready for the right ear. To change the headset for the left ear:


- 1 Open the headset boom, then open the earhook (90° from the headset).
- 2 Gently lift and pull the top of the earhook up and off the upper hinge pin. Then, pull it away to remove it.
- 3 Flip the headset over.
- 4 Hook the bottom of the earhook onto the lower hinge pin, then lift and pull the top of the earhook over the upper hinge pin.



CHANGING VOLUME BUTTON ORIENTATION

You can also change the orientation of the volume buttons on your headset.

- 1 Turn the headset power off.
- 2 Press the **Call** button until the indicator light becomes steadily lit in magenta, then press the **Volume** button you want to assign as the "volume up" button.



MAKING CALLS

Function	Action
Make a voice dial call	Tap the Call button and speak the name after the tone
End a call	Tap the Call button or close headset boom
Receive a call	Open headset boom or tap the Call button (if boom is already open)
Reject a call	Press and hold the Call button until you hear a beep
Redial last call	Press and hold the Call button until you hear a beep

Note: Your H700 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

MAKING CALLS *CONTINUED*

Function	Action
Answer a second incoming call	Press and hold the Call button (places first call on hold)
Toggle between two active calls	Press and hold the Call button
Join a 3-way call (Note: Feature is phone/network dependent.)	Press and hold both Volume buttons
Put an active call on hold or resume a call on hold	Press and hold the Call button until you hear a beep
Transfer a call from the phone to the headset	Tap the Call button
Disable or enable the indicator light	Press and hold both Volume buttons for 3 to 4 seconds
Mute or unmute a call	Tap both Volume buttons

INDICATOR LIGHTS

With the Charger Plugged In

Indicator Light	Headset Status
Red (steady)	Charging (less the 80% charged)
Yellow (steady)	Charging (more than 80% charged)
Green (steady)	Charging complete

With No Charger Plugged In

Indicator Light	Headset Status
Off	Power off
Magenta (steady)	Pairing mode
Red	Battery low
Blue (10 rapid flashes)	Pairing successful
Blue (slow pulse)	Connected (on a call)
Blue (quick flash)	Standby (not on call)

Note: After 5 minutes of inactivity, the light stops flashing to conserve power, but the headset remains in standby mode.

AUDIO TONES

The audio tones provide information about your headset status.

Audio Tone	Headset Status
Single high tone when pressing volume button	Volume at minimum or maximum
Five rapid high tones repeated every 60 sec.	Low battery
No audio indications; deteriorating quality	Out of range
Ring tone	Incoming call
Single high tone	Pairing confirmation
Single low tone	Voice activation
Dual high/low tone	Voice tag not recognized
Single high tone	End call
Low to high tone	Phone network not available
Two ascending tones	Mute enabled
Two descending tones	Mute enabled