

1. External Photograph of EUT

Brand Name: Zebra / Model Name: CS6080

Sample 1 & 3



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080





Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080

Sample 2 & 4



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080



**2. Photograph of Accessory****Brand Name: Zebra / Model Name: CS6080**

Specification of Accessories		
Adapter	Brand Name	Zebra
	Part Number	PWR-WUA5V6W0WW
Battery	Brand Name	Zebra
	Model Name	BT-000413
USB Cable 1	Brand Name	Zebra
	Part Number	CB-000707-01
USB Cable 2	Brand Name	Zebra
	Part Number	CB-000707-02

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: CS6080



Brand Name: Zebra / Model Name: CS6080

Adapter



Brand Name: Zebra / Model Name: CS6080

Battery

