



- No change in production shall be allowed without explicit prior written approval from Parrot
- Reference dimensions, shown in parantheses (DIM), are without tolerance and are for information prupose only
- All geometry is to be derived from the CAD database. Critical to function dimensions called out on this drawing are only for inspection purposes