

如何打开钥匙 查看产品标签 How to open the shell and show the Label location



第一步：用手摁下钥匙顶端的PUSH 键，钥匙顶端的备用钥匙可以轻松拉出。
Step 1: press the push button on the top of the key, the Emergency key on the top can be pulled out easily.



第二步，用撬动工具轻轻插入钥匙壳的顶端缝隙，稍微用力转动备用钥匙，就可以把这个遥控打开。
Step 2: Gently insert the prying tool into the top slot of the key case , and turn the Emergency key slightly to open the key.



第三步，这样就打开了这个钥匙来装和换电池，很容易看到产品标签，这个钥匙不会经过超声波 处理。
Step3: now the key was opened to install and change battery .and we can easy to see the label here. The key will not be processed by ultrasonic wave.

Step3: now the key was opened to install and change battery .and we can easy to see the label here. The key will not be processed by ultrasonic wave.