jump2group

Color Side 1: BLACK

Color Side 2: BLACK Flat size: 6.44 x 12.5 in.

Finished size: 6.44 x 2.5 in.

Fold: 5-panel accordian






1 *

4



2



3





MOB_OPT_SIP_Flatman_pen_M98401-B21_v4.indd 1

9/15/2021 9:04:24 PM



- Erases on-screen objects
- when pressed.

 Text selection tool.

 لودي الضغط عليه إلى محو العناصر الموجودة على إلشاشة. أداة تحديد النص.

- Menghapus objek pada layar saat ditekan.
- Alat pemilihan teks.
- При натискане изтрива обекти на екрана.

 ③ Инструмент за избор на
- Při stisknutí vymaže objekty na obrazovce.
- Nástroj pro výběr textu.
- Sletter genstande på skærmen, når der trykkes
- Værktøj til tekstvalg.

- O Durch Drücken dieser Taste werden Objekte auf dem Bildschirm gelöscht.
- Textauswahltool.
- Elimina objetos en pantalla al presionarlo.
- Herramienta de selección de texto.
- Σβήνει αντικείμενα στην οθόνη όταν πατηθεί.
- Εργαλείο επιλογής κειμένου.
- Un appui dessus permet d'effacer les objets à l'écran.

 Outil de sélection du texte.
- Briše objekte na zaslonu
- kada se pritisne.

 Alat za odabir teksta.
- Ouando premuto, cancella
- gli oggetti sullo schermo.

 Strumento di selezione del testo

- Басылған кезде, экрандағы нысандарды өшіреді.
- Мәтінді таңдауға арналған құрал.
- Nospiežot dzēš ekrānā esošos objektus.
- Teksta atlasīšanas rīks.
- Paspaudus ištrinami ekrane rodomi objektai.
- Teksto parinkimo įrankis.
- A megnyomásakor törlődnek a képernyőn megjelenő objektumok.
- Szövegkijelölő eszköz.
- Als u op deze knop drukt. worden objecten op het scherm gewist.
- Tekstselectietool.
- Fjerner objekter på skjermen
- når den trykkes på. Verktøy for tekstvalg.
- Po naciśnieciu wymazuje
- obiekty ekranowe.

 Narzędzie zaznaczania tekstu.

- Apaga os objetos no ecrã quando premido.
- Ferramenta de seleção de texto.
- Apaga objetos na tela quando pressionado.
 Ferramenta de seleção de
- texto.
- Când este apăsat, şterge
- obiecte de pe ecran.

 Instrument de selectare a textului.
- О При нажатии стирает
- объекты на экране. Инструмент выделения текста.
- Po stlačení vymaže objekty na
- obrazovke. Nástroj na výber textu.
- Če ga pritisnete, izbriše objekte na zaslonu.
- O Orodje za izbiro besedila.
- Poistaa painettaessa näytössä näkyvät kohteet.
- Tekstinvalintatyökalu.

- Briše objekte na ekranu kad se pritisne.
- Alatka za izbor teksta.
- Raderar objekt på skärmen när
- den här knappen trycks in.

 Verktyg för textmarkering.
- 🛭 ลบออบเจ็กต์บนหน้าจอ เมื่อกด เครื่องมือเลือกข้อความ
- Basıldığında ekrandaki nesneler silinir.
- Metin seçme aracı.
- Видалення екранних об'єктів при натисканні.
- Інструмент виділення тексту.
- オブジェクトを消せます。 **3** テキスト選択ツールです。
- 성 버튼을 눌러 화면의 개체를 지웁니다.
- ⑤ 텍스트 선택 도구.
- **②** 按下时将擦除屏幕上的对象。
- 按下時將清除螢幕上的物件。
- ① 文字選取工具。

Specifications

Temperature, operating Relative humidity 0°C to 40°C

(noncondensing), operating

(32°F to 104°F)

10% to 90%

Regulatory information

For regulatory identification purposes, your product is HSN-W002P.If required, regulatory markings for your country or region are located on the side of the product, on the packaging, or elsewhere in this document.

WARNING: To reduce the risk of fire or burns, do not disassemble, crush, or puncture; do not short external contacts; do not dispose of in fire or water.

RMN/型號/型号: HSN-W004P

© Copyright 2021 HP Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. First Edition: October 2021

PRINTER: Replace this box with Printed- In (PI) Statement(s) as per spec.

NOTE: This box is simply a placeholder. PI Statement(s) do not have to fit inside the box but should be placed in this area.



M98401-B21

MOB OPT SIP Flatman pen M98401-B21 v4.indd 2

9/15/2021 9:04:24 PM